# CTIAUTHSTATUS, CTI Authentication Status register

The CTIAUTHSTATUS characteristics are:

# **Purpose**

Provides information about the state of the implementation defined authentication interface for CTI.

# **Configuration**

CTIAUTHSTATUS is in the Debug power domain.

This register is optional, and is required for CoreSight compliance.

## **Attributes**

CTIAUTHSTATUS is a 32-bit register.

# Field descriptions

31 30 29 28	27 26 25 24	23 22 21 20 19 18 17 16	15 14 13 12	11 10 9 8	7 6 5	4 3 2 1 0
RES0	RAZ	RES0	RAZ	RES0	RAZ	NSNINSID

## Bits [31:28]

Reserved, res0.

#### Bits [27:24]

Reserved, RAZ.

#### Bits [23:16]

Reserved, res0.

## Bits [15:12]

Reserved, RAZ.

#### Bits [11:8]

Reserved, res0.

#### Bits [7:4]

Reserved, RAZ.

## NSNID, bits [3:2]

If EL3 is implemented, this field holds the same value as DBGAUTHSTATUS EL1.NSNID.

If EL3 is not implemented and the implemented Security state is Secure state, this field holds the same value as DBGAUTHSTATUS EL1.SNID.

#### **NSID**, bits [1:0]

If EL3 is implemented, this field holds the same value as DBGAUTHSTATUS EL1.NSID.

If EL3 is not implemented and the implemented Security state is Secure state, this field holds the same value as DBGAUTHSTATUS EL1.SID.

# **Accessing CTIAUTHSTATUS**

## CTIAUTHSTATUS can be accessed through the external debug interface:

Component	Offset	Instance
CTI	0xFB8	CTIAUTHSTATUS

Accesses on this interface are **RO**.

AArch32AArch64AArch32AArch64Index byExternalRegistersRegistersInstructionsInstructionsEncodingRegisters

28/03/2023 16:02; 72747e43966d6b97dcbd230a1b3f0421d1ea3d94

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.