<u>Base</u>	SIMD&FP	<u>SVE</u>	<u>SME</u>	Index by
<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	Encoding

SMC

Secure Monitor Call causes an exception to EL3.

SMC is available only for software executing at EL1 or higher. It is undefined in EL0.

If the values of *HCR_EL2*.TSC and *SCR_EL3*.SMD are both 0, execution of an SMC instruction at EL1 or higher generates a Secure Monitor Call exception, recording it in *ESR_ELx*, using the EC value 0x17, that is taken to EL3.

If the value of *HCR_EL2*.TSC is 1 and EL2 is enabled in the current Security state, execution of an SMC instruction at EL1 generates an exception that is taken to EL2, regardless of the value of *SCR_EL3*.SMD.

If the value of *HCR_EL2*.TSC is 0 and the value of *SCR_EL3*.SMD is 1, the SMC instruction is undefined.

31 30 29 28 27 26 25 24 23 22 21	20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5	4 3	2 1 0
1 1 0 1 0 1 0 0 0 0 0	imm16	0 0	0 1 1

```
SMC #<imm>
```

```
// Empty.
```

Assembler Symbols

<imm>

Is a 16-bit unsigned immediate, in the range 0 to 65535, encoded in the "imm16" field.

Operation

```
AArch64.CheckForSMCUndefOrTrap(imm16);
AArch64.CallSecureMonitor(imm16);
```

Internal version only: isa v33.64, AdvSIMD v29.12, pseudocode no diffs 2023 09 RC2, sve v2023-06 rel ; Build timestamp: 2023-09-18T17:56

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.

Sh Pseu

Sh Pseud