TRBMAR_EL1, Trace Buffer Memory Attribute Register

The TRBMAR EL1 characteristics are:

Purpose

Controls Trace Buffer Unit accesses to memory.

Configuration

External register TRBMAR_EL1 bits [63:0] are architecturally mapped to AArch64 System register TRBMAR_EL1[63:0].

This register is present only when FEAT_TRBE_EXT is implemented. Otherwise, direct accesses to TRBMAR_EL1 are res0.

TRBMAR EL1 is in the Core power domain.

Attributes

TRBMAR_EL1 is a 64-bit register.

Field descriptions

63 62 61 60 59 58 57 56 55 54 53 52 51 50 49 48 47 46 45 44 43 42 41 40 39 38 37 36 35 34 33 32

RES0					
RES0	PAS	SH	Attr		
31 30 20 28 27 26 25 24 23 22 21 20 10 18 17 16 15 14 13 12	11 10	0 8	7 6 5 / 3 2 1 0		

Bits [63:12]

Reserved, res0.

PAS, bits [11:10] When FEAT TRBE EXT is implemented:

Physical address specifier. Defines the PAS attribute for memory addressed by the buffer in External mode.

PAS	Meaning	Applies when
00d0	Secure.	When Secure state is implemented
0b01	Non- secure.	

0b10	Root.	When FEAT_RME is
		implemented
0b11	Realm.	When FEAT_RME is
		implemented

All other values are reserved.

If the Trace Buffer Unit is using external mode and either TRBMAR_EL1.PAS is set to a reserved value, or the implementation defined authentication interface prohibits invasive debug of the Security state corresponding to the physical address space selected by TRBMAR_EL1.PAS, then when the Trace Buffer Unit receives trace data from the trace unit, it does not write the trace data to memory and generates a trace buffer management event. That is, if any of the following apply:

- ExternalInvasiveDebugEnabled() == FALSE.
- Secure state is implemented, ExternalSecureInvasiveDebugEnabled() == FALSE, and TRBMAR EL1.PAS is 0b00.
- FEAT_RME is implemented, ExternalRootInvasiveDebugEnabled() == FALSE, and TRBMAR EL1.PAS is 0b10.
- FEAT_RME is implemented, ExternalRealmInvasiveDebugEnabled() == FALSE, and TRBMAR EL1.PAS is 0b11.

This field is ignored by the PE when SelfHostedTraceEnabled() == TRUE.

The reset behavior of this field is:

• On a Cold reset, this field resets to an architecturally unknown value.

Otherwise:

Reserved, res0.

SH, bits [9:8]

Trace buffer shareability domain. Defines the shareability domain for Normal memory used by the trace buffer.

SH	Meaning
0b00	Non-shareable.
0b10	Outer Shareable.
0b11	Inner Shareable.

All other values are reserved.

This field is ignored when TRBMAR_EL1.Attr specifies any of the following memory types:

- Any Device memory type.
- Normal memory, Inner Non-cacheable, Outer Non-cacheable.

All Device and Normal Inner Non-cacheable Outer Non-cacheable memory regions are always treated as Outer Shareable.

The reset behavior of this field is:

• On a Cold reset, this field resets to an architecturally unknown value.

Attr, bits [7:0] When TRBMAR_EL1.Attr == 0bxxxx0000:

Trace buffer memory type and attributes. Defines the memory type and, for Normal memory, the cacheability attributes, for memory addressed by the trace buffer.

Attr	Meaning	Applies when
0x00	Device-nGnRnE	
	memory.	
0x40	Normal memory,	When
	Inner Non-	FEAT_XS is
	cacheable,	implemented
	Outer Non-	
	cacheable with	
	the XS attribute	
0 - 0	set to 0.	TA71
0xA0	Normal memory,	When
	Inner Write-	FEAT_XS is
	through Cacheable,	implemented
	Outer Write-	
	through	
	Cacheable, Non-	
	transient, Read-	
	Allocate with	
	the XS attribute	
	set to 0.	
0xF0	Tagged Normal	When
	memory, Outer	FEAT_MTE2
	Write-Back Non-	is
	transient, Read-	implemented
	allocate Write-	
	allocate.	

All other values are reserved.

The reset behavior of this field is:

• On a Cold reset, this field resets to an architecturally unknown value.

When TRBMAR_EL1.Attr == 0b0000xxxx and TRBMAR_EL1.Attr != 0b00000000:

Trace buffer memory attributes. Defines the Device memory attributes for memory addressed by the trace buffer.

Attr	Meaning	Applies when
0x04	Device-nGnRE	
	memory.	
0x08	Device-nGRE	
	memory.	
0x0C	Device-GRE	
	memory.	
0x01	Device-	When
	nGnRnE	FEAT_XS is
	memory with	implemented
	the XS	
	attribute set to	
	0.	.
0x05	Device-nGnRE	When
	memory with the XS	FEAT_XS is
	attribute set to	implemented
	0.	
0x09	Device-nGRE	When
0x09	memory with	FEAT XS is
	the XS	implemented
	attribute set to	mpiomontoa
	0.	
0x0D	Device-GRE	When
01102	memory with	FEAT XS is
	the XS	implemented
	attribute set to	•
	0.	

All other values are reserved.

The reset behavior of this field is:

• On a Cold reset, this field resets to an architecturally unknown value.

When TRBMAR_EL1.Attr != 0bxxxx0000 and TRBMAR_EL1.Attr != 0b0000xxxx:

Trace buffer memory type and attributes. Defines the memory type and, for Normal memory, the Outer and Inner cacheability attributes, for memory addressed by the trace buffer.

	-
Attr	Meaning
0b0001xxxx	Normal memory, Outer Write-Through Transient,
0b0010xxxx	Write-allocate. Normal memory, Outer Write-Through Transient,
0b0011xxxx	Read-allocate. Normal memory, Outer Write-Through Transient, Read-allocate Write- allocate.
0b0100xxxx	Normal memory, Outer Non-cacheable.
0b0101xxxx	Normal memory, Outer Write-Back Transient, Write-allocate.
0b0110xxxx	Normal memory, Outer Write-Back Transient, Read-allocate.
0b0111xxxx	Normal memory, Outer Write-Back Transient, Read-allocate Write- allocate.
0b1000xxxx	Normal memory, Outer Write-Through Non- transient, No allocate.
0b1001xxxx	Normal memory, Outer Write-Through Non- transient, Write-allocate.
0b1010xxxx	Normal memory, Outer Write-Through Non- transient, Read-allocate.
0b1011xxxx	Normal memory, Outer Write-Through Non- transient, Read-allocate Write-allocate.
0b1100xxxx	Normal memory, Outer Write-Back Non-transient, No allocate.
0b1101xxxx	Normal memory, Outer Write-Back Non-transient, Write-allocate.

0b1110xxxx	Normal memory, Outer Write-Back Non-transient, Read-allocate.
0b1111xxxx	Normal memory, Outer Write-Back Non-transient, Read-allocate Write- allocate.
0bxxxx0001	Normal memory, Inner Write-Through Transient, Write-allocate.
0bxxxx0010	Normal memory, Inner Write-Through Transient, Read-allocate.
0bxxxx0011	Normal memory, Inner Write-Through Transient, Read-allocate Write- allocate.
0bxxxx0100	Normal memory, Inner Non-cacheable.
0bxxxx0101	Normal memory, Inner Write-Back Transient, Write-allocate.
0bxxxx0110	Normal memory, Inner Write-Back Transient, Read-allocate.
0bxxxx0111	Normal memory, Inner Write-Back Transient, Read-allocate Write- allocate.
0bxxxx1000	Normal memory, Inner Write-Through Non- transient, No allocate.
0bxxxx1001	Normal memory, Inner Write-Through Non- transient, Write-allocate.
0bxxxx1010	Normal memory, Inner Write-Through Non- transient, Read-allocate.
0bxxxx1011	Normal memory, Inner Write-Through Non- transient, Read-allocate Write-allocate.
0bxxxx1100	Normal memory, Inner Write-Back Non-transient, No allocate.
0bxxxx1101	Normal memory, Inner Write-Back Non-transient, Write-allocate.

0bxxxx1110	Normal memory, Inner
	Write-Back Non-transient,
	Read-allocate.
0bxxxx1111	Normal memory, Inner
	Write-Back Non-transient,
	Read-allocate Write-
	allocate.

The reset behavior of this field is:

• On a Cold reset, this field resets to an architecturally unknown value.

Otherwise:

Reserved, res0.

Accessing TRBMAR_EL1

The PE might ignore a write to TRBMAR_EL1 if any of the following apply:

- <u>TRBLIMITR_EL1</u>.E == 1 and the Trace Buffer Unit is using Selfhosted mode.
- <u>TRBLIMITR_EL1</u>.XE == 1 and the Trace Buffer Unit is using External mode.

TRBMAR_EL1 can be accessed through the external debug interface:

Component	Component Offset	
TRBE	0x028	TRBMAR_EL1

This interface is accessible as follows:

- When DoubleLockStatus(), or !IsCorePowered(), or OSLockStatus() or !AllowExternalTraceBufferAccess(), accesses to this register generate an error response.
- Otherwise, accesses to this register are **RW**.

AArch32	AArch64	AArch32	AArch64	Index by	<u>External</u>
<u>Registers</u>	<u>Registers</u>	<u>Instructions</u>	<u>Instructions</u>	Encoding	<u>Registers</u>

28/03/2023 16:02; 72747e43966d6b97dcbd230a1b3f0421d1ea3d94

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.