AArch64 Registers AArch32 Instructions AArch64 Instructions Index by Encoding

External Registers

ACTLR_EL2, Auxiliary Control Register (EL2)

The ACTLR EL2 characteristics are:

Purpose

Provides implementation defined configuration and control options for EL2.

Note

Arm recommends the contents of this register are updated to apply to EL0 when <u>HCR_EL2</u>. {E2H, TGE} is {1, 1}, gaining configuration and control fields from the <u>ACTLR_EL1</u>. This avoids the need for software to manage the contents of these register when switching between a Guest OS and a Host OS.

Configuration

AArch64 System register ACTLR_EL2 bits [31:0] are architecturally mapped to AArch32 System register HACTLR[31:0].

AArch64 System register ACTLR_EL2 bits [63:32] are architecturally mapped to AArch32 System register HACTLR2[31:0].

If EL2 is not implemented, this register is res0 from EL3.

This register has no effect if EL2 is not enabled in the current Security state.

Attributes

ACTLR_EL2 is a 64-bit register.

Field descriptions

63 62 61 60 59 58 57 56 55 54 53 52 51 50 49 48 47 46 45 44 43 42 41 40 39 38 37 36 35 34 33 32

IMPLEMENTATION DEFINED

IMPLEMENTATION DEFINED

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

IMPLEMENTATION DEFINED, bits [63:0]

implementation defined.

The reset behavior of this field is:

• On a Warm reset, this field resets to an architecturally unknown value.

Accessing ACTLR EL2

Accesses to this register use the following encodings in the System register encoding space:

MRS <Xt>, ACTLR_EL2

op0	op1	CRn	CRm	op2
0b11	0b100	0b0001	0b0000	0b001

```
if PSTATE.EL == EL0 then
    UNDEFINED;
elsif PSTATE.EL == EL1 then
    if EL2Enabled() && HCR_EL2.NV == '1' then
        Aarch64.SystemAccessTrap(EL2, 0x18);
    else
        UNDEFINED;
elsif PSTATE.EL == EL2 then
        X[t, 64] = ACTLR_EL2;
elsif PSTATE.EL == EL3 then
        X[t, 64] = ACTLR_EL2;
```

MSR ACTLR EL2, <Xt>

op0	op1	CRn	CRm	op2
0b11	0b100	0b0001	0b0000	0b001

```
if PSTATE.EL == EL0 then
    UNDEFINED;
elsif PSTATE.EL == EL1 then
    if EL2Enabled() && HCR_EL2.NV == '1' then
        AArch64.SystemAccessTrap(EL2, 0x18);
    else
        UNDEFINED;
elsif PSTATE.EL == EL2 then
    ACTLR_EL2 = X[t, 64];
```

elsif PSTATE.EL == EL3 then
 ACTLR_EL2 = X[t, 64];

AArch32 Registers AArch64 Registers AArch32 Instructions AArch64
Instructions

Index by Encoding

External Registers

 $28/03/2023\ 16:01;\ 72747e43966d6b97dcbd230a1b3f0421d1ea3d94$

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.