AArch64 Instructions Index by Encoding

External Registers

MPAMF_ERR_MSI_MPAM, MPAM Error MSI Write MPAM Information Register

The MPAMF ERR MSI MPAM characteristics are:

Purpose

MPAMF_ERR_MSI_MPAM is a 32-bit read/write register that sets the MPAM information for error MSI write attributes for MPAM errors in this MSC.

MPAMF_ERR_MSI_MPAM_s controls MPAM information labeling of Secure MPAM error MSI writes. MPAMF_ERR_MSI_MPAM_ns controls MPAM information labeling of Non-secure MPAM error MSI writes. MPAMF_ERR_MSI_MPAM_rt controls MPAM information labeling of Root MPAM error MSI writes. MPAMF_ERR_MSI_MPAM_rl controls MPAM information labeling of Realm MPAM error MSI writes.

Configuration

This register is present only when (FEAT_MPAMv0p1 is implemented or FEAT_MPAMv1p1 is implemented) and MPAMF_IDR.HAS_ERR_MSI == 1. Otherwise, direct accesses to MPAMF_ERR_MSI_MPAM are res0.

The power and reset domain of each MSC component is specific to that component.

Attributes

MPAMF_ERR_MSI_MPAM is a 32-bit register.

Field descriptions

31 30 29 28 27 26 25 24	23 22 21 20 19 18 17 16	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
RES0	PMG	PARTID

Bits [31:24]

Reserved, res0.

PMG, bits [23:16]

Performance monitoring group property for PARTID MSC error interrupt write.

The reset behavior of this field is:

• On a MSC reset, this field resets to an architecturally unknown value.

PARTID, bits [15:0]

Partition ID for MSC error interrupt write.

The PARTID in this register is in the Secure PARTID space in the MPAMF_ERR_MSI_MPAM_s instance and in the Non-secure PARTID space in the MPAMF_ERR_MSI_MPAM_ns instance of this register.

The reset behavior of this field is:

• On a MSC reset, this field resets to an architecturally unknown value.

Accessing MPAMF_ERR_MSI_MPAM

This register is within the MPAM feature page memory frames.

In a system that supports Secure, Non-secure, Root, and Realm memory maps, there must be MPAM feature pages in all four address maps:

- MPAMF_ERR_MSI_MPAM_s must only be accessible from the Secure MPAM feature page.
- MPAMF_ERR_MSI_MPAM_ns must only be accessible from the Non-secure MPAM feature page.
- MPAMF_ERR_MSI_MPAM_rt must only be accessible from the Root MPAM feature page.
- MPAMF_ERR_MSI_MPAM_rl must only be accessible from the Realm MPAM feature page.

MPAMF_ERR_MSI_MPAM_s, MPAMF_ERR_MSI_MPAM_ns, MPAMF_ERR_MSI_MPAM_rt, and MPAMF_ERR_MSI_MPAM_rl must be separate registers:

- The Secure instance (MPAMF_ERR_MSI_MPAM_s) accesses the MPAM information for MSI write request to signal an MPAM error used for Secure PARTIDs.
- The Non-secure instance (MPAMF_ERR_MSI_MPAM_ns) accesses the MPAM information for MSI write request to signal an MPAM error used for Non-secure PARTIDs.
- The Root instance (MPAMF_ERR_MSI_MPAM_rt) accesses the MPAM information for MSI write request to signal an MPAM error used for Root PARTIDs.
- The Realm instance (MPAMF_ERR_MSI_MPAM_rl) accesses the MPAM information for MSI write request to signal an MPAM error used for Realm PARTIDs.

MPAMF_ERR_MSI_MPAM can be accessed through the memory-mapped interfaces:

Component	Frame	Offset	Instance
MPAM	MPAMF_BASE_s	0x00DC	MPAMF_ERR_MSI_MPAM_s

Accesses on this interface are RW.

Component	Frame	Offset	Instance
MPAM	MPAMF_BASE_ns	0x00DC	MPAMF_ERR_MSI_MPAM_ns

Accesses on this interface are RW.

Component	Frame	Offset	Instance
MPAM	MPAMF_BASE_rt	0x00DC	MPAMF_ERR_MSI_MPAM_rt

When FEAT_RME is implemented, accesses on this interface are **RW**.

Component	Frame	Offset	Instance
MPAM	MPAMF_BASE_rl	0x00DC	MPAMF_ERR_MSI_MPAM_rl

When FEAT_RME is implemented, accesses on this interface are ${f RW}.$

AArch32	AArch64	AArch32	AArch64	<u>Index by</u>	<u>External</u>
<u>Registers</u>	<u>Registers</u>	<u>Instructions</u>	<u>Instructions</u>	Encoding	Registers

28/03/2023 16:02; 72747e43966d6b97dcbd230a1b3f0421d1ea3d94

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.