AFSR0_EL2, Auxiliary Fault Status Register 0 (EL2)

The AFSR0 EL2 characteristics are:

Purpose

Provides additional implementation defined fault status information for exceptions taken to EL2.

Configuration

AArch64 System register AFSR0_EL2 bits [31:0] are architecturally mapped to AArch32 System register <u>HADFSR[31:0]</u>.

If EL2 is not implemented, this register is res0 from EL3.

This register has no effect if EL2 is not enabled in the current Security state.

Attributes

AFSR0 EL2 is a 64-bit register.

Field descriptions

63 62 61 60 59 58 57 56 55 54 53 52 51 50 49 48 47 46 45 44 43 42 41 40 39 38 37 36 35 34 33 32

IMPLEMENTATION DEFINED

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

IMPLEMENTATION DEFINED, bits [63:0]

implementation defined.

The reset behavior of this field is:

• On a Warm reset, this field resets to an architecturally unknown value.

Accessing AFSR0 EL2

When <u>HCR_EL2</u>.E2H is 1, without explicit synchronization, access from EL2 using the mnemonic AFSR0_EL2 or AFSR0_EL1 are not guaranteed to be ordered with respect to accesses using the other mnemonic.

Accesses to this register use the following encodings in the System register encoding space:

MRS <Xt>, AFSR0_EL2

op0	op1	CRn	CRm	op2
0b11	0b100	0b0101	0b0001	0b000

```
if PSTATE.EL == EL0 then
    UNDEFINED;
elsif PSTATE.EL == EL1 then
    if EL2Enabled() && HCR_EL2.NV == '1' then
        AArch64.SystemAccessTrap(EL2, 0x18);
    else
        UNDEFINED;
elsif PSTATE.EL == EL2 then
    X[t, 64] = AFSR0_EL2;
elsif PSTATE.EL == EL3 then
    X[t, 64] = AFSR0_EL2;
```

MSR AFSR0_EL2, <Xt>

op0	op1	CRn	CRm	op2
0b11	0b100	0b0101	0b0001	0b000

```
if PSTATE.EL == EL0 then
    UNDEFINED;
elsif PSTATE.EL == EL1 then
    if EL2Enabled() && HCR_EL2.NV == '1' then
        AArch64.SystemAccessTrap(EL2, 0x18);
    else
        UNDEFINED;
elsif PSTATE.EL == EL2 then
    AFSRO_EL2 = X[t, 64];
elsif PSTATE.EL == EL3 then
    AFSRO_EL2 = X[t, 64];
```

When FEAT_VHE is implemented MRS <Xt>, AFSR0_EL1

op0	op1	CRn	CRm	op2
OPO		U	U	UP-

0b11 0b000 0b0101 0b0001 0b000	0b11	0b000	0b0101	0b0001	0b000
--	------	-------	--------	--------	-------

```
if PSTATE.EL == ELO then
    UNDEFINED;
elsif PSTATE.EL == EL1 then
    if EL2Enabled() && HCR_EL2.TRVM == '1' then
        AArch64.SystemAccessTrap(EL2, 0x18);
    elsif EL2Enabled() &&
IsFeatureImplemented(FEAT_FGT) && (!HaveEL(EL3) | |
SCR_EL3.FGTEn == '1') && HFGRTR_EL2.AFSR0_EL1 == '1'
then
        AArch64.SystemAccessTrap(EL2, 0x18);
    elsif EL2Enabled() && HCR_EL2.<NV2,NV1,NV> ==
'111' then
        X[t, 64] = NVMem[0x128];
    else
        X[t, 64] = AFSR0\_EL1;
elsif PSTATE.EL == EL2 then
    if HCR_EL2.E2H == '1' then
        X[t, 64] = AFSR0\_EL2;
    else
        X[t, 64] = AFSR0\_EL1;
elsif PSTATE.EL == EL3 then
    X[t, 64] = AFSR0\_EL1;
```

When FEAT_VHE is implemented MSR AFSR0_EL1, <Xt>

op0	op1	CRn	CRm	op2
0b11	0b000	0b0101	0b0001	0b000

```
if PSTATE.EL == ELO then
    UNDEFINED;
elsif PSTATE.EL == EL1 then
    if EL2Enabled() && HCR_EL2.TVM == '1' then
        AArch64.SystemAccessTrap(EL2, 0x18);
    elsif EL2Enabled() &&
IsFeatureImplemented(FEAT_FGT) && (!HaveEL(EL3)
SCR_EL3.FGTEn == '1') && HFGWTR_EL2.AFSR0 EL1 == '1'
then
        AArch64.SystemAccessTrap(EL2, 0x18);
    elsif EL2Enabled() && HCR_EL2.<NV2,NV1,NV> ==
'111' then
        NVMem[0x128] = X[t, 64];
    else
        AFSR0\_EL1 = X[t, 64];
elsif PSTATE.EL == EL2 then
    if HCR\_EL2.E2H == '1' then
        AFSR0\_EL2 = X[t, 64];
    else
        AFSR0\_EL1 = X[t, 64];
```

elsif PSTATE.EL == EL3 then
 AFSR0_EL1 = X[t, 64];

AArch32 Registers AArch64 Registers AArch32 Instructions AArch64
Instructions

Index by Encoding

External Registers

28/03/2023 16:02; 72747e43966d6b97dcbd230a1b3f0421d1ea3d94

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.