AMEVTYPER0<n>_EL0, Activity Monitors Event Type Registers 0, n = 0 - 3

The AMEVTYPER0<n>_EL0 characteristics are:

Purpose

Provides information on the events that an architected activity monitor event counter AMEVCNTR0<n>_EL0 counts.

Configuration

AArch64 System register AMEVTYPER0<n>_EL0 bits [31:0] are architecturally mapped to AArch32 System register AMEVTYPER0<n>[31:0].

AArch64 System register AMEVTYPER0<n>_EL0 bits [31:0] are architecturally mapped to External register AMEVTYPER0<n>[31:0].

This register is present only when FEAT_AMUv1 is implemented. Otherwise, direct accesses to AMEVTYPER0<n>_EL0 are undefined.

Attributes

AMEVTYPER0<n>_EL0 is a 64-bit register.

Field descriptions

63 62 61 60 59 58 57 56 55 54 53 52 51 50 49 48 47 46 45 44 43 42 41 40 39 38 37 36 35 34 33 32																															
RES0																															
RES0																				evtCount											
31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16																15 14 13 12 11 10				9		8		7		6		5		4		3		2		1		0	

Bits [63:16]

Reserved, res0.

evtCount, bits [15:0]

Event to count. The event number of the event that is counted by the architected activity monitor event counter AMEVCNTR0<n>_EL0. The value of this field is architecturally mandated for each architected counter.

The following table shows the mapping between required event numbers and the corresponding counters:

evtCount	Meaning	Applies when
0x0011	Processor frequency cycles	When n == 0
0x4004	Constant frequency cycles	When n == 1
0x0008	Instructions retired	When n == 2
0x4005	Memory stall cycles	When n == 3

Accessing AMEVTYPER0<n>_EL0

If <n> is greater than or equal to the number of architected activity monitor event counters, reads and writes of AMEVTYPER0<n>_EL0 are undefined.

Note

AMCGCR_EL0.CG0NC identifies the number of architected activity monitor event counters.

Accesses to this register use the following encodings in the System register encoding space:

MRS <Xt>, AMEVTYPER0<m>_EL0 ; Where m = 0-3

op0	op1	CRn	CRm	op2
0b11	0b011	0b1101	0b011:m[3]	m[2:0]

```
integer m = UInt(CRm<0>:op2<2:0>);

if m >= 4 then
    UNDEFINED;
elsif PSTATE.EL == EL0 then
    if Halted() && HaveEL(EL3) && EDSCR.SDD == '1'
&& boolean IMPLEMENTATION_DEFINED "EL3 trap priority
when SDD == '1'" && CPTR_EL3.TAM == '1' then
        UNDEFINED;
    elsif AMUSERENR_EL0.EN == '0' then
        if EL2Enabled() && HCR_EL2.TGE == '1' then
            AArch64.SystemAccessTrap(EL2, 0x18);
        else
```

```
            AArch64.SystemAccessTrap(EL1, 0x18);
    elsif EL2Enabled() && CPTR_EL2.TAM == '1' then
        AArch64.SystemAccessTrap(EL2, 0x18);
    elsif HaveEL(EL3) && CPTR_EL3.TAM == '1' then
        if Halted() && EDSCR.SDD == '1' then
            UNDEFINED;
        else
            AArch64.SystemAccessTrap(EL3, 0x18);
    else
        X[t, 64] = AMEVTYPER0_EL0[m];
elsif PSTATE.EL == EL1 then
    if Halted() && HaveEL(EL3) && EDSCR.SDD == '1'
&& boolean IMPLEMENTATION_DEFINED "EL3 trap priority
when SDD == '1'" && CPTR_EL3.TAM == '1' then
        UNDEFINED;
    elsif EL2Enabled() && CPTR_EL2.TAM == '1' then
        AArch64.SystemAccessTrap(EL2, 0x18);
    elsif HaveEL(EL3) && CPTR_EL3.TAM == '1' then
        if Halted() && EDSCR.SDD == '1' then
            UNDEFINED;
        else
            AArch64.SystemAccessTrap(EL3, 0x18);
    else
        X[t, 64] = AMEVTYPER0_EL0[m];
elsif PSTATE.EL == EL2 then
    if Halted() && HaveEL(EL3) && EDSCR.SDD == '1'
&& boolean IMPLEMENTATION_DEFINED "EL3 trap priority
when SDD == '1'" && CPTR_EL3.TAM == '1' then
        UNDEFINED;
    elsif HaveEL(EL3) && CPTR_EL3.TAM == '1' then
        if Halted() && EDSCR.SDD == '1' then
            UNDEFINED;
        else
            AArch64.SystemAccessTrap(EL3, 0x18);
    else
        X[t, 64] = AMEVTYPER0_EL0[m];
elsif PSTATE.EL == EL3 then
    X[t, 64] = AMEVTYPER0_EL0[m];
```


28/03/2023 16:02; 72747e43966d6b97dcbd230a1b3f0421d1ea3d94

Copyright Â© 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.