Base Instructions	SIMD&FP Instructions	<u>SVE</u> <u>Instructions</u>	SME Instructions	Index by Encoding
WFI				
Wait For Interruptow-power state information, see As described in would otherwise Exception level.	and remain there Wait For Interru Wait For Interru cause entry to a	e until a wakeup pt. pt, the execution low-power state	event occurs. For	or more ion that to a higher
31 30 29 28 27 26 25 2 1 1 0 1 0 1 0	$egin{array}{cccccccccccccccccccccccccccccccccccc$			
CRm op2				
WFI				
// Empty.				
Operation				
<pre>integer localtimeout = 1 << 64; // No local timeout event is Hint_WFI (localtimeout, WFxType_WFI);</pre>				
Base Instructions	SIMD&FP Instructions	<u>SVE</u> <u>Instructions</u>	SME Instructions	Index by Encoding
Internal version only: isa v33.64, AdvSIMD v29.12, pseudocode no_diffs_2023_09_RC2, sve v2023-06_rel ; Build timestamp: 2023-09-18T17:56				
Copyright \hat{A} © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.				

Sh Pseu

generat

Sh Pseu