EDDEVARCH, External Debug Device Architecture register

The EDDEVARCH characteristics are:

Purpose

Identifies the programmers' model architecture of the external debug component.

Configuration

When FEAT_DoPD is implemented, EDDEVARCH is in the Core power domain. Otherwise, EDDEVARCH is in the Debug power domain.

Implementation of this register is optional.

Attributes

EDDEVARCH is a 32-bit register.

Field descriptions

ARCHITECT, bits [31:21]

Defines the architecture of the component. For debug, this is Arm Limited.

Bits [31:28] are the JEP106 continuation code, 0x4.

Bits [27:21] are the JEP106 ID code, 0x3B.

Reads as 0b01000111011.

Access to this field is **RO**.

PRESENT, bit [20]

Indicates that the DEVARCH is present.

Reads as 0b1.

Access to this field is **RO**.

REVISION, bits [19:16]

Defines the architecture revision. For architectures defined by Arm this is the minor revision.

For debug, the revision defined by Armv8 is 0x0.

All other values are reserved.

Reads as 0b0000.

Access to this field is **RO**.

ARCHVER, bits [15:12]

Architecture Version. Defines the architecture version of the component. Defined values are:

ARCHVER	Meaning
0b0110	Armv8 debug architecture.
0b0111	Armv8 debug architecture with Virtualization Host Extensions.
0b1000	Armv8.2 debug architecture, FEAT_Debugv8p2.
0b1001	Armv8.4 debug architecture, FEAT_Debugv8p4.
0b1010	Armv8.8 debug architecture, FEAT_Debugv8p8.
0b1011	Armv8.9 debug architecture, FEAT_Debugv8p9.

EDDEVARCH.ARCHVER and EDDEVARCH.ARCHPART are also defined as a single field, EDDEVARCH.ARCHID, so that EDDEVARCH.ARCHVER is EDDEVARCH.ARCHID[15:12].

FEAT VHE adds the functionality identified by the value 0b0111.

FEAT_Debugv8p2 adds the functionality identified by the value 0b1000.

FEAT_Debugv8p4 adds the functionality identified by the value 0b1001.

FEAT_Debugv8p8 adds the functionality identified by the value 0b1010.

FEAT_Debugv8p9 adds the functionality identified by the value

From Armv8.1, when FEAT_VHE is implemented the value <code>0b0110</code> is not permitted.

From Armv8.2, the values 0b0110 and 0b0111 are not permitted.

From Armv8.4, the value 0b1000 is not permitted.

From Armv8.8, the value 0b1001 is not permitted.

From Armv8.9, the value 0b1010 is not permitted.

ARCHPART, bits [11:0]

Architecture Part. Defines the architecture of the component.

ARCHPART	Meaning
0xA15	Armv8-A debug
	architecture.

EDDEVARCH.ARCHVER and EDDEVARCH.ARCHPART are also defined as a single field, EDDEVARCH.ARCHID, so that EDDEVARCH.ARCHPART is EDDEVARCH.ARCHID[11:0].

Armv8-A debug architecture.

Access to this field is **RO**.

Accessing EDDEVARCH

EDDEVARCH can be accessed through the external debug interface:

Component	Offset	Instance
Debug	0xFBC	EDDEVARCH

This interface is accessible as follows:

- When FEAT_DoPD is not implemented or IsCorePowered(), accesses to this register are **RO**.
- Otherwise, accesses to this register generate an error response.

AArch32AArch64AArch32AArch64Index byExternalRegistersRegistersInstructionsInstructionsEncodingRegisters

28/03/2023 16:01; 72747e43966d6b97dcbd230a1b3f0421d1ea3d94

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.