<u>Base</u>	SIMD&FP	<u>SVE</u>	<u>SME</u>	Index by
<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	Encoding

Pseu

AUTDB, AUTDZB

Authenticate Data address, using key B. This instruction authenticates a data address, using a modifier and key B.

The address is in the general-purpose register that is specified by <Xd>.

The modifier is:

- In the general-purpose register or stack pointer that is specified by <Xn|SP> for AUTDB.
- The value zero, for AUTDZB.

If the authentication passes, the upper bits of the address are restored to enable subsequent use of the address. For information on behavior if the authentication fails, see *Faulting on pointer authentication*.

Integer (FEAT PAuth)

AUTDB (Z == 0)

```
AUTDB <Xd>, <Xn | SP>
```

AUTDZB (Z == 1 && Rn == 11111)

```
AUTDZB <Xd>
```

```
boolean source_is_sp = FALSE;
integer d = UInt(Rd);
integer n = UInt(Rn);

if !IsFeatureImplemented(FEAT_PAuth) then
        UNDEFINED;

if Z == '0' then // AUTDB
        if n == 31 then source_is_sp = TRUE;
else // AUTDZB
        if n != 31 then UNDEFINED;
```

Assembler Symbols

<Xd> Is the 64-bit name of the general-purpose destination register, encoded in the "Rd" field.

<Xn|SP> Is the 64-bit name of the general-purpose source register or stack pointer, encoded in the "Rn" field.

Operation

```
if IsFeatureImplemented(FEAT_PAuth) then
   if source_is_sp then
        X[d, 64] = AuthDB(X[d, 64], SP[], FALSE);
   else
        X[d, 64] = AuthDB(X[d, 64], X[n, 64], FALSE);
```

Internal version only: isa v33.64, AdvSIMD v29.12, pseudocode no diffs 2023 09 RC2, sve v2023-06 rel ; Build timestamp: 2023-09-18T17:56

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.

Sh Pseu