

Blix Minis - Disco Bot

Age 5+ | 35+ Parts | $12 CAD

Meet the smallest dancer in the Blix lineup. Build the Blix Minis Disco Bot, turn the lever, and watch it spring into a playful dance with every rotation. A yellow gear and a crank on the base plate drive the movement, so the body and arms swing as the lever turns. It's a quick, satisfying build that's fun to play with and looks great on display once you're done.

Full details, video and kits: brickandmotorlabs.com/builds/disco-bot.html

What You'll Learn

This quick, satisfying build introduces young builders to basic assembly and to how a turning lever drives a gear and crank to make a model move.

What's In The Box

- 35+ Premium Blix Building Parts
- Step-By-Step Instruction Manual
- A Blix Minis set that connects to the other Blix sets on our tables

Build Models

1 model · 35+ parts · ages 5+

Disco Bot

Build the bot on its legs with the yellow gear and crank on the base plate, then turn the lever to watch the body and arms swing in a playful dance.

Stay in the loop

Event dates, new kits and offers. We only email when it matters.

Your email address