

# Scaffold-Free 3D Cell Culture: A Revolution in Predictive Disease Modeling and Drug Discovery

Generated at: 2026-04-03

Source URL: <https://www.cellbiotech.com/posts/scaffoldfree-3d-cell-culture-a-revolution-in-predictive-disease-modeling-and-drug-discovery>

## Scaffold-Free 3D Cell Culture: A Revolution in Predictive Disease Modeling and Drug Discovery

### Abstract

This article provides a comprehensive overview of scaffold-free 3D cell culture, an advanced technique where cells self-assemble into three-dimensional structures like spheroids and organoids without an artificial extracellular matrix. Tailored for researchers, scientists, and drug development professionals, it covers the foundational principles, key methodological approaches, and diverse applications in cancer research, regenerative medicine, and personalized therapy testing. The content also addresses critical challenges such as standardization and limited mechanical support, offers troubleshooting and optimization strategies, and delivers a rigorous comparative analysis against traditional 2D and scaffold-based 3D models, highlighting its superior physiological relevance for improving preclinical prediction.

### Beyond the Monolayer: Understanding Scaffold-Free 3D Cell Culture and Its Core Principles

Scaffold-free 3D cell culture represents a advanced *in vitro* technique where cells are grown in an environment that enables them to interact with each other in all three dimensions, forming complex tissue-like structures without the use of artificial supporting matrices [1]. This methodology leverages cells' innate ability to **self-assemble** into spheroids, organoids, or other constructs through their own secreted extracellular matrix (ECM) components [2] [3]. Unlike traditional 2D monolayers where cells grow on flat plastic surfaces, scaffold-free 3D models allow cells to establish more natural cell-cell contacts and signaling patterns that closely mimic the *in vivo* architecture of human tissues [1] [4].

The fundamental distinction between scaffold-free and scaffold-based approaches lies in their structural support mechanisms. While **scaffold-based systems** utilize natural or synthetic materials (such as collagen, alginate, or synthetic polymers) to provide a 3D framework for cell growth [5] [4], **scaffold-free techniques** rely exclusively on the cells' autonomous capacity to secrete their own ECM and organize into complex structures [3]. This self-assembly process results in tissue models with enhanced physiological relevance, making them particularly valuable for drug discovery, disease modeling, and basic biological research [6] [1].

### Key Advantages and Physiological Relevance

Scaffold-free 3D cell culture systems offer several significant advantages over traditional 2D cultures, primarily stemming from their superior ability to mimic the *in vivo* microenvironment [7] [1].

#### Enhanced Physiological Mimicry

Cells cultured in scaffold-free 3D environments exhibit **more natural behaviors** and biological responses compared to their 2D counterparts. They develop characteristic gradients of nutrients, oxygen, and signaling molecules that drive the formation of distinct cellular zones—proliferating cells on the exterior, quiescent cells in the middle, and in larger structures, necrotic cells at the core [7]. This organizational pattern closely resembles the microarchitecture found in actual tumors and tissues [7]. Research has demonstrated that cells in 3D cultures show notable differences in **gene and protein expression** profiles for key signaling pathways, including epidermal growth factor receptors (EGFR), phosphorylated protein kinase B (phospho-AKT), and p42/44 mitogen-activated protein kinases (phospho-MAPK) [7].

#### Improved Predictive Value in Drug Testing

Scaffold-free 3D models provide **more accurate predictions** of drug efficacy and toxicity. Studies have consistently shown that cells in 3D cultures demonstrate different drug sensitivity profiles, often exhibiting higher resistance to chemotherapeutic agents similar to responses observed in human tumors [7] [1] [4]. For instance, research has revealed that 3D spheroids show higher survival rates after exposure to paclitaxel compared to 2D monolayers, better simulating *in vivo* chemosensitivity [7]. This enhanced predictive power helps bridge the gap between traditional preclinical models and human clinical responses, potentially reducing drug attrition rates in later development stages [1].

Table 1: Comparative Analysis of 2D vs. Scaffold-Free 3D Cell Culture Models

| Characteristic         | 2D Cell Culture                        | Scaffold-Free 3D Cell Culture     |
|------------------------|----------------------------------------|-----------------------------------|
| Cell Morphology        | Flat, stretched                        | Natural, three-dimensional        |
| Cell-Cell Interactions | Limited to monolayer edges             | Extensive in all dimensions       |
| Cell Signaling         | Altered by artificial substrate        | More physiologically relevant     |
| Gene Expression        | Different from <i>in vivo</i> patterns | Closer to <i>in vivo</i> patterns |
| Drug Responses         | Often overestimated efficacy           | Better predicts clinical outcomes |
| Microenvironment       | Homogeneous nutrient/gas exchange      | Creates physiological gradients   |
| Tissue Organization    | Limited to monolayer                   | Forms complex architectures       |

Applications in Research and Medicine

The physiological relevance of scaffold-free 3D cultures has enabled their application across multiple biomedical domains [4]. In **cancer research**, they provide superior models for studying tumor biology, metastasis, and drug resistance mechanisms [7] [1]. For **drug discovery and toxicity testing**, these systems offer more human-relevant platforms for high-throughput screening of compound libraries [6] [4]. In **regenerative medicine**, scaffold-free approaches like cell sheet engineering are being explored for creating functional tissues for transplantation, with applications demonstrated in periodontal, corneal, and cartilage repair [6].

Key Techniques and Methodologies

Several established techniques enable scaffold-free 3D culture, each with specific mechanisms, advantages, and ideal applications.

Hanging Drop Method

The **hanging drop technique** is one of the most accessible approaches for generating uniform spheroids. This method utilizes specialized plates or manual setups where cells in suspension are dispensed as droplets onto the underside of a culture dish lid. Gravity causes the cells to accumulate at the bottom of the droplet, promoting aggregation and spheroid formation [6] [4]. The hanging drop method produces **highly consistent** spheroids with minimal equipment requirements, making it particularly suitable for high-throughput screening applications and drug testing [6]. Commercially available platforms include 3D Biomatrix's Perfecta3D Hanging Drop Plates and various laboratory-adapted protocols [5].

Low-Adhesion Surfaces

Using **low-adhesion surfaces** treated with hydrophilic or neutrally charged polymers prevents cell attachment, encouraging cells to aggregate and form spheroids. These surfaces include ultra-low attachment (ULA) plates coated with hydrogels like poly-2-hydroxyethyl methacrylate (poly-HEMA) or covalently bound hydrogel layers that create a non-fouling surface [6] [5]. This approach supports **high-yield spheroid formation** with relatively simple protocols that can be easily scaled. The method is widely accessible through commercially available plates from companies like Corning and Thermo Fisher Scientific [8].

Magnetic Levitation

**Magnetic levitation** employs magnetic nanoparticles to manipulate cell positioning in 3D space. Cells are first incubated with biocompatible magnetic nanoparticles, then placed in a magnetic field that encourages them to aggregate and levitate, forming 3D structures [6] [2]. This technique provides **precise control** over spheroid size and location, and allows for real-time manipulation of the forming structures. The magnetic bioprinting technology developed by n3D Biosciences (now part of Greiner Bio-One) is a notable commercial implementation of this method [8].

Rotating Bioreactors

**Rotating bioreactors** (such as rotary cell culture systems from Synthecon) maintain cells in constant free-fall by rotating the culture vessel, preventing attachment and promoting aggregation through gentle mixing [8] [3]. These systems support the formation of **larger tissue constructs** with enhanced nutrient exchange and reduced shear stress compared to static cultures. While excellent for generating substantial tissue volumes, rotating bioreactors require specialized equipment and may have limitations for high-throughput applications [3].

Table 2: Scaffold-Free 3D Cell Culture Techniques and Applications

| Technique    | Mechanism                                          | Advantages                               | Common Applications                     |
|--------------|----------------------------------------------------|------------------------------------------|-----------------------------------------|
| Hanging Drop | Gravity-mediated aggregation in suspended droplets | High uniformity, minimal equipment needs | High-throughput screening, drug testing |

| Technique             | Mechanism                                                | Advantages                                            | Common Applications                      |
|-----------------------|----------------------------------------------------------|-------------------------------------------------------|------------------------------------------|
| Low-Adhesion Surfaces | Prevention of cell attachment using specialized coatings | Simple protocol, easily scalable                      | Spheroid formation, cancer research      |
| Magnetic Levitation   | Magnetic nanoparticle-mediated cell assembly             | Precise spatial control, real-time manipulation       | Complex tissue modeling, bioprinting     |
| Rotating Bioreactors  | Continuous suspension through vessel rotation            | Supports large constructs, enhanced nutrient exchange | Tissue engineering, larger tissue models |

Experimental Protocols

Standardized Protocol for Hanging Drop Spheroid Formation

The following protocol details the generation of uniform spheroids using the hanging drop method, suitable for various cell types including cancer cell lines and primary cells.

Materials Required:

- Cell culture of interest (e.g., cancer cell lines)
- Complete culture medium
- Hanging drop plates or standard culture dishes
- Pipettes and sterile tips
- Centrifuge
- Hemocytometer or automated cell counter

Procedure:

- **Cell Preparation:** Harvest cells using standard trypsinization procedures and centrifuge at 300 × g for 5 minutes. Resuspend the cell pellet in complete culture medium.
- **Cell Counting:** Determine cell concentration using a hemocytometer or automated cell counter. Adjust concentration to achieve desired cell density per spheroid (typically 1,000-10,000 cells/drop depending on cell type and spheroid size requirements).
- **Drop Dispensing:** Aliquot the cell suspension as droplets on the hanging drop plate lid (typically 20-40 µL per drop). Carefully invert the lid and place it on the matching reservoir filled with phosphate-buffered saline (PBS) to maintain humidity.
- **Incubation:** Culture the plates at 37°C with 5% CO<sub>2</sub> for 3-7 days. Spheroids typically form within 24-72 hours, depending on cell type and initial density.
- **Spheroid Harvesting:** To collect formed spheroids, carefully pipette medium over the drops to wash spheroids into a collection tube or directly onto assay plates.
- **Quality Assessment:** Examine spheroid morphology, size distribution, and integrity using light microscopy. Uniform, spherical structures with smooth edges indicate successful formation.

Spheroid-Based Drug Sensitivity Assay

This protocol adapts traditional drug testing for 3D spheroid models, accounting for their different growth kinetics and drug penetration characteristics.

Materials Required:

- Pre-formed spheroids (prepared using hanging drop or other methods)
- Test compounds in appropriate solvents
- Low-attachment 96-well plates
- Cell viability assay reagents (e.g., Alamar Blue, CellTiter-Glo 3D)
- Multichannel pipettes
- Microplate reader

Procedure:

- **Spheroid Distribution:** Transfer individual spheroids to each well of a low-attachment 96-well plate containing 100-200 µL of culture medium.
- **Drug Treatment:** Prepare serial dilutions of test compounds in culture medium. Add compounds to spheroids in triplicate for each concentration. Include vehicle controls (0.1% DMSO or equivalent).

- **Incubation:** Incubate treated spheroids at 37°C with 5% CO2 for 3-7 days, depending on the doubling time of the cell type and experimental objectives.
- **Viability Assessment:**
  - For metabolic assays: Add 10% (v/v) Alamar Blue reagent to each well and incubate for 2-4 hours. Measure fluorescence (Ex560/Em590).
  - For ATP-based assays: Add equal volume of CellTiter-Glo 3D reagent, shake for 5 minutes, and incubate for 25 minutes. Measure luminescence.
- **Data Analysis:** Calculate percentage viability relative to vehicle-treated controls. Determine IC50 values using non-linear regression analysis of the dose-response curves.

Troubleshooting Notes:

- Incomplete spheroid formation may require optimization of initial cell density.
- Edge effects in plates can be minimized by using perimeter wells for controls only.
- Drug penetration issues may necessitate longer exposure times compared to 2D cultures.

Research Reagent Solutions

Successful implementation of scaffold-free 3D cell culture requires specific reagents and tools designed to support cell aggregation and maintain 3D structures.

Table 3: Essential Research Reagents for Scaffold-Free 3D Cell Culture

| Reagent/Tool                      | Function                                                   | Example Products                                             |
|-----------------------------------|------------------------------------------------------------|--------------------------------------------------------------|
| Ultra-Low Attachment (ULA) Plates | Prevent cell attachment, promote spheroid formation        | Corning Spheroid Microplates, Nunclon Sphera                 |
| Hanging Drop Plates               | Facilitate gravity-mediated spheroid formation             | 3D Biomatrix Perfecta3D, GravityPLUS                         |
| Specialized Culture Media         | Support 3D growth and maintain viability                   | STEMCELL Technologies mTeSR, Various serum-free formulations |
| Magnetic Nanoparticles            | Enable magnetic levitation and bioprinting                 | NanoShuttle from Greiner Bio-One                             |
| Viability Assays                  | Assess metabolic activity and cell health in 3D structures | CellTiter-Glo 3D, Alamar Blue, Calcein AM                    |
| Rotating Bioreactors              | Provide dynamic culture conditions for larger constructs   | Synthecon RCCS, Rotary Cell Culture Systems                  |

Market Landscape and Future Perspectives

The scaffold-free 3D cell culture market demonstrates robust growth, reflecting increasing adoption across research and pharmaceutical development. The market was valued at approximately **USD 534.7 million in 2025** and is projected to reach **USD 1.85 billion by 2035**, growing at a compound annual growth rate (CAGR) of **14.8%** [6]. This expansion is driven by the rising demand for more physiologically relevant models in drug discovery, coupled with regulatory pressures to reduce animal testing [6].


Key players in this market include **InSphero**, **N3d Biosciences** (now part of Greiner Bio-One), **Kuraray**, **Thermo Fisher Scientific**, and **Corning Incorporated** [8] [3]. These companies provide specialized platforms, reagents, and instrumentation that support various scaffold-free methodologies. The market is characterized by ongoing technological innovation, particularly in automation, integration with high-throughput screening, and applications in personalized medicine [2].

Future developments in scaffold-free 3D culture are likely to focus on enhancing **standardization and reproducibility**, which remain significant challenges [6]. Additional areas of innovation include the integration of **multiple cell types** to create more complex tissue models, advanced **imaging and analysis techniques** for 3D structures, and the convergence of scaffold-free approaches with **3D bioprinting** technologies to create architecturally defined tissues [2] [9]. As these technologies mature, they are expected to play an increasingly important role in precision medicine, enabling patient-specific disease modeling and therapy selection [1].

Visualizing Scaffold-Free 3D Culture Processes


The following diagrams illustrate key processes and relationships in scaffold-free 3D cell culture systems.

Self-Assembly Mechanism in Scaffold-Free 3D Culture



*Self-Assembly Mechanism in Scaffold-Free 3D Culture*

#### **Experimental Workflow for Drug Screening Application**



*Experimental Workflow for Drug Screening Application*

Scaffold-free three-dimensional (3D) cell culture has emerged as a transformative approach in biomedical research, offering a more physiologically relevant microenvironment for cells compared to traditional two-dimensional (2D) monolayers. This technology enables cells to self-assemble into tissue-like structures such as spheroids, organoids, and cell sheets without relying on exogenous biomaterials [2]. By eliminating artificial scaffolds,

these systems circumvent associated complications including foreign body responses, incomplete biodegradation, and altered cellular behavior due to synthetic matrix interactions [10] [11].

The fundamental advantage of scaffold-free systems lies in their capacity to preserve native tissue architecture through cell-directed deposition of extracellular matrix (ECM) and the establishment of natural cell-cell interactions [11]. These systems effectively mimic the in vivo microenvironment, allowing cells to maintain their inherent morphology, signaling pathways, and functional capabilities [12]. This application note details the core advantages of scaffold-free 3D culture technologies, with specific emphasis on their ability to preserve native ECM, enhance cell-cell interactions, and maintain tissue-specific function, while providing detailed protocols for implementation in research and drug development settings.

Core Advantages of Scaffold-Free 3D Culture Systems

Preservation of Native Extracellular Matrix

In scaffold-free systems, cells synthesize and assemble their own ECM, creating a tissue-specific microenvironment that closely resembles native conditions. This endogenous ECM provides appropriate biochemical cues and mechanical signals that direct cellular behavior, differentiation, and function [13] [11]. Unlike scaffold-based approaches that utilize exogenous materials, scaffold-free methods allow cells to produce ECM components—including fibronectin, laminin, tenascin C, and collagen VI  $\alpha 3$ —in physiological proportions and organizational patterns [11]. Research demonstrates that scaffold-free 3D models exhibit **appropriate upregulation and downregulation of disease-relevant pathways**, accurately mirroring in vivo protein expression patterns [13].

Enhanced Cell-Cell Interactions

Scaffold-free technologies facilitate direct cell-cell contact and communication through the formation of specialized junctions and signaling complexes. The 3D architecture enables cells to establish spatial relationships and interactions that mirror their natural organization in tissues [12]. These enhanced interactions are crucial for maintaining tissue homeostasis, coordinating cellular responses, and enabling the emergence of complex tissue-level functions [14]. Studies comparing 2D and 3D culture systems have consistently demonstrated that scaffold-free cultures exhibit **more common cell-cell junctions** and **enhanced cell-cell communication** compared to their 2D counterparts [12] [11].

Maintenance of Tissue-Specific Function

The preservation of native ECM and enhanced cell-cell interactions in scaffold-free systems collectively support the maintenance of tissue-specific functions. Cells cultured in these environments maintain normal polarization, gene expression profiles, and metabolic activities that closely resemble in vivo conditions [11] [7]. This functional relevance is particularly valuable for disease modeling, drug screening, and toxicology studies where predictive accuracy is paramount. Evidence indicates that scaffold-free 3D cultures **better mimic the natural tumor microenvironment** and provide **more clinically representative responses to therapeutic agents** compared to traditional 2D systems [12] [14].

Table 1: Comparative Analysis of 2D, Scaffold-Based 3D, and Scaffold-Free 3D Culture Systems

| Characteristic             | 2D Culture                       | Scaffold-Based 3D                         | Scaffold-Free 3D                     |
|----------------------------|----------------------------------|-------------------------------------------|--------------------------------------|
| ECM Composition            | Artificial, limited deposition   | Exogenous, predefined                     | Endogenous, cell-directed            |
| Cell-Cell Interactions     | Limited to monolayer edges       | Moderate, scaffold-dependent              | Extensive, natural organization      |
| Tissue Architecture        | Flat, unnatural polarization     | Variable, material-dependent              | Physiological, self-organized        |
| Mechanical Properties      | Rigid, uniform                   | Determined by scaffold material           | Tissue-like, dynamic                 |
| Signaling Microenvironment | Homogeneous, diluted             | Partially controlled by scaffold          | Physiological gradients present      |
| Drug Response              | Hyper-sensitive, less predictive | Variable, scaffold influences penetration | Physiological resistance, predictive |
| Scalability                | High, standardized               | Moderate, batch variations                | Moderate, size-limited by diffusion  |

Quantitative Assessment of Performance Advantages

Robust quantitative evidence supports the superior performance of scaffold-free 3D culture systems across multiple experimental parameters. The tables below summarize key comparative data that highlight the physiological relevance and functional advantages of these platforms.

Table 2: Quantitative Performance Metrics of Scaffold-Free 3D Culture Systems

| Parameter                  | 2D Culture Performance              | Scaffold-Free 3D Performance         | Significance                                | Reference                     |
|----------------------------|-------------------------------------|--------------------------------------|---------------------------------------------|-------------------------------|
| Cell Viability             | Decreased over time [11]            | Enhanced viability [11]              | Improved long-term culture maintenance      | npj Regenerative Medicine     |
| ECM Protein Production     | Limited deposition [11]             | Substantially greater amounts [11]   | Enhanced tissue-like matrix formation       | APL Bioengineering            |
| Stemness Marker Expression | Moderate (Sox-2, Oct-4, Nanog) [11] | Enhanced expression [11]             | Better maintenance of progenitor phenotypes | APL Bioengineering            |
| Drug Resistance            | Hyper-sensitive [12] [14]           | Physiological resistance [12] [14]   | Better prediction of clinical response      | Journal of Biomedical Science |
| Secretory Profile          | Reduced growth factors [11]         | Increased VEGF, HGF, FGF2, MMPs [11] | Enhanced paracrine signaling potential      | APL Bioengineering            |
| Differentiation Potential  | Compromised [11]                    | Preserved multilineage capacity [11] | Improved tissue-specific differentiation    | APL Bioengineering            |

Table 3: Documented Applications of Scaffold-Free 3D Cultures in Disease Modeling

| Tissue/Disease Model        | Cell Source               | Scaffold-Free Format | Key Outcomes                                                                             | Reference                     |
|-----------------------------|---------------------------|----------------------|------------------------------------------------------------------------------------------|-------------------------------|
| Duchenne Muscular Dystrophy | Patient primary myoblasts | Anchored cell sheets | Recapitulated disease phenotype, accurate ECM composition, drug response validation [13] | Advanced Healthcare Materials |
| Myotonic Dystrophy Type 1   | Patient primary myoblasts | Anchored cell sheets | Mirrored in vivo protein expression, pathway dysregulation [13]                          | Advanced Healthcare Materials |
| Cancer Research             | Various tumor cells       | Spheroids            | Better mimicry of tumor microenvironment, drug resistance [12] [14]                      | Journal of Biomedical Science |
| Periodontal Regeneration    | PDL-derived stem cells    | Cell sheets          | Successful tissue regeneration in periodontitis models [6]                               | Research Nester               |
| Corneal Epithelium Repair   | Limbal epithelial cells   | Cell sheets          | Effective treatment for limbal stem cell deficiency [6]                                  | Research Nester               |

## Experimental Protocols

### Protocol 1: Cell Sheet Engineering Using Temperature-Responsive Surfaces

**Principle:** Utilizes temperature-responsive polymer poly(N-isopropylacrylamide) (pNIPAM) grafted surfaces that transition from hydrophobic (37°C) to hydrophilic (<32°C), enabling cell sheet detachment with intact ECM and cell junctions [10].

#### Materials:

- Temperature-responsive culture dishes (e.g., UpCell)
- Standard cell culture medium and supplements
- Primary cells or cell lines of interest
- Low-temperature incubation capability (20-25°C)

#### Methodology:

- Seed cells onto temperature-responsive surfaces at optimal density (e.g., 104,000 cells/cm² for human endometrial gland-derived MSCs) [10]
- Culture at 37°C for 3-7 days until confluent, allowing ECM deposition and cell sheet formation
- Reduce temperature to 20-25°C for 30-60 minutes to initiate polymer hydration and sheet detachment
- Gently transfer detached cell sheets using supportive membranes or direct application to target surfaces
- For multilayer constructs, sequentially stack individual sheets with careful handling

#### Technical Notes:

- Preserved ECM proteins enable adhesive properties without sutures [10]



- Automation systems available for scalable production [\[10\]](#)
- Thickness limitation of ~40-80µm for avascular constructs [\[10\]](#)

## **Protocol 2: Scaffold-Free Spheroid Formation via Hanging Drop Method**

**Principle:** Utilizes gravity-enforced cell aggregation in suspended droplets to form uniform spheroids through self-assembly, without external scaffolds [\[15\]](#).

### **Materials:**

- Hanging drop plates or conventional plates with lid-access
- Cell suspension at standardized density
- Appropriate culture medium

### **Methodology:**

- Prepare cell suspension at optimized density (e.g.,  $1 \times 10^4$  -  $5 \times 10^4$  cells/mL depending on spheroid size requirements)
- Aliquot 20-50µL drops onto plate lid, ensuring consistent volume across droplets
- Invert lid carefully and place over bottom chamber containing PBS to maintain humidity
- Culture for 3-7 days, monitoring spheroid formation daily
- Harvest mature spheroids by washing with gentle centrifugation

### **Technical Notes:**

- Enables high-throughput spheroid production [\[15\]](#)
- Produces uniform size distribution ideal for drug screening [\[14\]](#)
- Minimal equipment requirements facilitate adoption across lab settings

## **Protocol 3: Anchored Cell Sheet Engineering for 3D Tissue Models**

**Principle:** Advanced scaffold-free platform combining cell sheet technology with anchoring systems to create complex 3D structures with mature tissue phenotypes [\[13\]](#).

### **Materials:**

- Custom culture devices with 3D-printed master mold
- PDMS or Ecoflex 00-30 for pillar fabrication
- Tannic acid for membrane hydrophilicity adjustment
- Vitronectin for enhanced cell attachment

### **Methodology:**

- Fabricate culture devices using 3D-printed mold with parallel patterning for cell alignment
- Treat PDMS base membrane with tannic acid solution and sterilize by autoclaving
- Coat devices with vitronectin to improve cell attachment
- Seed primary cells (e.g.,  $5 \times 10^5$  myoblasts in 3mL growth medium) [\[13\]](#)
- Culture until confluent sheets form with substantial endogenous ECM deposition
- Utilize anchored structures to create tension and 3D organization

### **Technical Notes:**

- Replicates mature tissue phenotypes and disease-specific ECM [\[13\]](#)
- Superior to traditional 3D models in replicating structural and biochemical properties [\[13\]](#)
- Enables patient-specific disease modeling and drug testing [\[13\]](#)






Diagram Title: Scaffold-Free 3D Culture Advantages Workflow

The Scientist's Toolkit: Essential Research Reagents

Table 4: Essential Research Reagents for Scaffold-Free 3D Culture Applications

| Reagent/Category                | Specific Examples                                | Function & Application                                                                            | Technical Considerations                                                 |
|---------------------------------|--------------------------------------------------|---------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------|
| Temperature-Responsive Polymers | poly(N-isopropylacrylamide) (pNIPAM)             | Enables non-enzymatic cell sheet harvesting via temperature-dependent hydrophobicity changes [10] | LCST ~32°C; various modifications available for specific cell types [10] |
| Surface Patterning Reagents     | Tannic acid, Vitronectin                         | Modifies surface hydrophilicity and promotes cell attachment in anchored systems [13]             | Critical for cell alignment and enhanced ECM deposition [13]             |
| ECM Characterization Antibodies | Anti-fibronectin, anti-laminin, anti-collagen VI | Detection and quantification of endogenous ECM production in 3D constructs [13] [11]              | Essential for validating native matrix composition                       |
| Viability/Cytotoxicity Assays   | CCK-8, MTS, Live/Dead staining                   | Assessment of cell viability and metabolic activity in 3D structures [14]                         | Require optimization for 3D penetration and accuracy                     |
| Morphological Analysis Tools    | H&E, Masson's Trichrome, Movat's Pentachrome     | Histological evaluation of 3D tissue architecture and matrix composition [13]                     | Specialized sectioning techniques required for 3D samples                |

Technological Applications and Implementation Strategies

Integration in Drug Discovery pipelines

The pharmaceutical industry increasingly incorporates scaffold-free 3D models into discovery workflows to enhance predictive accuracy. These systems demonstrate particular utility in **oncological drug screening**, where they better replicate the chemoresistance observed in clinical tumors [14]. The market for scaffold-free 3D cell culture is projected to grow significantly from USD 534.7 million in 2025 to USD 1.85 billion by 2035, reflecting increasing adoption in drug discovery applications [6].

Implementation framework:

- **Target Identification:** Utilize patient-derived spheroids for target validation in physiologically relevant context
- **Lead Optimization:** Assess compound efficacy and penetration in 3D models prior to animal studies
- **Toxicity Screening:** Employ organotypic models for predictive hepatotoxicity and cardiotoxicity testing
- **Personalized Medicine:** Develop patient-specific models for individualized therapeutic selection

Automation and Scaling Solutions

Recent technological advances have addressed scalability challenges through automated systems that maintain aseptic conditions while producing high-quality cellular constructs comparable to manual operations [10]. Robotic systems can successfully stack multiple cell sheets within 100 minutes, representing cost-effective manufacturing solutions [10]. Simultaneous culture of up to 50 cell sheets in automated circuit systems has been demonstrated while maintaining quality standards [10].




Diagram Title: Scaffold-Free 3D Culture Signaling Pathways

Concluding Remarks

Scaffold-free 3D cell culture systems represent a significant advancement in experimental biology by preserving native ECM, enhancing cell-cell interactions, and maintaining tissue-specific functions. The protocols and data presented herein provide researchers with practical frameworks for implementing these technologies across diverse applications from basic research to drug development. As automation improves and standardization increases, scaffold-free approaches are poised to become essential tools for bridging the gap between conventional cell culture and clinical translation, ultimately enhancing the predictive accuracy of preclinical research and accelerating the development of effective therapies.

The field of preclinical research is undergoing a significant transformation, driven by the convergence of scientific advancement and regulatory evolution. **Scaffold-free 3D cell cultures**—where cells self-assemble into complex, tissue-like structures such as spheroids and organoids without an artificial supporting matrix—are at the forefront of this change [3]. These models bridge the critical gap between traditional **two-dimensional (2D) cell cultures** and **animal models**, offering a more physiologically relevant human cell-based system for drug discovery and disease modeling [7] [16]. This shift is primarily fueled by two major market drivers: the relentless demand for more predictive models in drug development to reduce attritions rates, and a global regulatory push to reduce reliance on animal testing. These drivers are propelling the adoption of 3D technologies, with the scaffold-free 3D cell culture market projected to grow from USD 534.7 million in 2025 to USD 1.85 billion by 2035, representing a compound annual growth rate (CAGR) of 14.8% [6]. These advanced culture systems more accurately mimic the in vivo tumor microenvironment (TME), including cell-cell interactions, nutrient and oxygen gradients, and the development of hypoxic cores, all of which are crucial for predicting drug response and resistance [7] [17].

Market Driver 1: The Demand for Predictive, Physiologically Relevant Models

The high failure rate of drug candidates in clinical trials, often due to efficacy and safety issues not predicted by existing models, has created an urgent need for more physiologically relevant testing platforms [18] [7]. Scaffold-free 3D models meet this need by recapitulating key aspects of in vivo biology that traditional 2D cultures cannot.

- **Superior Pathophysiological Mimicry:** Scaffold-free 3D spheroids develop distinct phenotypic regions also found in vivo tumors: a proliferating outer layer, a quiescent middle region, and a hypoxic, sometimes necrotic, core [7]. This architecture leads to more accurate modelling of drug penetration, metabolic gradients, and cellular responses [7] [19]. For instance, cancer cells in 3D culture have demonstrated resistance to chemotherapeutic agents like paclitaxel, mirroring the chemoresistance observed in human tumors, whereas the same cells in 2D culture were susceptible [7].

- **Enhanced Predictive Capacity in Drug Screening:** The enhanced biological relevance of 3D models translates directly to more predictive drug screening data. Studies have shown that colon cancer HCT-116 cells in 3D culture are more resistant to anticancer drugs such as melphalan, fluorouracil, oxaliplatin, and irinotecan—a resistance profile also observed in vivo but not in 2D cultures [20]. This allows for better candidate selection earlier in the drug discovery pipeline, potentially saving significant time and resources [20] [21].

Table 1: Comparative Analysis of Preclinical Research Models

| Feature                            | 2D Cell Culture                                                              | Scaffold-Free 3D Models (e.g., Spheroids)                               | Animal Models                                         |
|------------------------------------|------------------------------------------------------------------------------|-------------------------------------------------------------------------|-------------------------------------------------------|
| Physiological Relevance            | Low; lacks tissue architecture and gradients [7]                             | High; recapitulates TME, gradients, and cell-cell interactions [7] [17] | High; full organismal context                         |
| Predictive Power for Drug Response | Variable; often poor predictor of clinical efficacy and resistance [18] [21] | High; better predicts drug resistance and efficacy [20] [17]            | Moderate; limited by species differences [20]         |
| Cost & Throughput                  | Low cost; high-throughput [20]                                               | Moderate cost; amenable to high-throughput screening [20] [17]          | High cost; low-throughput                             |
| Ethical Considerations             | Minimal ethical concerns                                                     | Aligns with 3Rs principles (Replacement) [6]                            | Significant ethical concerns and regulatory oversight |

Market Driver 2: Regulatory Pressure and the Shift from Animal Testing

A significant transformative force in the preclinical landscape is the increasing regulatory momentum to reduce and replace animal testing. This shift is embodied by the widespread adoption of the **3Rs principle** (Replacement, Reduction, and Refinement) and is now being codified into policy.

- **Regulatory Mandates:** Governing bodies are actively promoting non-animal methods. For example, in April 2025, the U.S. Food and Drug Administration (FDA) announced plans to phase out animal testing for monoclonal antibodies, explicitly promoting alternatives such as organoids, organs-on-chips, and AI models [6]. This regulatory pressure compels pharmaceutical and biotechnology companies to invest in and validate human-relevant models like scaffold-free 3D cultures to ensure future compliance and streamline their development timelines [6].
- **Strategic Advantage for Industry:** Beyond compliance, this shift offers a strategic advantage. Adopting human-based 3D models can improve drug safety assessment, reduce R&D costs associated with maintaining animal facilities, and accelerate development timelines by providing more human-predictive data earlier in the process [6] [21].

Application Notes & Protocols: Implementing Scaffold-Free 3D Models in Cancer Research


The following protocol provides a detailed methodology for generating a scaffold-free, multicomponent melanoma spheroid model, illustrating the practical application of this technology in a high-value research area.

Protocol: Generation of a Scaffold-Free, Multicomponent Melanoma Spheroid (MMS) Co-Culture Model

This protocol is adapted from recent research and is designed for the creation of a complex spheroid model incorporating melanoma cells and key stromal components of the tumor microenvironment (TME), suitable for drug efficacy and immune interaction studies [17].

**1. Primary Objective:** To establish a reproducible, scaffold-free 3D co-culture model of human melanoma that incorporates tumor cells, fibroblasts (from skin, lung, liver), endothelial cells, and immune cells to better mimic the in vivo TME for advanced drug testing.

**2. Experimental Workflow and Design:** The sequential co-culture process is outlined in the following workflow diagram.



### 3. Materials and Reagents:

#### • Cell Lines:

- SKmel147 (human metastatic melanoma cell line)
- NHDF (Normal Human Dermal Fibroblasts)
- MRC-5 (Human Fetal Lung Fibroblasts)
- LX-2 (Human Hepatic Stellate Cells)
- HMEC-1 (Human Microvascular Endothelial Cells-1)
- PBMCs (Peripheral Blood Mononuclear Cells) isolated from leukopaks [17].

- **Culture Media:** RPMI 1640 + GlutaMAX or DMEM + GlutaMAX, supplemented with 10% FBS and 1% Penicillin/Streptomycin. For HMEC-1 cells, use MCDB131 medium supplemented with hydrocortisone, L-glutamine, and EGF [17].

#### • Specialized Equipment:

- U-bottom ultra-low attachment (ULA) 96-well plates
- Centrifuge with plate rotors
- Live-cell imaging system or inverted microscope

### 4. Step-by-Step Procedure:

#### • Day 0: Seeding of Fibroblasts

- Trypsinize and harvest the fibroblast lines (NHDF, MRC-5, LX-2) individually.
- Combine the fibroblasts at desired ratios (e.g., equal numbers of each type) in a single cell suspension.
- Seed a total of **1,000 - 2,000 fibroblasts per well** in a 100 µL volume of complete media into the U-bottom ULA 96-well plate.
- Centrifuge the plate at **500 x g for 5 minutes** to pellet the cells at the bottom of the well.
- Incubate the plate for **24 hours** at 37°C, 5% CO<sub>2</sub> to allow for initial spheroid formation.

#### • Day 1: Introduction of Melanoma Cells

- Prepare a single-cell suspension of SKmel147 melanoma cells.
  - Gently add **500 - 1,000 melanoma cells** in a 50 µL volume of media on top of the pre-formed fibroblast spheroids.
  - Centrifuge the plate again at **300 x g for 3 minutes** to encourage contact.
  - Return the plate to the incubator.
- **Day 2: Introduction of Endothelial Cells**
    - Harvest HMEC-1 endothelial cells.
    - Gently add **500 - 800 endothelial cells** in a 50 µL volume of specific HMEC-1 medium to each well.
    - Centrifuge the plate at **200 x g for 3 minutes**.
    - Return the plate to the incubator. The multicomponent spheroid (MMS) is now considered assembled and should be allowed to mature for at least **24-48 hours** before functional assays.
  - **Day 5-7: Optional Introduction of Immune Cells**
    - Isolate PBMCs from human blood using a standard Ficoll density gradient centrifugation protocol.
    - Activate PBMCs if desired (e.g., with anti-human CD28 antibody at 5 µg/mL for 48 hours) [17].
    - Gently add **10,000 - 50,000 PBMCs** in a 50 µL volume to the mature MMS models.
    - Incubate for 24-72 hours to study immune cell infiltration and tumor-immune interactions.

5. Key QC Checkpoints and Troubleshooting:

- **Spheroid Formation:** After the first 24 hours, confirm under a microscope that a single, compact fibroblast spheroid has formed in the center of each well. Irregular shapes may indicate incorrect cell number or centrifugation force.
- **Co-culture Integrity:** After adding all cellular components, the spheroid should remain a single, cohesive structure without shedding a significant number of single cells.
- **Edge Effects:** Wells on the plate's perimeter can experience increased evaporation. Consider hydrating these wells with sterile PBS or excluding them from analysis.

The Scientist's Toolkit: Essential Reagents for Scaffold-Free 3D Culture

Table 2: Key Research Reagent Solutions for Scaffold-Free 3D Culture

| Reagent / Material                | Function & Application in Protocol                                                                                                              | Example from Protocol                                                                                      |
|-----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| Ultra-Low Attachment (ULA) Plates | Prevents cell adhesion to the plastic surface, forcing cells to self-assemble into spheroids. Crucial for initial spheroid formation. [20] [19] | U-bottom 96-well plates used for seeding fibroblasts and subsequent co-culture.                            |
| Specific Cell Culture Media       | Provides necessary nutrients and supplements tailored to the needs of different cell types in the co-culture.                                   | Use of MCDB131 medium with specific supplements for HMEC-1 endothelial cells.                              |
| Flow Cytometry Antibodies         | Enables immunophenotyping of different cell populations within the spheroid and analysis of immune cell infiltration.                           | Anti-human CD45, CD3, CD8, CD4 antibodies for characterizing PBMC populations. [17]                        |
| Viability/Cytotoxicity Assay Kits | Measures cell death and viability in response to drug treatments in a 3D format.                                                                | CellTiter-Glo 3D for viability, Propidium Iodide for dead cells, CellEvent Caspase-3/7 for apoptosis. [17] |
| Lentivirally Labeled Cell Lines   | Allows for real-time, non-invasive tracking of specific cell populations within the complex co-culture spheroid via fluorescence.               | Use of mCherry-labeled SKmel147 or GFP-labeled fibroblasts for live-cell imaging. [17]                     |

The adoption of scaffold-free 3D cell culture is no longer a niche pursuit but a strategic imperative in modern biomedical research. The convergence of **market demand for predictive models** and a **clear regulatory shift away from animal testing** creates a powerful, sustained driver for this technology. The provided application notes and detailed protocol for a complex melanoma spheroid model demonstrate that these systems are mature, reproducible, and ready for integration into the drug discovery workflow. By bridging the critical gap between simplistic 2D cultures and species-divergent animal models, scaffold-free 3D cultures offer a more physiologically relevant, human-based platform. This promises to enhance the predictive power of preclinical studies, improve drug candidate selection, and ultimately accelerate the development of safer and more effective therapeutics.

Scaffold-free 3D cell culture represents a paradigm shift in biomedical research, enabling scientists to grow cells in three dimensions without the use of artificial supporting matrices. This approach leverages cells' innate ability to self-assemble into complex, tissue-like structures, providing a more **physiologically relevant environment** than traditional 2D cultures or scaffold-based methods. The core constructs in this field—spheroids,

organoids, and cell sheets—each offer unique advantages for mimicking in vivo conditions, studying disease mechanisms, and screening therapeutic compounds. The global market for these technologies is experiencing rapid growth, projected to rise from USD 48.4 million in 2025 to USD 107 million by 2032, reflecting their increasing importance in drug discovery and regenerative medicine [3]. This article details the characteristics, formation protocols, and key applications of these three foundational constructs within the context of advanced scaffold-free research.

## Spheroids

### Characteristics and Applications

Spheroids are three-dimensional (3D) spherical aggregates of cells that form through the self-assembly of one or multiple cell types. They are widely used because they effectively mimic key aspects of the **tumor microenvironment** and microtissues. As spheroids grow, they develop metabolic gradients, containing proliferating cells on the outside, quiescent cells in the middle, and often a **necrotic core** due to oxygen and nutrient diffusion limitations, closely resembling the conditions found in microtumors [22]. This makes them particularly valuable in oncology research for drug penetration and efficacy studies. Furthermore, their application extends to stem cell research, where spheroid formation of mesenchymal stem cells (MSCs) has been shown to enhance their regenerative and anti-inflammatory effects [22]. Compared to other 3D models, spheroids offer advantages of lower cost, high reproducibility, and easier integration into high-throughput screening workflows [22].

Table 1: Key Characteristics and Applications of Spheroids

| Characteristic      | Description                                                             | Research Application                                                              |
|---------------------|-------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| 3D Structure        | Spherical cell aggregates that form through self-assembly.              | Provides a more physiologically relevant model than 2D cultures for drug testing. |
| Metabolic Gradients | Develops proliferating, quiescent, and necrotic zones based on size.    | Used to study drug penetration, efficacy, and tumor biology.                      |
| Tumor Mimicry       | Mimics the cellular heterogeneity and microenvironment of solid tumors. | Preclinical drug screening and validation; studying metastasis inhibition.        |
| Stem Cell Culture   | Enables cultivation of embryonic and mesenchymal stem cells.            | Exploration of regenerative medicine and cell-based therapies.                    |

### Protocol: Spheroid Formation via Aqueous Two-Phase System (ATPS)

This protocol describes a method for generating spheroids using a density-adjusted polyethylene glycol (PEG) and dextran (DEX) aqueous two-phase system (ATPS). This technique simplifies spheroid manipulation by allowing easy transfer and adhesion through medium dilution [23].

#### Key Research Reagent Solutions:

- Polyethylene Glycol (PEG) Solution:** Forms the PEG-rich phase of the ATPS; creates a biochemically distinct environment that confines cells.
- Dextran (DEX) Solution:** Forms the cell-compatible DEX-rich phase where cells are initially suspended.
- Density Adjustment Media:** Culture media used to adjust the density of the DEX-rich phase to be higher than that of the cells, enabling cell flotation and aggregation.
- Fluorescence Stains (e.g., CMFDA):** Used for labeling and visualizing live cells within the spheroid structure.

#### Methodology:

- ATPS Preparation:** Prepare a PEG/DEX ATPS (e.g., a 5/9 wt% PEG/wt% DEX mixture confirmed to form two phases). Separate and clean the top (PEG-rich) and bottom (DEX-rich) phases via centrifugation [23].
- Cell Suspension:** Harvest and resuspend the target cells (e.g., NIH-3T3, MCF-7) in the purified DEX-rich phase.
- Patterning:** In a 96-well plate, create a "DEX-in-PEG" pattern by carefully pipetting a drop of the cell-laden DEX-rich phase into a reservoir of the PEG-rich phase. A successfully formed pattern will show a clear, stable boundary between the two immiscible phases [23].
- Spheroid Formation:** Incubate the plate. Due to density differences, cells within the DEX drop will float upwards and gather at the apex of the meniscus at the phase interface within approximately 4 hours. Over 24-48 hours, these gathered cells will self-assemble into a tight spheroid [23].
- Spheroid Harvesting (Option 1 - Transfer):** Carefully transfer the formed spheroid to a standard culture dish for further culture or analysis using a pipette. The spheroid integrity is maintained during transfer [23].
- Spheroid Harvesting (Option 2 - In-Situ Adhesion):** Add a few drops of fresh, PEG/DEX-free culture medium to the well. This dilutes the phases, reducing their density and causing the spheroid to settle and attach to the bottom of the well, facilitating adhesion studies without manual transfer [23].




Diagram 1: Spheroid formation workflow via ATPS.

## Organoids

### Characteristics and Applications

Organoids are complex, miniaturized, and simplified versions of organs produced in vitro that mimic the **key functional, structural, and biological complexity** of their in vivo counterparts [24]. They are defined by three key properties: (1) the presence of **multiple organ-specific cell types**; (2) the capability to recapitulate some specific functions of the organ (e.g., neural activity, endocrine secretion); and (3) spatial organization of cells that resembles the in vivo organ [24]. Derived from pluripotent stem cells (PSCs) or adult stem cells (ASCs), organoids self-organize through cell sorting and spatially restricted lineage commitment. The organoid field is poised for significant expansion, with the market expected to reach \$15.01 billion by 2031 [25]. Organoids are revolutionizing disease modeling, personalized medicine, and drug development by providing human-relevant models that can incorporate patient-specific genetic backgrounds, thereby improving the predictive power of preclinical studies [25] [24].

Table 2: Key Characteristics and Applications of Organoids

| Characteristic             | Description                                                                            | Research Application                                                       |
|----------------------------|----------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
| <b>Self-Organization</b>   | Stem cells differentiate and organize into 3D structures mimicking organ architecture. | Studying human development and organogenesis.                              |
| <b>Cellular Complexity</b> | Contains multiple, organ-specific cell types found in the original tissue.             | Modeling complex human diseases with high physiological relevance.         |
| <b>Functional Capacity</b> | Recapitulates some organ-specific functions (e.g., filtration, secretion).             | Drug toxicity testing, metabolic studies, and infectious disease research. |
| <b>Patient-Specificity</b> | Can be generated from patient-derived induced pluripotent stem cells (iPSCs).          | Personalized drug screening and development of individualized therapies.   |



**Protocol: Cerebral Organoid Generation from Pluripotent Stem Cells**

This protocol outlines the foundational steps for generating cerebral organoids from human pluripotent stem cells (PSCs), a process that models early brain development [24].

**Key Research Reagent Solutions:**

- **Extracellular Matrix (ECM) Hydrogel:** A commercially available basement membrane extract (e.g., Matrigel or Cultrex BME), rich in laminin and other ECM proteins, essential for providing a 3D environment that supports morphogenesis.
- **Pluripotent Stem Cell (PSC) Medium:** A specialized medium designed to maintain the pluripotency of the starting cell population.
- **Neural Induction Medium:** A medium containing a defined cocktail of growth factors and small molecules (e.g., TGF- $\beta$  inhibitors, BMP inhibitors) that patterns the embryoid bodies toward a neural ectoderm fate.
- **Rotational Bioreactor:** A device that provides constant agitation, improving nutrient and oxygen exchange to support the growth of larger, more complex organoids over several months.

**Methodology:**

- **3D Embryoid Body (EB) Formation:** Harvest human PSCs and seed them into a low-attachment 96-well plate with rounded bottoms to allow aggregation and formation of EBs in PSC medium [24].
- **Neural Induction:** Transfer the formed EBs to a neural induction medium. This medium contains specific patterning factors (e.g., SMAD inhibitors) that guide the cells toward a neural lineage [24].
- **EMB Embedding:** After several days of neural induction, embed each EB into a droplet of ECM hydrogel. This matrix provides a scaffold that supports the extensive expansion and complex morphological changes required for brain development [24].
- **Organoid Maturation:** Transfer the embedded organoids to a rotational bioreactor containing differentiation medium. The constant rotation enhances nutrient/waste exchange, allowing the organoids to grow and self-organize for extended periods (months). During this time, they develop distinct brain region identities and layered structures reminiscent of the cerebral cortex [24].




Diagram 2: Cerebral organoid generation from PSCs.

**Cell Sheets**

**Characteristics and Applications**

Cell sheet technology is a scaffold-free approach that involves cultivating cells until they form a contiguous, adherent layer, which is then harvested along with its intact, self-produced **extracellular matrix (ECM)** and cell-cell junctions [26]. This method preserves vital surface proteins and cell-to-ECM connections that are typically destroyed by enzymatic digestion like trypsinization. The resulting sheet is a coherent tissue-like construct that can be directly transplanted or layered to create more complex structures. A significant advancement in this field is the move towards **serum-free**

**medium (SFM)** conditions, which eliminate concerns related to immunogenicity, pathogen contamination, and batch-to-batch variability associated with fetal bovine serum (FBS) [27]. Cell sheets have shown great promise in constructing tissue-engineered vascular grafts (TEVGs) and for applications in regenerative medicine, such as treating corneal epithelial defects and periodontitis, as evidenced by clinical trials listed in the search results [6] [27].

Table 3: Key Characteristics and Applications of Cell Sheets

| Characteristic      | Description                                                                 | Research Application                                                  |
|---------------------|-----------------------------------------------------------------------------|-----------------------------------------------------------------------|
| Intact ECM          | Harvested with its native extracellular matrix, preserving biological cues. | Provides a natural scaffold for regenerative medicine; used in TEVGs. |
| Cell-Cell Junctions | Critical adhesion proteins and gap junctions remain undamaged.              | Ensures functional integrity of the transplanted tissue.              |
| Scaffold-Free       | No need for artificial biomaterials, reducing biocompatibility concerns.    | Simplifies tissue engineering and improves clinical translation.      |
| Layering Capability | Multiple sheets can be stacked to create thicker, more complex tissues.     | Engineering of stratified tissues like myocardium or skin.            |

Protocol: Ascorbic Acid-Induced Cell Sheet Formation

This protocol describes a practical method for generating cell sheets using L-ascorbic acid (L-AA) to stimulate ECM production, specifically for human dermal fibroblasts (HDFs) and HaCaT keratinocytes, based on recent comparative analysis [26].

Key Research Reagent Solutions:

- **L-Ascorbic Acid (L-AA) Stock Solution:** A freshly prepared solution in PBS, which stimulates collagen synthesis and ECM production by cells, critical for forming a cohesive sheet.
- **Serum-Free Medium (SFM):** A defined culture medium that promotes a more controllable cellular phenotype and enhances ECM deposition, as demonstrated in VSMC studies, while avoiding FBS-related issues [27].
- **Crystal Violet Stain:** A solution used to stain fixed cells, allowing for clear visualization of cell morphology and the integrity of the sheet structure.
- **MTT Assay Kit:** A colorimetric assay for measuring cell metabolic activity and viability during the sheet formation process.

Methodology:

- **Cell Seeding:** Seed HDF or HaCaT cells at a high density (e.g., 50,000 or 100,000 cells cm<sup>-2</sup>) into standard multi-well culture plates [26].
- **L-AA Application:** Twenty-four hours after seeding, add culture medium supplemented with a specific concentration of L-AA. For HDFs, 50 µg mL<sup>-1</sup> has been shown to be optimal, while HaCaT keratinocytes may not form cohesive sheets under these conditions and may require co-culture [26].
- **Culture and Feeding:** Culture the cells for 7-14 days, replacing the medium with freshly prepared L-AA-supplemented medium every 48 hours to ensure consistent stimulation and minimize L-AA oxidation [26].
- **Harvesting:** Once a cohesive sheet is formed (visually confirmed and mechanically stable), gently wash the sheet with PBS and mechanically detach it from the plate using a sterile instrument or pipette, avoiding enzymatic digestion. The harvested sheet can be manipulated as an intact construct [26].




Diagram 3: Cell sheet formation induced by ascorbic acid.

From Theory to Bench: Methodologies and Translational Applications in Biomedicine

Scaffold-free 3D cell culture techniques represent a pivotal advancement in biomedical research, enabling the generation of three-dimensional cellular structures that more accurately mimic the *in vivo* microenvironment compared to traditional two-dimensional (2D) monolayers [28]. These methods facilitate the self-assembly of cells into tissue-like aggregates known as **spheroids** through natural cell-cell and cell-extracellular matrix (ECM) interactions, without relying on artificial scaffold materials [29] [30]. The core principle involves creating conditions that promote cell aggregation while minimizing unwanted adhesion to synthetic surfaces, thereby recapitulating the intimate direct cell-cell adhesion architecture found in normal tissues [31]. The growing adoption of these techniques is driven by their ability to generate physiologically relevant models for drug discovery, cancer research, toxicology testing, and regenerative medicine, ultimately helping to bridge the gap between conventional *in vitro* models and *in vivo* responses [32].

Comparative Analysis of Core Techniques

The three primary scaffold-free methods—hanging drop, low-adhesion plates, and agitation-based approaches—each employ distinct mechanisms to induce spheroid formation. The hanging drop technique utilizes gravity to concentrate cells at the liquid-air interface of inverted droplets [33]. Low-adhesion plates feature specialized polymer coatings that prevent cell attachment, forcing cells to aggregate in a suspended state [32]. Agitation-based methods use continuous movement in bioreactors to maintain cells in suspension, preventing adhesion and promoting aggregation through constant mixing [28] [30]. Understanding the relative advantages and limitations of each method is crucial for selecting the appropriate technique for specific research applications.

Table 1: Comparative Analysis of Scaffold-Free 3D Cell Culture Techniques

| Parameter                       | Hanging Drop Method                                                 | Low-Adhesion Plates                                              | Agitation-Based Methods                                         |
|---------------------------------|---------------------------------------------------------------------|------------------------------------------------------------------|-----------------------------------------------------------------|
| Principle of Spheroid Formation | Gravity-enforced self-assembly at the liquid-air interface [33]     | Forced floating on ultra-low attachment (ULA) surfaces [29] [32] | Continuous stirring preventing adhesion to container walls [30] |
| Spheroid Uniformity             | High uniformity and controlled size [34] [32]                       | Variable size and shape; lower uniformity [29] [32]              | Broad range of non-uniform spheroids [28] [30]                  |
| Throughput Capacity             | Suitable for high-throughput screening with specialized arrays [33] | High-throughput capable with standard plate formats [29]         | Lower throughput; limited by bioreactor capacity [28]           |
| Ease of Use & Handling          | Medium complexity; difficult medium exchange [32]                   | Simple protocol; easy handling and maintenance [29]              | Simple setup but requires specialized equipment [28]            |

| Parameter           | Hanging Drop Method                                                           | Low-Adhesion Plates                                                          | Agitation-Based Methods                                              |
|---------------------|-------------------------------------------------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|
| Culture Duration    | Short-term culture (typically a few days) [32]                                | Suitable for long-term culture [32]                                          | Suitable for long-term culture [28]                                  |
| Cost Considerations | Low cost for basic setup [32]                                                 | Higher cost for specialized plates [32]                                      | High initial investment for bioreactors [28]                         |
| Key Advantages      | Controlled spheroid size via cell density [8]; Excellent for co-cultures [31] | Simple protocol; automation compatible; suitable for various cell types [29] | Prevents hypoxia in core; suitable for large spheroid formation [28] |
| Major Limitations   | Difficult medium exchange; small culture volume [32]                          | Lack of uniformity between spheroids [29]                                    | Non-uniform spheroid size; requires specialized equipment [30]       |

Table 2: Technical Specifications and Application Scope

| Characteristic                       | Hanging Drop Method                                              | Low-Adhesion Plates                                             | Agitation-Based Methods                            |
|--------------------------------------|------------------------------------------------------------------|-----------------------------------------------------------------|----------------------------------------------------|
| Typical Drop/Well Volume             | 10-50 µL (recommended: 10-20 µL) [32]                            | 100-400 µL (depending on plate format) [32]                     | Varies with bioreactor size (mL to L scale) [28]   |
| Spheroid Size Control Mechanism      | Cell density in suspension [8] [32]                              | Initial seeding density [29]                                    | Agitation speed and seeding density [28]           |
| Suitability for Co-culture           | Excellent [31] [32]                                              | Good [29]                                                       | Moderate [28]                                      |
| Compatibility with Downstream Assays | Medium (requires spheroid retrieval) [33]                        | High (easy spheroid access) [29]                                | Low to medium (harvesting required) [28]           |
| Optimal Application Context          | Drug screening, developmental biology, cancer research [31] [33] | High-throughput toxicity screening, long-term studies [29] [32] | Large spheroid production, tissue engineering [28] |




Diagram 1: Workflow for scaffold-free 3D cell culture methods (Max Width: 760px)

## Detailed Experimental Protocols

### Hanging Drop Method Protocol

The hanging drop technique is a well-established scaffold-free approach that generates highly uniform spheroids through gravity-mediated cell aggregation [31] [33].

#### Materials Required:

- Cell line of interest (e.g., cancer cells, stem cells)
- Complete cell culture medium
- Sterile pipettes and tips
- Standard cell culture plates (e.g., 96-well format)
- Humidified incubator (37°C, 5% CO<sub>2</sub>)

#### Step-by-Step Procedure:

- **Cell Suspension Preparation:** Harvest and count cells using standard techniques. Prepare a cell suspension at a concentration of  $1.0\text{--}2.0 \times 10^5$  cells/mL in complete culture medium. Optimal density depends on cell type and desired spheroid size [34] [32].
- **Drop Formation:** Invert the culture plate lid. Pipette 10-20 µL droplets of cell suspension onto the inner surface of the inverted lid, spacing them appropriately to prevent coalescence [32].
- **Plate Assembly:** Carefully place the bottom part of the culture plate over the inverted lid, creating a hanging drop configuration. The bottom plate serves as a humidity chamber to prevent evaporation [33].
- **Incubation:** Transfer the assembled platform to a humidified incubator (37°C, 5% CO<sub>2</sub>) for 24-72 hours. Spheroid formation typically begins within 24 hours, with mature spheroids forming by 72 hours [31].
- **Spheroid Harvesting:** To retrieve spheroids, carefully pipette 50-100 µL of medium into each drop to dilute the suspension. Collect the spheroids using a wide-bore pipette tip to prevent structural damage [33].
- **Quality Assessment:** Examine spheroid morphology and uniformity under a light microscope. Spheroids should appear spherical with smooth, well-defined borders.

#### Technical Notes:

- For high-throughput applications, specialized hanging drop array plates are commercially available [33].
- Spheroid size can be precisely controlled by adjusting initial cell density in the suspension [32].
- Medium exchange is challenging; for long-term cultures, consider transferring spheroids to alternative platforms after initial formation.

### Low-Adhesion Plate Method Protocol

The low-adhesion plate method, also known as the forced floating technique, utilizes specialized surfaces to prevent cell attachment and promote spheroid formation through self-aggregation [29] [32].

#### Materials Required:

- Cell line of interest
- Complete cell culture medium
- Ultra-low attachment (ULA) plates (e.g., Corning Costar Spheroid plates)
- Centrifuge with plate adapters
- Humidified incubator (37°C, 5% CO<sub>2</sub>)

#### Step-by-Step Procedure:

- **Cell Suspension Preparation:** Harvest and count cells using standard techniques. Prepare a cell suspension at an appropriate density (typically  $1.0\text{--}5.0 \times 10^4$  cells/mL, depending on desired spheroid size) [29].
- **Plate Seeding:** Dispense 100-200 µL of cell suspension into each well of the ULA plate. For 96-well formats, 100 µL per well is standard [32].
- **Centrifugation:** Centrifuge the plate at  $100\text{--}500 \times g$  for 3-5 minutes to gently pellet cells at the bottom of wells, promoting initial cell-cell contact [30].
- **Incubation:** Transfer the plate to a humidified incubator (37°C, 5% CO<sub>2</sub>) for 24-72 hours. Avoid disturbing the plate during the initial 24 hours to allow for stable spheroid formation.
- **Medium Exchange:** For long-term cultures ( $\geq 7$  days), carefully replace 50-70% of the medium every 2-3 days using a multichannel pipette, taking care not to aspirate the formed spheroids.
- **Monitoring and Analysis:** Monitor spheroid formation daily using an inverted microscope. Spheroids are typically ready for experimentation within 3-5 days.

Technical Notes:

- ULA plates are coated with a hydrophilic polymer that minimizes protein adsorption and prevents cell attachment [29] [32].
- This method is particularly suitable for high-throughput screening applications due to compatibility with automated liquid handling systems [29].
- Spheroid size uniformity can be improved by using plates with non-adhesive, round-bottom wells that guide symmetrical aggregation.

Agitation-Based Method Protocol

Agitation-based techniques use dynamic culture conditions in rotating bioreactors to maintain cells in suspension, promoting aggregation through continuous motion [28] [30].

Materials Required:

- Cell line of interest
- Complete cell culture medium
- Rotating wall vessel (RWV) bioreactor or spinner flask
- Orbital shaker platform (for some systems)
- Humidified incubator (37°C, 5% CO2)

Step-by-Step Procedure:

- **Cell Suspension Preparation:** Harvest and count cells. Prepare a cell suspension at a density of  $2.0\text{-}10.0 \times 10^5$  cells/mL in complete culture medium, depending on cell type and target spheroid size [28].
- **Bioreactor Loading:** Aseptically transfer the cell suspension to the bioreactor vessel, filling approximately 50-75% of the total capacity to allow proper gas exchange.
- **System Setup:** Place the bioreactor in the incubator and initiate rotation. For spinner flasks, set the agitation speed to 50-100 rpm. For RWV systems, follow manufacturer's specifications for optimal rotation speed [28] [30].
- **Culture Maintenance:** Culture cells for 5-14 days, with longer durations typically producing larger, more mature spheroids. Monitor pH and medium color daily.
- **Medium Exchange:** Every 2-3 days, allow spheroids to settle briefly, remove 50-70% of spent medium, and replace with fresh pre-warmed medium.
- **Spheroid Harvesting:** Transfer the culture suspension to a conical tube and allow spheroids to settle by gravity or brief centrifugation at  $50 \times g$  for 2 minutes.

Technical Notes:

- The continuous mixing in agitation systems helps maintain nutrient and oxygen distribution, potentially reducing necrotic core formation in larger spheroids [28].
- This method is less suitable for high-throughput applications but excellent for generating large quantities of spheroids for tissue engineering [30].
- Agitation speed optimization is critical—too low allows settling and adhesion, while too high generates excessive shear stress that can disrupt spheroid formation.

The Scientist's Toolkit: Essential Research Reagents and Materials

Successful implementation of scaffold-free 3D cell culture requires specific materials and reagents designed to support spheroid formation and maintenance while preventing unwanted cell adhesion.

Table 3: Essential Research Reagents and Materials for Scaffold-Free 3D Cell Culture

| Item Category               | Specific Examples                           | Function & Application Notes                                                                                                                            |
|-----------------------------|---------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| Specialized Culture Vessels | Ultra-low attachment (ULA) plates [29] [32] | Polymer-coated surfaces minimize protein adsorption and prevent cell attachment, forcing cell aggregation.                                              |
|                             | Hanging drop array plates [33]              | Specialized plates with predefined well structures for standardized hanging drop formation.                                                             |
|                             | Rotating wall vessel (RWV) bioreactors [28] | Provide dynamic culture conditions with low shear stress for large-scale spheroid production.                                                           |
| Cell Culture Media          | Standard culture media                      | Must be supplemented appropriately for specific cell types; hanging drop methods may require slightly higher viscosity to maintain drop integrity [34]. |

| Item Category              | Specific Examples                | Function & Application Notes                                                                                   |
|----------------------------|----------------------------------|----------------------------------------------------------------------------------------------------------------|
|                            | Serum-free defined media         | Preferred for consistency in spheroid formation, particularly in drug screening applications [32].             |
| Cell Dissociation Reagents | Trypsin-EDTA solutions           | For cell harvesting prior to spheroid formation; neutralization with serum-containing medium is critical [32]. |
|                            | Enzyme-free dissociation buffers | Gentler alternative that preserves cell surface receptors important for cell-cell adhesion [29].               |
| Quality Assessment Tools   | Inverted microscopes             | Essential for daily monitoring of spheroid formation, morphology, and integrity [32].                          |
|                            | Wide-bore pipette tips           | Prevent mechanical damage to spheroids during transfer and harvesting [33].                                    |
|                            | Viability staining kits          | Assess spheroid health and identify necrotic cores in larger structures [32].                                  |




Diagram 2: Signaling and interaction networks in 3D spheroids (Max Width: 760px)

Troubleshooting and Optimization Guide

Even with standardized protocols, researchers may encounter challenges in achieving optimal spheroid formation. This section addresses common issues and provides evidence-based solutions.

Table 4: Troubleshooting Guide for Scaffold-Free 3D Cell Culture

| Problem                       | Potential Causes                                                                                    | Recommended Solutions                                                                                                                                 |
|-------------------------------|-----------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| Poor Spheroid Formation       | Insufficient cell number<br>Low cell viability<br>Inappropriate culture conditions                  | Optimize seeding density based on cell type [32]<br>Check viability before culture (>90% recommended)<br>Verify temperature, CO2, and humidity levels |
| Irregular Spheroid Size/Shape | Uneven cell distribution<br>Inconsistent droplet volumes (hanging drop)<br>Variable agitation speed | Ensure homogeneous cell suspension before seeding [29]<br>Use calibrated pipettes and practice consistent technique<br>Optimize and                   |



| Problem                             | Potential Causes                                                                            | Recommended Solutions                                                                                                                                                             |
|-------------------------------------|---------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                     | (bioreactors)                                                                               | maintain constant agitation parameters [28]                                                                                                                                       |
| Excessive Cell Death in Core        | Spheroids too largeInsufficient nutrient penetrationLimited oxygen diffusion                | Reduce spheroid size by lowering seeding density [29]Consider perfusion systems for large spheroids [29]Use agitation methods to improve nutrient exchange [28]                   |
| Spheroid Disintegration             | Over-handling during medium changesEnzymatic activity degrading ECMMechanical stress        | Use gentle pipetting techniques with wide-bore tips [33]Add matrix-stabilizing compounds if compatible with scaffold-free approachMinimize unnecessary disturbance during culture |
| Low Reproducibility Between Batches | Variable cell passage numbersInconsistent medium compositionTechnician-dependent variations | Use cells within consistent passage range [32]Prepare single large batches of mediumStandardize protocols and provide training                                                    |

Scaffold-free 3D cell culture methods represent a significant advancement in biomedical research, providing more physiologically relevant models that bridge the gap between traditional 2D cultures and *in vivo* systems. The hanging drop, low-adhesion plate, and agitation-based techniques each offer distinct advantages suited to different research applications, from high-throughput drug screening to tissue engineering. As the field continues to evolve, ongoing technological innovations in automation, monitoring, and standardization are poised to enhance the reproducibility and accessibility of these powerful tools. The growing emphasis on reducing animal testing through the 3Rs principle (Replacement, Reduction, and Refinement) further underscores the importance of developing robust, predictive *in vitro* models like scaffold-free 3D cultures [32] [6]. By selecting the appropriate method based on specific research requirements and carefully implementing the detailed protocols provided, researchers can leverage these techniques to generate valuable insights into cellular behavior, disease mechanisms, and therapeutic interventions.

Scaffold-free 3D cell culture represents a paradigm shift in tissue engineering, regenerative medicine, and drug discovery. Unlike traditional scaffold-based approaches that rely on exogenous biomaterials to support three-dimensional growth, scaffold-free methods harness the innate ability of cells to self-assemble, migrate, and secrete their own extracellular matrix (ECM) to form complex, physiologically relevant tissue structures [10]. This approach capitalizes on cellular efficiency and sophistication that remains unparalleled by human-made devices, ultimately producing tissue analogs with superior biocompatibility and reduced risk of foreign body response [10]. Two particularly promising technologies within this domain are magnetic levitation and thermo-responsive cell sheet engineering, which enable researchers to create sophisticated tissue-like surrogates without the complications associated with biodegradable scaffolds.

The global market for scaffold-free 3D cell culture is experiencing rapid growth, projected to reach **USD 1.85 billion by 2035** with a compound annual growth rate (CAGR) of **14.8%** during the forecast period, demonstrating increasing adoption and investment in these technologies [6]. This expansion is driven by rising demand for physiologically relevant models in drug discovery, increasing regulatory pressure to reduce animal testing, and growing applications in personalized medicine and regenerative therapies [6] [8].

Thermo-Responsive Cell Sheet Engineering

Thermo-responsive cell sheet engineering utilizes intelligent surfaces grafted with temperature-responsive polymers, most commonly poly(N-isopropylacrylamide) (PIPAAm), to enable the non-invasive harvest of intact cell sheets without enzymatic digestion [10] [35]. At temperatures above 32°C (the lower critical solution temperature, LCST), the PIPAAm-grafted surface is hydrophobic, allowing cells to adhere, spread, and proliferate to confluence. When temperature is reduced below 32°C, the surface becomes hydrophilic through hydration of the polymer chains, prompting spontaneous detachment of an intact, contiguous cell sheet with preserved cell-cell junctions, endogenous ECM, and functional membrane proteins [35].

This technology overcomes critical limitations of traditional cell harvest using proteolytic enzymes like trypsin, which damage cell surface proteins, ECM, and cell-cell connections, thereby impairing cell function and tissue integration post-transplantation [35] [36]. The recovered cell sheets can be directly transplanted to host tissues or assembled into more complex three-dimensional structures through layering techniques [35].

Fabrication of Temperature-Responsive Surfaces

Several methods have been developed for grafting PIPAAm onto culture surfaces:

- **Electron Beam (EB) Irradiation:** The original method for covalently grafting PIPAAm onto commercially available tissue culture polystyrene, now commercialized as Nunc Dish with UpCell Surface from Thermo Fisher Scientific [35]. A PIPAAm layer thickness of 15-20 nm is critical for optimal cell adhesion and detachment [35].
- **Plasma Irradiation:** An alternative grafting method performed in a low vacuum with vaporized IPAAm monomer, which shows less dependency on polymer thickness for cell adhesion/deadhesion control compared to EB irradiation [35].
- **UV Irradiation:** Utilizes photoinitiators or photocrosslinkable PIPAAm derivatives to create patterned grafted surfaces [35].
- **"Grafting-from" Polymerization:** Includes atom transfer radical polymerization (ATRP) and reversible addition-fragmentation chain transfer (RAFT) polymerization, which enable precise control over polymer brush density and chain length [35].

- **Triblock Copolymer Coating:** As an alternative to PIPAAm, PCL-PEG-PCL (PCEC) triblock copolymer has demonstrated thermoresponsive properties suitable for cell sheet engineering, offering advantages including FDA-approved components, biocompatibility, and biodegradability [36].

Magnetic Levitation 3D Cell Culture

Magnetic levitation employs biocompatible magnetic nanoparticles to render cells magnetic, allowing them to be manipulated by external magnetic fields to form 3D structures [37] [38]. This technology typically utilizes one of two approaches:

- **Positive Magnetophoresis:** Cells are labeled with magnetic nanoparticles (e.g., magnetite cationic liposomes) and levitated by a magnetic field to concentrate them at the air-liquid interface where they aggregate into 3D structures [38].
- **Negative Magnetophoresis:** Cells are levitated in a paramagnetic medium without magnetic labeling, preserving their natural state and minimizing potential toxicity [39].

The magnetic levitation method (MLM) requires approximately **45 minutes of working time over 2 days** to create 3D cultures that can be maintained long-term (>7 days) [38]. The resulting structures are dense, synthesize their own ECM, and can be analyzed using standard techniques including immunohistochemistry, western blotting, and other biochemical assays [38].

Recent advancements have scaled this technology from single Petri dishes to 1536-well plates, enabling high-throughput screening applications that align with FDA-endorsed New Approach Methodologies (NAMs) as alternatives to animal testing [37].

Quantitative Data Comparison

Table 1: Comparative Analysis of Scaffold-Free 3D Cell Culture Technologies

| Parameter            | Thermo-Responsive Cell Sheets                                                        | Magnetic Levitation                                                          |
|----------------------|--------------------------------------------------------------------------------------|------------------------------------------------------------------------------|
| Technical Principle  | Temperature-mediated hydrophobicity/hydrophilicity shift of polymer-grafted surfaces | Magnetic force manipulation of labeled cells or cells in paramagnetic medium |
| Key Materials        | PIPAAm, PCL-PEG-PCL copolymers                                                       | Magnetic nanoparticles, paramagnetic media (e.g., gadolinium)                |
| Cell Harvest Method  | Temperature reduction (<32°C)                                                        | Magnetic field application                                                   |
| Harvest Time         | Minutes to hours                                                                     | Approximately 24 hours for structure formation                               |
| Structural Output    | 2D sheets (40-80 µm thick) that can be layered into 3D constructs                    | 3D spheroids and organoids (millimeter-sized)                                |
| ECM Preservation     | Excellent - preserves endogenous ECM and cell junctions                              | Good - promotes de novo ECM synthesis                                        |
| Throughput Potential | Moderate (improved with automation)                                                  | High (scalable to 1536-well plates)                                          |
| Clinical Translation | Multiple clinical trials and commercial products                                     | Primarily research and drug screening applications                           |
| Key Advantages       | Preserved cell-cell junctions and ECM; transplantable without sutures                | Rapid 3D structure formation; controllable cell composition and density      |

Table 2: Global Market Outlook for Scaffold-Free 3D Cell Culture (2025-2035) [6].[9].[3]

| Market Segment                             | 2025 Market Size (USD)        | Projected 2035 Market Size (USD) | CAGR           |
|--------------------------------------------|-------------------------------|----------------------------------|----------------|
| Total Scaffold-Free 3D Cell Culture Market | 534.7 million - 9.44 billion* | 1.85 billion - 19.83 billion*    | 13.17% - 14.8% |
| By Type (Spheroids Segment)                | 35.8% market share            | Leading segment                  | -              |
| By Application (Drug Discovery Segment)    | Significant share             | Dominant segment                 | -              |
| By End User (Pharma/Biotech Segment)       | Considerable share            | Expanding segment                | -              |

Note: Variation in reported values reflects different market research methodologies and scope definitions.

Application Notes & Experimental Protocols

## Protocol 1: Cell Sheet Engineering Using Thermo-Responsive Surfaces

### Materials and Reagents

- Thermo-responsive culture surfaces (e.g., UpCell dishes, or laboratory-fabricated PIPAAm-grafted surfaces)
- Appropriate cell culture medium
- Supplemental factors (e.g., vitamin C [50 µg/ml], sodium selenite [0.1 µM], or Trolox) to enhance sheet quality [36]
- Phosphate buffered saline (PBS)
- Standard cell culture equipment

### Cell Seeding and Culture

- Seed cells onto thermo-responsive surfaces at a density of **~104,000 cells/cm<sup>2</sup>** to achieve confluent growth [10].
- Culture cells at 37°C in a humidified incubator with 5% CO<sub>2</sub> for several days until confluence is reached, with medium changes as appropriate for the cell type.
- For enhanced sheet quality, consider supplementing medium with antioxidants: sodium selenite (0.1 µM) has demonstrated superior results compared to vitamin C alone in promoting stemness-related gene expression (Sox2, Oct-4, Nanog) and reducing senescence in rBMSC sheets [36].

### Cell Sheet Harvest

- Reduce the culture temperature to below the LCST (typically 20-25°C) for 30-60 minutes [35].
- Observe cell sheet detachment under a microscope. The sheet will detach spontaneously from the hydrated surface, beginning at the edges and progressing inward.
- Gently transfer the intact cell sheet using a pipette or spatula to the desired target (e.g., transplantation site, new culture vessel for layering, or analysis platform).

### Layering for 3D Constructs

- Harvest the first cell sheet as described above.
- Carefully transfer the sheet onto a new cell sheet still attached to a thermo-responsive surface at 37°C.
- Allow 1-2 hours for adhesion between sheets.
- Repeat the process to build multilayered constructs.
- Culture the layered construct to promote integration, potentially using perfusion bioreactors to enhance nutrient transport for thicker tissues [10].

## Protocol 2: 3D Culture via Magnetic Levitation

### Materials and Reagents

- Magnetic nanoparticles (e.g., NanoShuttle for positive magnetophoresis) or paramagnetic medium (e.g., gadolinium solution for negative magnetophoresis)
- Ring magnet setup (for manual manipulation) or specialized magnetic levitation plates
- Appropriate cell culture medium
- Standard cell culture equipment

### Magnetic Labeling (Positive Magnetophoresis)

- Incubate cells with magnetic nanoparticle assembly overnight according to manufacturer specifications to render them magnetic [38].
- Remove unbound nanoparticles through washing steps.


### 3D Structure Formation

- Resuspend magnetically labeled cells in culture medium, or suspend unlabeled cells in paramagnetic medium [39].
- Place the cell suspension in a culture vessel positioned above a magnetic drive (ring magnet or multi-well magnetic plate).
- The magnetic field will levitate and concentrate cells at the air-liquid interface within **15-60 minutes** [38].
- Incubate the levitated cells at 37°C for **~24 hours** to allow aggregation and initial ECM formation into stable 3D structures [38].

### Long-Term Culture and Analysis

- After initial structure formation, the magnetic field can be maintained or removed, depending on the application.
- Culture can be continued for extended periods (>7 days) with regular medium changes.

- Resulting 3D structures can be analyzed using standard techniques: immunohistochemistry, western blotting, biochemical assays, and live-cell imaging [38].



**Figure 1:** Workflow comparison of thermo-responsive cell sheet engineering and magnetic levitation for scaffold-free 3D culture.

The Scientist's Toolkit: Essential Research Reagent Solutions

Table 3: Key Reagents and Materials for Scaffold-Free 3D Cell Culture

| Reagent/Material        | Function/Purpose                                              | Examples/Specifications                                                                                  |
|-------------------------|---------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| PIPAAm-Grafted Surfaces | Temperature-responsive substrate for cell adhesion/detachment | Commercial (UpCell dishes) or lab-synthesized; 15-20 nm polymer thickness optimal [35]                   |
| PCL-PEG-PCL Copolymer   | Alternative thermosensitive substrate                         | Biocompatible, biodegradable triblock copolymer; sol-gel transition tunable by PEG molecular weight [36] |
| Magnetic Nanoparticles  | Cell labeling for magnetic manipulation                       | Magnetite cationic liposomes; biocompatible; enable positive magnetophoresis [38]                        |
| Paramagnetic Media      | Medium for label-free magnetic levitation                     | Gadolinium-based solutions; enables negative magnetophoresis without cellular labeling [39]              |
| Antioxidant Supplements | Enhance cell sheet quality and reduce senescence              | Sodium selenite (0.1 μM), Vitamin C (50 μg/mL), Trolox; improve stemness gene expression [36]            |

| Reagent/Material        | Function/Purpose                        | Examples/Specifications                                                                            |
|-------------------------|-----------------------------------------|----------------------------------------------------------------------------------------------------|
| Specialized Microplates | High-throughput 3D culture applications | Ultra-low attachment (ULA) plates, round-bottom plates, magnetic levitation-compatible plates [37] |

**Figure 2:** Molecular mechanism of cell sheet detachment from thermo-responsive PIPAAm-grafted surfaces.

### Challenges and Future Perspectives

Despite significant advancements, scaffold-free tissue engineering faces several challenges that must be addressed for wider clinical translation:

- **Scalability and Cost:** Developing clinically relevant 3D implants requires very high cell numbers and prolonged culture periods, creating scalability and cost-effectiveness challenges [10].
- **Structural Limitations:** Scaffold-free constructs often lack initial mechanical stability, and diffusion limitations restrict the thickness of viable tissues to approximately 40-80 μm without vascular networks [10] [6].
- **Standardization Concerns:** Achieving consistent, reproducible results across different laboratories remains challenging due to variations in cell types, culture conditions, and techniques [6].

Future developments are focusing on several key areas:

- **Vascularization Strategies:** Co-culture approaches with endothelial cells to create pre-vascularized networks within constructs, enhancing graft survival after transplantation [10].
- **Automation and Bioreactor Systems:** Automated systems for cell sheet production, stacking, and maturation to improve reproducibility, scalability, and reduce manual manipulation [10].
- **Advanced Biofabrication:** Integration with 3D bioprinting technologies to create more complex, hierarchically organized tissue structures [8].
- **Regulatory Advancements:** Evolving regulatory frameworks, including FDA recognition of New Approach Methodologies (NAMs) that incorporate 3D cell cultures as alternatives to animal testing [37].

As these technologies mature, magnetic levitation and thermo-responsive cell sheet engineering are poised to significantly advance regenerative medicine, drug development, and our fundamental understanding of tissue morphogenesis and disease processes.

Three-dimensional (3D) cell culture has emerged as a transformative technology in oncology research, bridging the critical gap between traditional two-dimensional (2D) monolayers and complex *in vivo* systems [7]. While 2D cultures have served as fundamental tools, they significantly oversimplify the tumor microenvironment (TME), leading to poor predictive value in preclinical drug development [40] [41]. The high failure rate of anticancer agents in clinical trials underscores the limitation of these conventional models [41]. Scaffold-free 3D culture systems, wherein cells self-assemble into spheroids or organoids without artificial supporting matrices, provide a more physiologically relevant platform [2]. These models recapitulate critical TME features, including **complex cell-cell interactions**, **oxygen and nutrient gradients**, and **spatial organization** that directly influence tumor progression, metastasis, and drug response [41] [7]. This application note details the implementation of scaffold-free 3D models for specifically investigating tumor microenvironments and drug penetration dynamics, providing structured protocols, quantitative data, and analytical workflows for the research community.

### Key Advantages of Scaffold-Free 3D Tumor Models

Scaffold-free models generate tumor spheroids that closely mimic the architectural and functional complexity of *in vivo* tumors. The self-assembly process promotes natural cell-ECM secretion and organization, leading to the formation of distinct proliferative, quiescent, and necrotic zones that drive **drug resistance** and tumor heterogeneity [7]. Research demonstrates that cells within 3D spheroids exhibit gene and protein expression profiles, including upregulated expression of chemokine receptors (CXCR7, CXCR4) and epithelial-mesenchymal transition (EMT) markers, that are more representative of clinical tumors than 2D-cultured cells [42] [7]. A pivotal study comparing non-small cell lung cancer (NSCLC) models found that scaffold-free (SF) spheroids displayed an intermediate drug resistance phenotype, with IC50 values higher than 2D monolayers but lower than scaffold-based (SB) spheroids, highlighting their utility in modeling gradient-dependent drug penetration barriers [42].

Table 1: Comparative Analysis of 2D vs. Scaffold-Free 3D Cancer Models

| Feature                   | 2D Monolayer Culture                          | Scaffold-Free 3D Spheroid Culture                                              |
|---------------------------|-----------------------------------------------|--------------------------------------------------------------------------------|
| Tumor Architecture        | Flat, monolayer; no tissue-like structure [4] | Spherical, multi-cellular aggregates with 3D structure [4]                     |
| Cell-Matrix Interactions  | Limited to rigid plastic surface [40]         | Self-produced, natural extracellular matrix (ECM) [42]                         |
| Proliferation & Gradients | Uniform exposure to nutrients and oxygen [41] | Distinct zones: proliferative (outer), quiescent (middle), necrotic (core) [7] |

| Feature                 | 2D Monolayer Culture                                               | Scaffold-Free 3D Spheroid Culture                                                        |
|-------------------------|--------------------------------------------------------------------|------------------------------------------------------------------------------------------|
| Gene/Protein Expression | Altered, less physiologically relevant profiles [43]               | More realistic profiles; upregulation of EMT and drug resistance markers [42]            |
| Drug Response           | Often hypersensitive; fails to predict clinical efficacy [41] [44] | Increased resistance; better predicts clinical outcomes and penetration issues [42] [44] |
| Throughput & Cost       | High-throughput, low cost [41]                                     | Moderately high-throughput with modern platforms; cost-effective [2] [41]                |

## Materials and Reagents

### The Scientist's Toolkit: Essential Research Reagents

Table 2: Key Reagents for Scaffold-Free 3D Spheroid Culture and Analysis

| Item/Category                     | Function/Description                                               | Example Products & Notes                                                               |
|-----------------------------------|--------------------------------------------------------------------|----------------------------------------------------------------------------------------|
| Cell Lines                        | Source of cancer cells for spheroid formation.                     | Patient-derived cells, commercial cancer cell lines (e.g., A549 for NSCLC) [42].       |
| Ultra-Low Attachment (ULA) Plates | Prevent cell adhesion, forcing cell aggregation into spheroids.    | Corning Spheroid Microplates; available in 96- and 384-well formats [41].              |
| Hanging Drop Plates               | Facilitate spheroid formation via gravity in suspended droplets.   | 3D Biomatrix, GravityPLUS plates [41] [44].                                            |
| Culture Medium                    | Provides nutrients for cell growth and spheroid maintenance.       | Base medium (e.g., DMEM, RPMI-1640) supplemented with serum or defined growth factors. |
| Viability Stains                  | Distinguish live and dead cells for viability analysis.            | Fluorescein diacetate (FDA)/Propidium Iodide (PI) or Calcein-AM/Ethidium Homodimer-1.  |
| Histology Reagents                | For spheroid fixation, embedding, sectioning, and staining.        | Formalin, paraffin, H&E stain, antibodies for immunohistochemistry (IHC) [45].         |
| ATP-based Viability Assays        | Quantify cell viability based on ATP content after drug treatment. | CellTiter-Glo 3D Cell Viability Assay (optimized for spheroids) [42].                  |

## Experimental Protocols

### Protocol 1: Generation of Spheroids using the Forced Floating Method

This protocol utilizes ULA plates to generate uniform, scalable spheroids ideal for high-throughput drug screening [41].

- Cell Preparation:** Harvest and count cells from a sub-confluent 2D culture. Prepare a single-cell suspension in complete culture medium at a concentration of **1x10^5 cells/mL**. The optimal seeding density must be determined empirically for each cell line (e.g., a common range is 1,000-10,000 cells per spheroid).
- Seeding:** Pipette the cell suspension into the wells of a 96-well ULA plate. A recommended volume is **100 µL per well**.
- Centrifugation (Optional):** Centrifuge the plate at a low speed (e.g., **200 x g for 3 minutes**) to aggregate cells at the bottom of the well and promote uniform spheroid formation.
- Incubation:** Place the plate in a **37°C, 5% CO2** incubator.
- Spheroid Formation:** Monitor spheroid formation daily under a microscope. Compact, spherical structures typically form within **24-72 hours**.
- Maintenance:** Spheroids are ready for experimentation after stable formation (typically 3-5 days post-seeding). Culture medium can be partially replaced (e.g., 50%) every 2-3 days for long-term cultures.


### Protocol 2: Drug Sensitivity and Penetration Assay

This protocol assesses the efficacy and penetration capacity of anticancer drugs using established spheroids.

- Spheroid Preparation:** Generate spheroids in a 96-well ULA plate following Protocol 1. Ensure spheroids are uniform in size before initiating treatment.

- **Drug Preparation:** Prepare a serial dilution of the chemotherapeutic or targeted therapeutic agent in complete culture medium. A typical 10-point, half-log dilution series is recommended for IC<sub>50</sub> determination.
- **Drug Treatment:** After spheroid formation, carefully remove 50  $\mu\text{L}$  of the old medium from each well and add **50  $\mu\text{L}$  of the 2X concentrated drug solution**. For controls, add medium without the drug. This results in a final volume of 100  $\mu\text{L}$  per well with the desired drug concentration.
- **Incubation:** Return the plate to the incubator for the desired treatment duration (e.g., **72-120 hours**).
- **Viability Assessment:**
  - **ATP-based Assay:** Equilibrate the plate and the CellTiter-Glo 3D reagent to room temperature for 30 minutes. Add **100  $\mu\text{L}$  of reagent** to each well. Place the plate on an orbital shaker for **5 minutes** to induce cell lysis. Incubate for 25 minutes in the dark to stabilize the luminescent signal. Record luminescence using a plate reader.
  - **Viability Staining:** Add a mixture of Calcein-AM (2  $\mu\text{M}$ , live cell stain) and Ethidium Homodimer-1 (4  $\mu\text{M}$ , dead cell stain) directly to the medium. Incubate for 45-60 minutes at 37°C. Image the spheroids using a fluorescence microscope or confocal imager to visualize drug penetration and zones of cell death.

The experimental workflow for drug testing is systematic, as shown in the diagram below.



**Figure 1: Drug Testing Workflow for 3D Spheroids.** This flowchart outlines the key steps from spheroid generation to data analysis in a typical drug sensitivity assay.



Data Analysis and Interpretation

Quantitative Analysis of Drug Response


Data from ATP-based viability assays are normalized to untreated control spheroids (100% viability) to generate dose-response curves. Nonlinear regression analysis is used to calculate the **half-maximal inhibitory concentration (IC50)**. Comparative studies consistently show that IC50 values are significantly higher in 3D spheroid models than in 2D monolayers, confirming their enhanced predictive power for drug resistance [42] [45].

Table 3: Exemplary Drug Sensitivity Data in Different Culture Models

| Cell Line (Cancer Type) | Therapeutic Agent  | IC50 in 2D | IC50 in Scaffold-Free 3D | Fold-Resistance (3D/2D) | Citation Context                                                         |
|-------------------------|--------------------|------------|--------------------------|-------------------------|--------------------------------------------------------------------------|
| A549 (NSCLC)            | Cisplatin          | 5.2 μM     | 25.1 μM                  | 4.8                     | Trend: IC50 (3D-SB) > IC50 (3D-SF) > IC50 (2D) [42]                      |
| U87 (Glioblastoma)      | Temozolomide (TMZ) | ~150 μM    | ~450 μM                  | ~3.0                    | 3D-cultured cells exhibited greater resistance to alkylating agents [45] |
| Primary Glioma          | Lomustine (CCNU)   | ~50 μM     | ~250 μM                  | ~5.0                    | 3D scaffold culture showed patterns similar to patient responses [45]    |

Molecular Analysis of Resistance Mechanisms

The acquisition of a drug-resistant phenotype in 3D spheroids is driven by several interconnected signaling pathways activated by the spheroid microenvironment. Key pathways include the upregulation of survival signals like **phospho-AKT** and **phospho-MAPK**, induction of **Epithelial-Mesenchymal Transition (EMT)**, and increased expression of drug efflux pumps [7]. The signaling network underlying this resistance is complex, as illustrated below.



**Figure 2: Signaling Pathways in 3D Spheroid Drug Resistance.** This network diagram shows how the 3D microenvironment activates multiple molecular mechanisms that converge to promote a drug-resistant phenotype. Arrows indicate activation or upregulation.

Gene expression analysis via RT-qPCR or RNA-Seq typically reveals **upregulation of EMT markers (e.g., Vimentin, N-cadherin)** and **multi-drug resistant genes (e.g., ABCB1)** in spheroids compared to 2D cultures [42]. Furthermore, protein-level analysis by Western Blot or IHC often shows increased levels of proteins like **O6-methylguanine-DNA methyltransferase (MGMT)**, a key mediator of resistance to alkylating agents in gliomas [45].

Scaffold-free 3D cell culture models represent a physiologically relevant and technologically advanced platform for oncology research. Their ability to accurately model the tumor microenvironment and recapitulate critical drug resistance mechanisms provides unparalleled insights for drug discovery and development. The protocols and analytical frameworks outlined in this application note empower researchers to systematically investigate tumor biology and therapeutic efficacy, ultimately accelerating the development of more effective anticancer strategies. As the field progresses, the integration of these models with high-content imaging, omics technologies, and personalized medicine approaches will further solidify their role as indispensable tools in the fight against cancer.

Within the rapidly expanding field of scaffold-free 3D cell culture, estimated to be worth between **\$8.09 and \$9.44 billion in 2025** and projected to grow at a **CAGR of approximately 14%** through 2033, cell sheet therapy has emerged as a particularly promising regenerative strategy [46] [9]. Unlike scaffold-based approaches that utilize artificial matrices, scaffold-free techniques rely on the innate ability of cells to self-assemble and secrete their own extracellular matrix (ECM), creating highly organized, functional tissue constructs [6] [3]. This approach preserves natural cell-cell interactions and tissue architecture, leading to enhanced physiological relevance and clinical outcomes [8] [47]. These engineered tissues demonstrate remarkable capabilities for promoting local tissue restoration by activating the host microenvironment and stimulating autologous stem cell proliferation [48]. This application note details specific protocols and therapeutic applications of scaffold-free 3D cell sheet techniques for repairing cardiac, corneal, and dermal tissues, providing researchers with standardized methodologies for advancing regenerative medicine.


Table 1: Clinical Applications of Scaffold-Free 3D Cell Sheets in Tissue Repair

| Target Tissue        | Stem Cell Construct          | Disease Model                          | Key Outcomes                                                                                                                |
|----------------------|------------------------------|----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| Heart/Cardiac Tissue | ASC spheroid                 | Discogenic low back pain               | Promoted tissue repair and functional recovery [6]                                                                          |
| Corneal Epithelium   | Limbal epithelial cell sheet | Unilateral limbal stem cell deficiency | Supported corneal regeneration and visual restoration [6]                                                                   |
| Skin/Soft Tissue     | hGMSCs/Matrigel matrix       | Full-thickness buccal mucosa wound     | Accelerated soft tissue repair by promoting autologous stem cell proliferation and enhancing collagen fiber generation [48] |
| Periodontal Tissue   | PDL-derived stem cell sheet  | Periodontitis                          | Enhanced periodontal regeneration and tissue integration [6]                                                                |
| Articular Cartilage  | ASC spheroid                 | Knee osteoarthritis                    | Promoted cartilage repair and functional improvement [6]                                                                    |

Experimental Protocols: Cell Sheet Fabrication and Characterization

Scaffold-Free 3D Cell Sheet Production Workflow

The following diagram illustrates the standardized protocol for generating scaffold-free 3D cell sheets for regenerative applications:



Protocol 1: Cell Sheet Generation from Human Gingival Mesenchymal Stem Cells (hGMSCs)

**Objective:** To generate scaffold-free 3D cell sheets using hGMSCs for soft tissue regeneration [48].

**Materials:**

- **hGMSCs** isolated from gingival tissues (P2-P5)
- **Growth medium:**  $\alpha$ -MEM supplemented with 15-20% FBS and 1% penicillin/streptomycin
- **Matrigel matrix** (Corning #354,234, protein concentration 8.9 mg/mL)
- **24-well plate**
- **Live/dead staining kit** (Calcein-AM/PI)
- **Osteogenic/adipogenic differentiation media**

**Methodology:**

- **Cell Preparation:** Harvest hGMSCs at 80-90% confluence using 0.25% trypsin-EDTA. Centrifuge at 15,000 rpm for 10 min at 4°C and resuspend in PBS.
- **Matrix Preparation:** Thaw Matrigel slowly at 4°C overnight. Keep all reagents on ice.
- **3D Construct Formation:** Mix hGMSCs suspension ( $1 \times 10^6$  cells in 150  $\mu$ L PBS) with equal volume of Matrigel (150  $\mu$ L) by pipetting gently on ice.
- **Plating:** Distribute 250  $\mu$ L of mixture per well in 24-well plate (final density: 3333 cells/ $\mu$ L). Incubate at 37°C for 30 min to allow solidification.
- **Culture Maintenance:** Add 500  $\mu$ L growth medium per well. Culture at 37°C with 5% CO<sub>2</sub>, changing medium every 3 days.
- **Quality Control:** Monitor cell distribution and soma extension daily using inverted microscopy. Assess viability on days 1, 3, 5, and 8 using live/dead staining.

**Validation Parameters:**

- **Viability:** >85% viable cells (Calcein-AM positive)
- **Differentiation Capacity:** Confirm multilineage potential through osteogenic and adipogenic induction
- **Surface Markers:** Verify MSC phenotype via flow cytometry (CD44+, CD90+, CD34-, CD45-)

**Protocol 2: Stem Cell Spheroid Formation for Cardiac Repair**

**Objective:** To generate 3D stem cell spheroids for myocardial regeneration and cardiac patch development [49] [47].

**Materials:**

- **Cardiac progenitor cells** or **adipose-derived stem cells (ASCs)**
- **Cardiac differentiation medium**
- **Ultra-low attachment plates** or **hanging drop plates**
- **Bioreactors** (for scale-up)
- **Calcium-sensitive dyes** for functional assessment

**Methodology:**

- **Cell Seeding:** Harvest ASCs at 90% confluence. Seed at density of  $1 \times 10^4$  cells per well in 96-well ultra-low attachment plates or 20  $\mu$ L drops in hanging drop plates.
- **Spheroid Formation:** Centrifuge plates at 200 $\times$ g for 10 min to enhance cell aggregation. Culture for 3-7 days at 37°C with 5% CO<sub>2</sub>.
- **Cardiac Differentiation:** Induce with cardiac differentiation medium containing BMP-4, VEGF, and FGF-2 for 14-21 days.
- **Maturation:** Transfer spheroids to rotary wall vessel bioreactors for enhanced nutrient distribution and maturation (5-7 additional days).
- **Functional Assessment:** Analyze spontaneous contraction, calcium transients, and cardiac marker expression (cTnT,  $\alpha$ -actinin).

**The Scientist's Toolkit: Essential Research Reagents**

Table 2: Key Reagent Solutions for Scaffold-Free 3D Cell Culture

| Reagent/Material            | Manufacturer Examples | Function                                                    | Application Specifics                                                       |
|-----------------------------|-----------------------|-------------------------------------------------------------|-----------------------------------------------------------------------------|
| Matrigel Matrix             | Corning (#354,234)    | Basement membrane extract providing natural ECM environment | hGMSCs culture for soft tissue repair; protein concentration 8.9 mg/mL [48] |
| Ultra-Low Attachment Plates | 3D Biomatrix, Corning | Prevent cell adhesion, promote 3D self-assembly             | Spheroid formation for cardiac and cartilage repair [6]                     |

| Reagent/Material           | Manufacturer Examples    | Function                                               | Application Specifics                                              |
|----------------------------|--------------------------|--------------------------------------------------------|--------------------------------------------------------------------|
| Stem Cell Culture Media    | Thermo Fisher, Reprocell | Support stem cell growth and maintenance               | Formulated with specific growth factors for different lineages [8] |
| Live/Dead Viability Kit    | Solarbio                 | Dual staining with Calcein-AM (live) and PI (dead)     | Quality assessment of 3D constructs [48]                           |
| Differentiation Media Kits | Solarbio, Beyotime       | Induce osteogenic, adipogenic, chondrogenic lineages   | Validate multipotency of stem cell sheets [48]                     |
| ELplasia 12K Flask         | Corning                  | Specialized scaffold for consistent spheroid formation | High-throughput production of uniform spheroids [50]               |

Therapeutic Applications and Outcome Assessment

Cardiac Tissue Repair

**Clinical Context:** Engineered heart tissues and cardiovascular spheroids show promise for treating familial cardiomyopathies, cardiac toxicity assessment, and in vivo cardiac regeneration (cardiac patches) [49].

Application Protocol:

- **Implantation Preparation:** Generate ASC spheroids (as in Protocol 2) with diameter 150-200 μm.
- **Delivery Method:** Suspend spheroids in fibrin hydrogel for injection or arrange as cardiac patch using biodegradable support.
- **Animal Model:** Utilize myocardial infarction models in SD rats or porcine models.
- **Assessment Parameters:**
  - **Functional:** Echocardiography (EF%, FS%)
  - **Histological:** Masson's trichrome for fibrosis, immunofluorescence for cardiac markers
  - **Electrophysiological:** ECG for arrhythmia incidence

**Outcome Data:** Studies show scaffold-free cardiac spheroids improve ejection fraction by 18-25% in rodent models and enhance vascularization in the infarct border zone [49].

Corneal Epithelial Regeneration

**Clinical Context:** Limbal epithelial cell sheets address unilateral limbal stem cell deficiency, restoring corneal integrity and transparency [6].

Application Protocol:

- **Cell Source:** Isolate limbal epithelial cells from biopsy or allogeneic sources.
- **Sheet Fabrication:** Culture on temperature-responsive surfaces or via self-assembly methods.
- **Surgical Implantation:** Transfer cell sheet to damaged corneal surface using fibrin carrier.
- **Assessment Parameters:**
  - **Clinical:** Corneal clarity, neovascularization, epithelial integrity
  - **Histological:** Goblet cell density, epithelial stratification
  - **Functional:** Visual acuity, tear film stability

Skin and Soft Tissue Reconstruction

**Clinical Context:** hGMSCs/Matrigel constructs accelerate healing of full-thickness soft tissue defects, including major aphthous ulcers penetrating muscle layers [48].

Application Protocol:

- **Construct Preparation:** Prepare hGMSCs/Matrigel mixture as described in Protocol 1.
- **Animal Model:** SD rat full-thickness buccal mucosa wound model.
- **Implantation:** Inject hGMSCs/Matrigel into submucosa of wound (250 μL per cm²).
- **Assessment Parameters:**
  - **Healing Rate:** Wound closure measurement daily
  - **Histomorphometry:** Collagen density, epithelial thickness, cellularity
  - **Immunohistochemistry:** Ki-67 for proliferation, CD31 for angiogenesis

**Outcome Data:** hGMSCs/Matrigel significantly accelerates soft tissue repair by promoting autologous stem cell proliferation and enhancing collagen fiber generation compared to untreated controls or Matrigel alone [48].

Technical Challenges and Optimization Strategies

The implementation of scaffold-free 3D cell sheet technologies presents several technical challenges that require careful consideration and optimization:

Table 3: Challenges and Solutions in Scaffold-Free 3D Cell Culture

| Challenge                  | Impact on Research                                                                                    | Recommended Solutions                                                                                            |
|----------------------------|-------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| Limited mechanical support | Hinders development of thick, organized tissues; restricts replication of in vivo mechanical cues [6] | • Sequential layering of cell sheets• Biodegradable temporary supports• In vivo maturation prior to implantation |
| Standardization concerns   | Variable spheroid size, viability, and function; complications in data interpretation [6]             | • Automated liquid handling systems• Standardized culture protocols• Quality control checkpoints                 |
| High production costs      | Limits accessibility for smaller labs and high-throughput applications [8]                            | • Shared facility resources• Optimization of media formulations• Scale-appropriate production methods            |
| Regulatory complexity      | Lengthy approval pathways for cell-based therapies [8] [59]                                           | • Early engagement with regulatory agencies• Comprehensive documentation• GMP-compliant processes from inception |

Scaffold-free 3D cell sheet technology represents a transformative approach in regenerative medicine, offering significant advantages through preservation of native cell-cell interactions and tissue-like architecture. The protocols detailed herein for cardiac, corneal, and dermal applications provide researchers with standardized methodologies to advance therapeutic development. The field is evolving rapidly, with emerging trends including **integration with bioprinting technologies**, **automation for high-throughput production**, and **personalized medicine approaches** using patient-specific cells [46] [8]. The convergence of scaffold-free culture with advanced bioengineering technologies such as microfluidics, genome editing, and next-generation omics will create unprecedented opportunities to develop novel regenerative therapies that more accurately recapitulate native tissue function and repair mechanisms [49]. As these technologies mature and standardization improves, scaffold-free 3D cell sheet therapies are poised to transition from research applications to mainstream clinical solutions for tissue repair and regeneration.

The high failure rate of anticancer drugs in clinical trials, estimated at **95%**, is largely attributed to the poor predictive value of conventional two-dimensional (2D) cell culture models [51]. These traditional monolayers fail to recapitulate the complex **three-dimensional architecture**, **cell-cell interactions**, and **physiochemical gradients** of human tumors [52] [51]. High-throughput drug screening using scaffold-free 3D cell culture models represents a transformative approach that bridges the critical gap between simplistic 2D systems and physiologically complex in vivo models [52] [51].

Scaffold-free 3D models, particularly spheroids and organoids, spontaneously self-assemble into structures that mimic key aspects of solid tumors: an **external proliferating zone**, an internal **quiescent zone**, and a hypoxic **necrotic core** [51]. This organization significantly influences drug penetration, metabolic activity, and cellular responses to therapeutic agents [53] [51]. By incorporating these critical microenvironmental elements, scaffold-free 3D models provide a more physiologically relevant platform for assessing both **drug efficacy** and **toxicity** early in the discovery pipeline, enabling better candidate selection and potentially reducing late-stage attrition [52] [54] [51].

Key Advantages of Scaffold-Free 3D Models in HTS

Enhanced Physiological Relevance

- **Native ECM Production:** Cells in scaffold-free systems produce their own extracellular matrix, creating a more authentic microenvironment that influences drug penetration and cellular responses [3] [51].
- **Gradient Formation:** These models naturally develop nutrient, oxygen, and metabolic waste gradients, creating heterogeneous microenvironments that drive the formation of proliferating, quiescent, and necrotic zones—features absent in 2D cultures but critical for understanding drug resistance [51].
- **Tumor-like Architecture:** The spontaneous self-assembly into 3D structures better replicates the histology and cellular interactions found in human tumors, including the development of hypoxic regions that promote aggressive tumor phenotypes [53] [51].

Improved Predictive Value for Drug Responses

The architectural and microenvironmental complexity of scaffold-free 3D models directly enhances the predictive accuracy of drug screening outcomes. Studies demonstrate that cells in 3D cultures exhibit **different gene expression patterns**, **drug metabolism capabilities**, and **therapeutic sensitivity profiles** compared to their 2D counterparts [51]. The presence of hypoxic regions is particularly significant, as oxygen-deprived cells activate DNA damage repair proteins, alter cellular metabolism, and decrease proliferation rates—all factors that substantially

influence tumor sensitivity to chemotherapeutic agents [51]. This improved pathophysiological relevance makes 3D models particularly valuable for assessing drug penetration, target engagement, and mechanism-of-action studies [53].

Table 1: Comparative Analysis of Culture Models for Drug Screening

| Feature                  | 2D Monolayers                  | Scaffold-Free 3D Models                    | In Vivo Models               |
|--------------------------|--------------------------------|--------------------------------------------|------------------------------|
| Architectural Complexity | Low                            | High (3D structure, ECM)                   | Very High (native tissue)    |
| Tumor Microenvironment   | Absent                         | Present (gradients, hypoxia)               | Fully Present                |
| Cost & Throughput        | Low cost, High-throughput      | Moderate cost, Compatible with HTS [55]    | High cost, Low throughput    |
| Scalability              | Excellent                      | Good with automation [55] [53]             | Limited                      |
| Predictive Value         | Limited (high false positives) | Improved for efficacy & toxicity [54] [51] | High but species-specific    |
| Ethical Considerations   | Minimal                        | Aligns with 3R principles [51]             | Significant ethical concerns |

## Automated Workflow for High-Throughput Screening

The integration of automation technologies has been pivotal in adapting fragile 3D culture systems for high-throughput screening applications [55]. Automated systems manage the entire 3D cell culture workflow—from plating and media exchange to compound addition, staining, and imaging—significantly reducing manual intervention, improving consistency, and enabling scale-up [55].

### Protocol: Automated Generation and Compound Screening of Scaffold-Free Spheroids

This protocol utilizes Corning Elplasia plates to generate multiple uniformly-sized spheroids per well, dramatically increasing data points while reducing reagent consumption and screening costs compared to standard U-bottom plates [53].

#### Materials & Equipment


- Corning Elplasia 96-well plates (#4442) [53]
- HCT116 cell line (ATCC) or other relevant cancer cells [53]
- Complete growth media (McCoy's medium supplemented with 10% FBS) [53]
- Automated liquid handling system
- Test compounds (e.g., cytarabine, doxorubicin, etoposide, staurosporine, taxol) [53]
- ImageXpress Micro Confocal High-Content Imaging System [53]
- MetaXpress High-Content Image Acquisition and Analysis Software [53]

#### Procedure

- **Plate Pre-treatment:** Pre-wet Elplasia plates according to the manufacturer's protocol [53].
- **Cell Seeding:** Using an automated liquid handler, plate HCT116 cells at a density of 50,000 cells/well in 100 µL of complete growth media.  
*Critical: Optimize seeding density for each cell line to ensure consistent spheroid formation. [53]*
- **Spheroid Formation:** Incubate plates at 37°C, 5% CO<sub>2</sub> for 24 hours to allow for spheroid formation. Visually inspect spheroids using a tissue culture microscope to verify formation before proceeding [53].
- **Compound Treatment:**
  - Prepare compound dilution series (e.g., seven-point, 1:5 serial dilutions) using an automated liquid handler.
  - Add compounds to wells in duplicate. Include vehicle-only controls.
  - Incubate for desired treatment duration (e.g., 6 days). For extended incubations, use automation for medium exchange and compound re-addition on day 3 [53].
- **Viability Staining:**
  - Prepare a live/dead staining solution containing: 3 µM Calcein AM (viability), 2 µM Ethidium Homodimer III (EthD-III, cytotoxicity), and 33 µM Hoechst 33342 (nuclear staining) [53].
  - Using automated liquid handling, add 10 µL of dye solution directly to each well. *Note: To minimize spheroid disturbance, do not wash out dyes after incubation. [53]*
  - Incubate plates for 2.5 hours at 37°C before imaging [53].
- **Image Acquisition:**
  - Acquire images using the ImageXpress Micro Confocal system with a 10X objective.
  - Set confocal pinhole size to 60 µm.
  - Capture Z-stacks (e.g., 12 images with 5 µm step size) to cover at least half the spheroid volume [53].
- **Image Analysis:**
  - Analyze 3D image stacks using the Custom Module Editor in MetaXpress software.

- Use the "Find Spherical Objects" algorithm (3D function) to identify spheroids based on Hoechst staining.
- Apply the "Count Nuclei" module to quantify total cell numbers.
- Use the "Live/Dead" and "Cell Scoring" modules to quantify live (Calcein AM-positive) and dead (EthD-III-positive) cells, respectively.
- Join object masks across all Z-planes using the "Connect by Best Match" algorithm to create 3D objects for accurate volumetric quantification [53].

The following workflow diagram illustrates this automated screening process:



### Protocol: Automated Live-Cell Analysis for Longitudinal Assessment

For time-course studies, the CellXpress.ai Automated Cell Culture System enables continuous monitoring and analysis without manual intervention [56].

#### Procedure

- **System Setup:** Load pre-configured spheroid workflow protocols onto the CellXpress.ai system [56].
- **Automated Culture:** The system automatically performs media changes with fine-tuned fluidics to avoid damaging or losing spheroids [56].
- **AI-Driven Monitoring:** The integrated AI uses machine learning to standardize processes, replacing subjective decisions with objective measurements for optimal passaging times [56].
- **Continuous Imaging:** Schedule regular imaging sessions to track spheroid growth and morphology changes over time.
- **Data Output:** The system provides traceable data logs and alerts for potential errors or contamination events [56].

## Quantitative Assessment and Data Analysis

### High-Content Analysis Parameters

Advanced image analysis of 3D models generates multi-parametric data that provides comprehensive insights into compound effects. Key quantitative parameters include:

- **Viability Metrics:** Total live/dead cell counts, live/dead cell ratio, and viability percentage [53].
- **Morphometric Parameters:** Spheroid diameter, volume, surface area, and shape factor (circularity) [53].
- **Spatial Distribution:** Radial analysis of viability and proliferation markers to assess compound penetration and heterogeneous effects [53].
- **Phenotypic Classification:** AI-based classification of treatment-induced morphological changes (e.g., spheroid disintegration, cellular dispersion) [56].



Data Visualization and Interpretation

The qHTSWaterfall R package enables effective 3-dimensional visualization of quantitative high-throughput screening data, incorporating compound concentration, efficacy, and curve-fit parameters (EC<sub>50</sub>, Hill slope) in a single plot [57]. This facilitates rapid identification of structure-activity relationships and compound prioritization [57].

Table 2: Representative Efficacy Data (HCT116 Spheroids Treated with Anticancer Compounds) [53].

| Compound      | EC <sub>50</sub> (μM) | Max Efficacy (% Reduction in Live Cells) | Primary Phenotypic Effect                         | Hill Slope |
|---------------|-----------------------|------------------------------------------|---------------------------------------------------|------------|
| Cytarabine    | 0.128                 | >80%                                     | Loss of compact structure, cell detachment [53]   | -          |
| Doxorubicin   | 0.156                 | >85%                                     | Cytotoxicity, increased cell death [53]           | -          |
| Staurosporine | 31.78                 | >75%                                     | Spheroid dispersion/flattening, cytotoxicity [53] | -          |
| Taxol         | 13.00                 | >70%                                     | Cytostatic effect, reduced total cell number [53] | -          |
| Etoposide     | -                     | >70%                                     | Cytostatic effect, reduced total cell number [53] | -          |

Data analysis reveals distinct mechanistic profiles: staurosporine and doxorubicin show strong cytotoxic effects with significant increases in dead cells, while taxol and etoposide exhibit primarily cytostatic effects with reduced total cell numbers [53]. Notably, some treatments cause substantial changes in spheroid volume (20-40% reduction) without significant diameter changes, highlighting the importance of volumetric measurements over simple diameter assessment [53].

The Scientist's Toolkit: Essential Research Reagent Solutions

Table 3: Key Reagents and Equipment for Scaffold-Free 3D HTS

| Product Category              | Example Products                                                    | Key Features & Applications                                                          |
|-------------------------------|---------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| Specialized Microplates       | Corning Elplasia plates [53]                                        | Microcavity design for multiple uniform spheroids/well; Ultra-low attachment surface |
| Cell Culture Media            | Cell-specific optimized media [8]                                   | Supports long-term spheroid growth; Maintains metabolic function                     |
| Viability/Cytotoxicity Assays | ATP-based assays (e.g., ReadIUse Rapid Luminometric ATP Assay) [52] | Superior penetration in 3D; Increased sensitivity vs. colorimetric assays            |
| Multiplex Staining Kits       | Calcein AM/EthD-III/Hoechst combination [53]                        | Simultaneous live/dead/nuclear staining; Minimal washing required                    |
| High-Content Imagers          | ImageXpress Micro Confocal [53]                                     | Z-stack acquisition; 3D analysis capability; Automated for HTS                       |
| Analysis Software             | MetaXpress with Custom Module Editor [53], IN Carta with AI [56]    | 3D object analysis; AI-based segmentation; Phenotypic classification                 |

Troubleshooting and Technical Considerations

Common Challenges and Solutions

- **Poor Spheroid Uniformity:** Optimize seeding density for each cell type. Use plates with microcavities (e.g., Elplasia) rather than standard U-bottom plates for improved consistency [53].
- **Incomplete Compound Penetration:** Consider smaller spheroids (150-300 μm) for better compound distribution. Pre-test compound diffusion rates using fluorescent analogs [51].
- **Variable Staining Efficiency:** Extend staining incubation times (2-4 hours) for adequate dye penetration into core regions. Use fluorescent/luminescent assays instead of colorimetric readouts [52].
- **Imaging Limitations:** Utilize confocal microscopy with Z-stacking to capture full spheroid volume. Optimize step size to balance resolution and acquisition time [52] [53].
- **Data Complexity:** Implement AI-driven analysis tools (e.g., IN Carta Software) for automated classification of complex phenotypic responses [56].

Quality Control Metrics

Establish strict QC criteria for spheroid experiments:

- **Size Distribution:** >80% of spheroids within  $\pm 15\%$  of target diameter [53]
- **Shape Uniformity:** Shape factor >0.85 (where 1.0 is a perfect sphere) [53]
- **Viability Threshold:** >90% viability in vehicle controls before compound addition
- **Edge Effect Monitoring:** Exclude outer wells if showing abnormal growth patterns

Scaffold-free 3D cell culture models represent a significant advancement in high-throughput drug screening by providing more physiologically relevant systems for assessing compound efficacy and toxicity. The integration of automation, advanced imaging, and AI-driven analysis has transformed these complex models into robust, scalable platforms compatible with HTS requirements [55] [56]. As the field evolves, emerging technologies such as organ-on-a-chip systems, multi-tissue platforms, and advanced bioprinting are poised to further enhance the predictive power of in vitro screening platforms [52] [8]. The continued refinement and adoption of these sophisticated models will ultimately accelerate the identification of safer, more effective therapeutics while reducing reliance on animal testing in accordance with the 3R principles [51].

## Navigating Challenges: Strategies for Standardization, Scalability, and Enhanced Performance

Within scaffold-free 3D cell culture, spheroids have emerged as a cornerstone for creating physiologically relevant models that bridge the gap between traditional 2D cultures and in vivo environments. These self-assembled cellular aggregates replicate critical aspects of native tissues, including complex cell-cell interactions and the development of metabolic gradients [58]. However, a significant challenge persists: achieving high reproducibility in spheroid size and viability, which is paramount for generating reliable, comparable data in downstream applications such as drug discovery and disease modeling [58] [59]. This application note provides detailed protocols and analytical frameworks to standardize the generation and assessment of scaffold-free spheroids, thereby enhancing experimental rigor and throughput.

### Platform Comparison for Spheroid Formation

The choice of culture platform is a primary determinant in the reproducibility of spheroid formation. The table below summarizes the key characteristics of widely used scaffold-free methods.

Table 1: Comparison of Scaffold-Free Spheroid Culture Platforms

| Platform                                      | Principle                                                                                                      | Typical Spheroid Yield per Well   | Key Advantages                                                                                                       | Key Limitations                                                         |
|-----------------------------------------------|----------------------------------------------------------------------------------------------------------------|-----------------------------------|----------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| U-/V-Bottom Ultra-Low Attachment (ULA) Plates | Prevents cell adhesion, forcing self-assembly into a single spheroid [60].                                     | 1                                 | Simple workflow; high uniformity; compatible with high-content imaging [53].                                         | Low throughput per well; higher reagent consumption for screening [53]. |
| Hanging Drop Plates                           | Cells aggregate by gravity within a suspended droplet [59].                                                    | 1                                 | Form compact, uniform spheroids; size controlled by initial cell seeding density [58].                               | Labor-intensive media changes and harvesting; not easily scalable [53]. |
| Microwell Plates (e.g., Corning Elplasia)     | Microcavities within ULA wells promote simultaneous formation of multiple spheroids [53].                      | ~78 (in a 96-well plate) [53]     | High-throughput; generates highly uniform spheroids within and between wells; maximizes data output [53].            | Potential for spheroid fusion if over-seeded; cost per plate.           |
| Pillar/Perfusion Plates                       | Spheroids formed on a pillar plate are interfaced with a perfusion plate for dynamic culture on a rocker [61]. | User-defined (e.g., 36, 144, 384) | Enhanced nutrient/waste exchange reduces necrotic core; improved cell growth and viability; assay-ready design [61]. | Requires specialized equipment (digital rocker); more complex setup.    |

### Detailed Protocols for Reproducible Spheroid Culture

#### Protocol: High-Throughput Spheroid Formation in Microwell Plates

This protocol is adapted for using Corning Elplasia plates to generate numerous uniform spheroids for high-content screening [53].

- **Materials:**

- Corning Elplasia 96-well plate (#4442)
- HCT116 cell line (or other cell line of interest)
- Complete growth medium (e.g., McCoy's with 10% FBS)
- Hemocytometer or automated cell counter

- **Method:**

- **Cell Preparation:** Harvest and count cells. Prepare a single-cell suspension at a concentration of **500,000 cells/mL** in pre-warmed complete medium.
- **Plating:** Pipette **100 µL** of the cell suspension into each well of the Elplasia plate (resulting in **50,000 cells/well**).
- **Spheroid Formation:** Carefully place the plate in a 37°C, 5% CO<sub>2</sub> incubator for **24 hours**. Do not disturb the plate during this period to allow for consistent spheroid formation across all microwells.
- **Inspection:** After 24 hours, visually inspect the plate under a tissue culture microscope to confirm the formation of spherical, compact spheroids in the microcavities.
- **Culture and Treatment:** Proceed with compound treatment or continued culture. For long-term cultures, replace **50% of the medium** every 2-3 days using careful pipetting to avoid disturbing the spheroids.

### Protocol: Dynamic Culture Using Pillar/Perfusion Plates

This protocol enhances spheroid health and reduces necrosis by employing dynamic flow conditions [\[61\]](#).

- **Materials:**

- 384PillarPlate and 384DeepWellPlate (Bioprinting Laboratories Inc.)
- LoadingPlate
- Digital rocker
- Hydrogel (e.g., Alginate, if encapsulation is desired)

- **Method:**

- **Spheroid Loading:** Seed cells into a ULA plate to form pre-spheroids or use the pillar plate for spheroid formation via self-assembly.
- **Sandwich Encapsulation (Optional):** For hydrogel encapsulation, place the pillar plate with spheroids onto a LoadingPlate containing a hydrogel solution. Apply gentle pressure to encourage hydrogel penetration around the spheroids.
- **Perfusion Setup:** Transfer the pillar plate onto the perfusion plate (deep well plate) filled with culture medium. The design creates a small gap, allowing medium to flow through during rocking.
- **Dynamic Culture:** Place the assembled unit on a digital rocker inside a standard 37°C, 5% CO<sub>2</sub> incubator. Set the rocker to a continuous, slow angle to ensure medium perfuses through the wells.
- **Medium Exchange:** To refresh medium, simply separate the pillar plate from the perfusion plate, replace the medium in the deep well plate, and reassemble.

### Workflow: Automated Spheroid Handling and Analysis

For labs requiring the highest levels of standardization, automated systems offer a solution for gentle and reproducible spheroid processing.




Diagram 1: Automated spheroid handling workflow. A novel microfluidic method gently aspirates single spheroids and deposits them encapsulated in nanoliter droplets, achieving high efficiency and maintaining viability [62].

Assay Optimization for 3D Spheroid Models

Standard 2D assay protocols often require optimization to account for the diffusion barriers and increased cell mass inherent in 3D spheroids.

Table 2: Optimization of Cell Viability Assays for 3D Spheroids

| Assay Parameter       | 2D Culture Recommendation                                | 3D Spheroid Optimization                                                                                       | Impact of Optimization                                                                                                                 |
|-----------------------|----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Reagent Concentration | Standard 1X concentration (e.g., for XTT assay) [60].    | <b>2X concentration</b> may be required for adequate penetration and signal generation [60].                   | <b>Increased Signal-to-Noise (S/N) ratio</b> , leading to greater assay sensitivity and ability to detect changes in cell health [60]. |
| Incubation Time       | 10 min - 3 hours (e.g., for PrestoBlue HS reagent) [60]. | Extend to <b>5 - 10 hours</b> to ensure complete reagent penetration and conversion in the spheroid core [60]. | Ensures the signal is within the <b>linear range</b> of the assay, providing a more accurate quantification of viability [60].         |
| Staining & Washing    | Typically includes wash steps to reduce background.      | Dyes can be left in wells <b>without washing</b> to minimize spheroid disturbance [53].                        | Prevents disruption or loss of spheroids during processing, improving reproducibility and workflow simplicity [53].                    |

Protocol: Viability Staining and 3D Image Analysis

This protocol is designed for simultaneous live/dead assessment of multiple spheroids directly in the culture well [53].

- **Materials:**
  - Staining solution: 3 μM Calcein AM, 2 μM Ethidium Homodimer III (EthD-III), 33 μM Hoechst 33342 in culture medium.
  - ImageXpress Micro Confocal High-Content Imaging System (or similar confocal microscope)
  - MetaXpress High-Content Image Acquisition and Analysis Software
- **Method:**
  - **Staining:** Add 10 μL of the pre-mixed staining solution directly to each 100 μL well containing spheroids.
  - **Incubation:** Incubate the plate for **2.5 hours** at 37°C. Do not wash.

- **Image Acquisition:** Acquire z-stack images using a confocal high-content imager (e.g., 12 images with a 5 µm step size using a 10x objective) to capture at least half the spheroid volume.
- **3D Analysis:** Use 3D analysis software (e.g., Custom Module Editor in MetaXpress) to:
  - Identify spheroids using the Hoechst channel with a "Find Spherical Objects" algorithm.
  - Quantify total nuclei (Hoechst-positive).
  - Quantify live cells (Calcein AM-positive, EthD-negative).
  - Quantify dead cells (EthD-positive). Use "Connect by Best Match" to join object masks across all planes into 3D objects.

The Scientist's Toolkit: Essential Research Reagents and Materials

Critical reagents and specialized materials form the foundation of reproducible scaffold-free spheroid work.

Table 3: Essential Research Reagent Solutions for Spheroid Culture and Analysis

| Item                                   | Function/Application                                                                                                   | Example Product/Catalog                                                                           |
|----------------------------------------|------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|
| Ultra-Low Attachment (ULA) Microplates | Prevents cell adhesion, enabling scaffold-free spheroid formation in U-bottom or microwell formats.                    | Corning Elplasia plates [53]; Thermo Scientific Nunclon Sphera plates [60]                        |
| Pillar/Perfusion Plate System          | Enables dynamic 3D culture, enhancing nutrient exchange and reducing central necrosis.                                 | Bioprinting Laboratories Inc. 384PillarPlate & 384DeepWellPlate [61]                              |
| Viability Assay Kits                   | Assess cell health and compound cytotoxicity in 3D models; require optimization for concentration and incubation time. | Invitrogen CyQUANT XTT Cell Viability Assay; Invitrogen PrestoBlue HS Cell Viability Reagent [60] |
| Fluorescent Live/Dead Stains           | Simultaneously label live (green) and dead (red) cells for 3D confocal imaging analysis.                               | Calcein AM (for live cells); Ethidium Homodimer III (EthD-III, for dead cells) [53]               |
| Automated Microfluidic Handling        | Provides gentle, high-throughput spheroid manipulation (aspiration, sorting, dispensing) for superior standardization. | Platforms utilizing the "Pick-Flow-Drop" principle [62]                                           |
| High-Content Confocal Imager           | Acquires z-stack images through entire spheroids for subsequent 3D volumetric analysis.                                | ImageXpress Micro Confocal System [53]                                                            |

The pursuit of engineering thick, complex tissues using scaffold-free methods is a fundamental challenge in regenerative medicine. Scaffold-free therapies aim to leverage the innate capacity of cells to create sophisticated, organotypic three-dimensional (3D) tissue structures, offering superior biocompatibility and reduced risk of foreign body response compared to scaffold-based approaches [10]. A primary structural limitation, however, is **diffusion constraints**, which restrict the thickness of viable tissues. Without a vascular network, the maximum thickness for a viable tissue construct is typically **40–80 micrometers** [10]. Beyond this limit, cells in the core of the construct experience critical deficits in oxygen and nutrients, leading to necrotic cell death. This application note details practical strategies and protocols to overcome this barrier, enabling the engineering of thick, metabolically active tissues for research and therapeutic applications.

The following table summarizes the primary structural challenges and the corresponding engineering strategies addressed in this document.

Table 1: Key Structural Limitations and Engineering Strategies

| Structural Limitation           | Impact on Tissue Construct                                                | Proposed Engineering Strategy                                           |
|---------------------------------|---------------------------------------------------------------------------|-------------------------------------------------------------------------|
| Limited Diffusion               | Necrotic core formation in constructs thicker than ~40-80 µm [10]         | Integration of vascular networks; use of bioreactors for perfusion [10] |
| Poor Mechanical Integrity       | Inability to handle or implant constructs; lack of structural stability   | Cell sheet stacking; self-assembly into spheroids/organoids [10] [63]   |
| Scalability and Reproducibility | High costs; inability to produce standardised constructs for clinical use | Automated cell sheet handling and robotic stacking systems [10]         |


Strategic Approaches and Experimental Workflows

Strategy 1: Cell Sheet Engineering and Stacking

Cell sheet technology utilizes temperature-responsive culture surfaces to harvest intact, contiguous layers of cells along with their deposited extracellular matrix (ECM). This preserves critical cell-cell junctions and ECM, providing a foundational unit for building thicker tissues [10].

## Workflow Diagram: Cell Sheet Stacking for Thick Tissue Construction

The following diagram illustrates the multi-step process of creating a thick tissue construct through the layering of individual cell sheets.



## Detailed Protocol: Fabrication of a Multi-Layered Cell Sheet Construct


- **Objective:** To create a 3D tissue construct with a thickness exceeding 150  $\mu\text{m}$  through the sequential stacking of individual cell sheets.
- **Materials:**
  - Temperature-responsive culture dishes (e.g., grafted with poly(N-isopropylacrylamide))
  - Cell culture medium specific to cell type (e.g., DMEM for fibroblasts, Endothelial Growth Medium for HUVECs)
  - Phosphate Buffered Saline (PBS)
  - Cell types: Primary human cells (e.g., dermal fibroblasts, mesenchymal stem cells) or relevant cell lines
  - Sterile transfer supports (e.g., polyvinylidene fluoride membranes)
  - Robotic or manual sheet stacking apparatus
- **Method:**
  - **Culture and Confluence:** Seed cells onto temperature-responsive dishes at a density of  $\geq 100,000$  cells/cm<sup>2</sup> [10]. Culture until 100% confluent and allow an additional 2-3 days for robust ECM deposition.
  - **Sheet Harvesting:** Aspirate the culture medium. Rinse gently with PBS. Add fresh medium and incubate at **room temperature (20-25°C)** for approximately 20-60 minutes. Monitor under a microscope for sheet detachment. The cell sheet will detach as a contiguous layer.
  - **Sheet Transfer:** Carefully position a sterile transfer support on top of the floating cell sheet. Using forceps, lift the support with the adhered cell sheet from the solution.
  - **Sheet Stacking:** Place the first cell sheet onto a culture dish or bioreactor chamber. For the second layer, carefully transfer a new cell sheet directly on top of the first. To ensure strong adhesion between layers, incubate the construct for 1-2 hours at **37°C** before adding subsequent layers.
  - **Maturation:** After the final layer is stacked, culture the multi-layered construct in a perfusion bioreactor for 1-2 weeks to promote ECM integration and strengthen cohesive forces.

## Strategy 2: Pre-vascularization of Constructs

A promising solution to the diffusion limit is the creation of an internal capillary network within the tissue construct before implantation. This can be achieved through co-culture strategies [10].

## Workflow Diagram: Creating a Pre-vascularized Tissue Construct

This diagram outlines the process of generating a tissue construct with an internal, self-assembled capillary network.



### Detailed Protocol: Generating a Pre-vascularized Spheroid

- **Objective:** To form a 3D spheroid containing a self-assembled network of endothelial cells.
- **Materials:**
  - Hanging drop plates or low-adhesion U-bottom spheroid plates
  - Co-culture medium (a 1:1 mixture of media optimized for both cell types)
  - Cell types: Human Umbilical Vein Endothelial Cells (HUVECs) and primary parenchymal cells (e.g., human myoblasts, fibroblasts)
  - Matrigel (for assay validation, optional)
- **Method:**
  - **Cell Preparation:** Trypsinize and count HUVECs and the chosen parenchymal cell line. Mix the cells at a recommended ratio of **1:4 (HUVECs : parenchymal cells)**.
  - **Spheroid Formation:**
    - **Hanging Drop Method:** Suspend the cell mixture in culture medium at a density of **25,000 cells/mL**. Pipette 20 µL droplets (~500 cells/droplet) onto the lid of a culture dish. Invert the lid and incubate. Cells will aggregate into a single spheroid at the bottom of each droplet within 24-48 hours.
    - **U-bottom Plate Method:** Seed 500 cells per well in a U-bottom ultra-low attachment plate. Centrifuge the plate at 300 x g for 3 minutes to aggregate cells at the well bottom.
  - **Culture and Maturation:** Culture the spheroids for **5-7 days**, changing 50% of the medium every other day. Capillary-like tubules formed by HUVECs will typically become visible within 3-5 days under a microscope.
  - **Validation:** Fix spheroids and immunostain for CD31 (PECAM-1) to confirm the formation of endothelial networks.

### Strategy 3: Advanced Maturation in Perfusion Bioreactors

Bioreactors that provide continuous medium perfusion are critical for maturing thick, scaffold-free constructs by ensuring convective transport of nutrients and oxygen [\[10\]](#).

### Detailed Protocol: Perfusion Culture of a Thick Tissue Construct



- **Objective:** To maintain viability and promote maturation in a thick, multi-layered cell sheet construct through continuous perfusion.
- **Materials:**
  - Perfusion bioreactor system with a chamber designed for 3D constructs
  - Peristaltic pump and silicone tubing
  - Oxygen sensor (optional, for advanced monitoring)
- **Method:**
  - **Bioreactor Setup:** Assemble the bioreactor and tubing according to the manufacturer's instructions. Sterilize the system by autoclaving or ethylene oxide treatment.
  - **Construct Loading:** Aseptically transfer the multi-layered cell sheet construct (from Protocol 3.1) into the bioreactor chamber.
  - **Perfusion Culture:** Connect the bioreactor to a medium reservoir. Initiate perfusion at a low flow rate (e.g., **0.2 mL/min**) to prevent mechanical damage to the construct. Gradually increase the flow rate to **1-2 mL/min** over 24-48 hours.
  - **Culture Duration:** Maintain the construct under perfusion for **1-4 weeks**, monitoring medium pH and gas levels. Sample the medium regularly for metabolic (e.g., glucose consumption, lactate production) analysis.

The Scientist's Toolkit: Essential Research Reagents and Materials

Table 2: Key Reagents and Materials for Scaffold-Free Tissue Engineering

| Item                                            | Function/Benefit                                                                                       | Example Application                                                |
|-------------------------------------------------|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------|
| Temperature-Responsive Culture Dishes           | Enable harvest of intact cell sheets with preserved ECM and cell junctions [10]                        | Cell sheet engineering protocol (3.1)                              |
| Mesenchymal Stem Cells (MSCs)                   | Multipotent stem cells with therapeutic potential for differentiation and immunomodulation [10] [63]   | Source for building various tissue types (bone, cartilage, muscle) |
| Human Umbilical Vein Endothelial Cells (HUVECs) | Form capillary-like tubular structures in co-culture systems [10]                                      | Pre-vascularization protocol (3.2)                                 |
| Low-Adhesion Spheroid Plates                    | Promote cell aggregation and 3D spheroid formation via forced floating                                 | Pre-vascularized spheroid formation (Protocol 3.2)                 |
| Perfusion Bioreactor System                     | Provides nutrient/waste exchange via convective flow, enabling long-term culture of thick tissues [10] | Advanced maturation protocol (3.3)                                 |

Within the advancing field of **scaffold-free 3D cell culture**, maintaining and controlling stem cell properties—or **stemness**—and functionality is a paramount objective for applications in regenerative medicine, disease modeling, and drug development [2]. Scaffold-free techniques, which allow cells to self-assemble into spheroids or organoids without an artificial supporting matrix, provide a more physiologically relevant environment that closely mimics the natural cellular microenvironment [4] [5]. A critical factor in optimizing these cultures is the regulation of cellular tension and cytoskeletal organization. Here, **Rho-associated coiled-coil containing protein kinase (ROCK) inhibitors** have emerged as powerful tools [64]. By inhibiting ROCK signaling, these molecules reduce actomyosin contractility, promoting cell survival, enhancing stemness, and facilitating the formation of larger, more structurally mature 3D tissue constructs [64] [65]. This application note details the role of ROCK inhibitors and provides optimized protocols for their use in scaffold-free 3D cultures, framed within the broader context of thesis research aimed at improving the physiological relevance and output of these advanced cellular models.

The Scientific Basis of ROCK Inhibition

ROCK Signaling in Cell Behavior


ROCK enzymes, comprising ROCK1 and ROCK2 isoforms, are key regulators of the **actin cytoskeleton** and cellular contractility through their effects on actomyosin dynamics [65]. They are activated by the RhoA GTPase and influence critical processes including cell adhesion, migration, and differentiation [65]. In the context of 3D cell culture, particularly during the initial phases of spheroid and organoid formation, high levels of ROCK-mediated contractility can lead to **anoikis**, a form of cell death that occurs when cells detach from their substrate [28]. Inhibition of ROCK has been shown to suppress this detrimental contractility, thereby enhancing cell viability and allowing for the successful self-assembly of 3D structures [28].

Mechanism of ROCK Inhibitors in Enhancing Stemness and Function

ROCK inhibitors such as **Y27632** and **Ripasudil** specifically target the ATP-binding site of ROCK1 and ROCK2, disrupting their kinase activity [65]. This disruption leads to a cascade of effects that are beneficial for 3D culture:

- **Reduced Actomyosin Contractility:** ROCK phosphorylates and activates myosin light chain (MLC), driving contractility. Inhibition relaxes the cytoskeleton [65].
- **Enhanced Cell Survival:** By mitigating compaction-induced stress and anoikis, ROCK inhibitors significantly increase the survival of dissociated cells and the viability of forming spheroids [28].
- **Promotion of 3D Growth:** In adipogenesis models using 3T3-L1 cells, ROCK inhibitors have been demonstrated to **dramatically enhance** the production of large, lipid-enriched 3D organoids, with significant increases in the expression of adipogenic genes like *Pparγ* and *Cebpa* [64]. Furthermore, micro-squeezer analysis revealed that these organoids were markedly less stiff, indicating a profound physical change in the tissue construct conducive to maturation [64].

The following diagram illustrates the signaling pathway affected by ROCK inhibitors and their functional outcomes in a 3D cell culture.



Quantitative Data on ROCK Inhibitor Effects

The impact of ROCK inhibitors on 3D cultures can be quantitatively measured across multiple parameters. The following tables summarize key experimental findings and the typical working concentrations for commonly used inhibitors.

Table 1: Quantitative Effects of ROCK Inhibitors on 3T3-L1 Adipogenesis in a 3D Culture Model [64]

| Parameter Measured             | Control (DIF+) | With ROCK-i (10 μM)       | Change  | Measurement Method                         |
|--------------------------------|----------------|---------------------------|---------|--------------------------------------------|
| Organoid Size (Area)           | Baseline       | Significantly Increased   | >> 100% | Phase Contrast Microscopy & Image Analysis |
| Lipid Accumulation             | Baseline       | Dramatically Enhanced     | >> 100% | Oil Red O Staining                         |
| Gene Expression: <i>Pparγ</i>  | Baseline       | Significantly Upregulated | >> 100% | Quantitative PCR (qPCR)                    |
| Gene Expression: <i>Cebpa</i>  | Baseline       | Significantly Upregulated | >> 100% | Quantitative PCR (qPCR)                    |
| Gene Expression: <i>Leptin</i> | Baseline       | Significantly Decreased   | ↓       | Quantitative PCR (qPCR)                    |
| ECM Gene: <i>Col4</i>          | Baseline       | Upregulated               | > 100%  | Quantitative PCR (qPCR)                    |
| ECM Gene: <i>Col6</i>          | Baseline       | Upregulated               | > 100%  | Quantitative PCR (qPCR)                    |

| Parameter Measured | Control (DIF+) | With ROCK-i (10 µM) | Change | Measurement Method      |
|--------------------|----------------|---------------------|--------|-------------------------|
| Physical Stiffness | Baseline       | Markedly Decreased  | ↓↓↓    | Micro-Squeezer Analysis |

Table 2: Common ROCK Inhibitors and Their Application in 3D Culture

| ROCK Inhibitor | Common Working Concentration | Key Characteristics                         | Applicable Cell Types                               |
|----------------|------------------------------|---------------------------------------------|-----------------------------------------------------|
| Y27632         | 5 - 20 µM                    | Well-characterized, widely used in research | Pluripotent Stem Cells (iPSCs/ESCs), Organoids [28] |
| Ripasudil      | 10 - 30 µM                   | Approved for clinical use (glaucoma)        | 3T3-L1, Ocular tissue models [64]                   |
| Fasudil        | 10 - 50 µM                   | Approved for clinical use (vasospasm)       | Various cancer cell lines, primary cells [65]       |

Detailed Experimental Protocols

Protocol 1: Scaffold-Free Spheroid Formation Using Hanging Drop Method with ROCK Inhibitor

This protocol is ideal for generating uniform spheroids from a variety of cell types, including dissociated stem cells.

Research Reagent Solutions & Materials:

- **Cell type:** Induced Pluripotent Stem Cells (iPSCs) or adult stem cells [66]
- **ROCK Inhibitor Stock Solution:** Y27632, typically prepared as a 10 mM stock in sterile water or DMSO [28]
- **Culture Medium:** Appropriate basal medium (e.g., DMEM/F12) supplemented with necessary growth factors and cytokines [66]
- **Equipment:** Low-adhesion U-bottom 96-well plates or plates specifically designed for hanging drop culture [66]

Methodology:

- **Cell Preparation:** Harvest and dissociate your stem cells into a single-cell suspension. Accurately determine the cell concentration using a hemocytometer or automated cell counter.
- **Solution Preparation:** Prepare the working cell suspension by diluting the cells in complete culture medium to the optimal seeding density (e.g., 5,000 - 10,000 cells per 20 µL drop). **Add Y27632 to a final concentration of 10 µM** from the stock solution.
- **Drop Generation:** Pipette a precise 20 µL aliquot of the cell suspension onto the lid of a tissue culture dish or into the designated wells of a hanging drop plate. Carefully invert the lid and place it over a dish filled with PBS to maintain humidity and prevent evaporation.
- **Culture:** Place the culture setup in a **37°C, 5% CO2 incubator** for 3-7 days. Monitor spheroid formation daily using brightfield microscopy.
- **ROCK Inhibitor Withdrawal:** After 72 hours, or once compact spheroids have formed, carefully transfer the spheroids to a low-adhesion plate with fresh culture medium **without** the ROCK inhibitor to allow for subsequent differentiation or experimental treatment.

Protocol 2: Enhancing Adipogenic Differentiation in 3D Organoids with ROCK Inhibition

This protocol, adapted from a published study, details the use of ROCK inhibitors to promote the formation and maturation of lipid-enriched 3D organoids [64].

Research Reagent Solutions & Materials:

- **Cell type:** 3T3-L1 preadipocyte cell line [64]
- **ROCK Inhibitor:** Ripasudil or Y27632
- **Culture Medium:**
  - *Maintenance Medium:* DMEM with 10% Bovine Calf Serum.
  - *Adipogenic Differentiation Cocktail (DIF+):* MDI induction cocktail (Isobutylmethylxanthine, Dexamethasone, Insulin) [64].
- **Staining Solution:** Oil Red O working solution for lipid staining.
- **Analysis Kits:** RNA extraction kit and reagents for quantitative RT-PCR.

Methodology:

- **3D Organoid Setup:** Create a scaffold-free 3D culture using a drop-cell method or low-adhesion round-bottom plates. Seed approximately 20,000 3T3-L1 cells per organoid in 28 µL of maintenance medium.
- **Initial Maturation:** Culture the preadipocytes for 7 days to allow for the formation of a mature, compact organoid structure. Electron microscopy can confirm ECM deposition and structural integrity at this stage [64].
- **Adipogenic Induction:** On day 7, switch the medium to the adipogenic differentiation cocktail (DIF+). **Supplement the DIF+ medium with 10 µM Ripasudil or Y27632** in the treatment group. The control group receives DIF+ alone.

- **Culture Maintenance:** Continue the culture for an additional 7-14 days, refreshing the differentiation medium and ROCK inhibitor every 2-3 days.
- **Endpoint Analysis:**
  - **Size Measurement:** Capture phase-contrast images and quantify organoid cross-sectional area using image analysis software.
  - **Lipid Staining:** Fix organoids and stain with Oil Red O to visualize and quantify neutral lipid accumulation.
  - **Gene Expression:** Extract total RNA and perform qPCR for adipogenic markers (*Pparγ*, *Cebpa*, *Leptin*) and ECM components (*Col4*, *Col6*).
  - **Biophysical Analysis:** Use a micro-squeezer to measure the physical stiffness of the organoids [64].

The Scientist's Toolkit: Essential Reagents and Materials

Table 3: Essential Research Reagent Solutions for Scaffold-Free 3D Culture with ROCK Inhibition

| Item Category                 | Specific Examples                                                                                 | Function & Importance                                                                                                                                                  |
|-------------------------------|---------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ROCK Inhibitors               | Y27632, Ripasudil, Fasudil                                                                        | Key biochemical modulators that enhance cell survival, reduce dissociation-induced apoptosis, and promote 3D structure formation [64] [28].                            |
| Specialized Cultureware       | Low-adhesion U-bottom plates, Hanging drop plates, Bioreactors                                    | Prevents cell attachment to plastic, forcing self-aggregation into spheroids. Bioreactors improve nutrient/waste exchange for larger organoids [66] [5].               |
| Cell Sources                  | Induced Pluripotent Stem Cells (iPSCs), Primary Cells, Adult Stem Cells                           | iPSCs offer unlimited potential for differentiation and patient-specific models. The cell source dictates protocol optimization [66].                                  |
| Basement Membrane Substitutes | Geltrex                                                                                           | Used in some scaffold-free protocols to provide initial biochemical cues for complex organoid generation, though its batch variability requires careful handling [66]. |
| Analysis Reagents             | Live/Dead Viability Stains, RNA Extraction Kits, qPCR Master Mixes, Antibodies for Immunostaining | Critical for characterizing the viability, morphology, gene expression, and protein localization within the 3D models [66].                                            |

Concluding Remarks

The integration of **ROCK inhibitors** into **scaffold-free 3D cell culture protocols** represents a significant advancement for enhancing the reproducibility, size, and functional maturity of spheroids and organoids. The detailed protocols and quantitative data provided here serve as a robust framework for researchers aiming to optimize stemness and specific differentiation outcomes in their systems. As the field progresses, the combination of ROCK inhibition with other small molecules, advanced bioreactor cultures, and bioprinting technologies will further solidify the role of scaffold-free models as indispensable tools in translational research [2] [8]. Future work in this area, including thesis research, should focus on fine-tuning inhibitor exposure timing and concentration for specific lineages, and exploring the long-term functional effects of this transient biomechanical manipulation.

The transition of **scaffold-free 3D cell culture** from a research tool to an industrial-scale manufacturing platform represents a pivotal challenge in regenerative medicine and drug development. While these systems—including spheroids, organoids, and cell sheets—provide superior **physiological relevance** by recapitulating native tissue microenvironments, their widespread commercial adoption has been limited by scalability constraints [10]. The global market, projected to grow at a **CAGR of 14-15%** and reach USD 1.05-1.85 billion by 2032-2035, reflects the urgent need for scalable solutions [6] [3]. Industrial scalability requires addressing two interconnected fronts: the **high cell numbers** needed to create functional, implantable devices and the **prolonged ex vivo culture periods** that increase costs and complexity [10]. This document outlines integrated strategies leveraging automation and advanced bioreactor systems to overcome these barriers, enabling the robust, reproducible, and cost-effective production of scaffold-free tissues for therapeutic and screening applications.

Scalable Scaffold-Free Platforms & Their Automation

Core Scaffold-Free Technologies with Scalable Potential

| Technology Platform    | Key Scalability Feature                    | Reported Throughput/Scale                                                        | Industrial Application Readiness                           |
|------------------------|--------------------------------------------|----------------------------------------------------------------------------------|------------------------------------------------------------|
| Cell Sheet Engineering | Automated stacking & robotic handling [10] | Robotic stacking of 5 layers in ~100 min; simultaneous culture of 50 sheets [10] | High for clinical applications (e.g., TempoCell, CellSeed) |

| Technology Platform                      | Key Scalability Feature                          | Reported Throughput/Scale                       | Industrial Application Readiness                            |
|------------------------------------------|--------------------------------------------------|-------------------------------------------------|-------------------------------------------------------------|
| Spheroid Formation (Hanging Drop)        | Compatibility with high-throughput screening [2] | High reproducibility (>90% for MCTs) [29]       | Medium-High (e.g., InSphero, 3D Biomatrix)                  |
| Spheroid Formation (Low-Adhesion Plates) | Ease of automation & maintenance [29]            | Suitable for high-throughput screening [29] [5] | High (standardized microplates from Corning, Thermo Fisher) |
| Magnetic Levitation                      | Simplified 3D culture initiation [29]            | Addresses biodegradability of scaffolds [29]    | Medium (e.g., n3D Biosciences)                              |
| 3D Bioreactors                           | Enhanced nutrient exchange & scalability [67]    | Enables larger tissue construct volumes [68]    | Medium-High for scale-up                                    |

Integration of Automation Systems

Automation is critical for de-risking technology transfer from the lab to clinical and commercial settings. Successfully demonstrated automated systems include:

- **Robotic Cell Sheet Manipulation:** Automated technologies have been developed for the production of multi-layered tissue constructs. For instance, a robotic apparatus successfully stacked **five layers of human skeletal muscle myoblast sheets within 100 minutes**, establishing a cost-effective manufacturing system for clinical-scale production [10].
- **Fully Automated Modular Platforms:** Integrated systems provide sequential seeding, expansion, and cell sheet preparation for various cell types (e.g., skeletal myoblasts, articular chondrocytes, iPSCs). These platforms maintain **aseptic conditions and produce high-quality cellular constructs** comparable to manual operations, which is essential for regulatory compliance and product consistency [10].
- **High-Batch Production Systems:** For cell sheet-based therapies, automated circuit systems have been engineered to culture up to **50 human oral mucosa epithelial cell sheets simultaneously** in separate, fully closed culture vessels. These systems meet the quality standards of manual procedures while dramatically increasing output [10].




Figure 1: Automated Workflow for Scaffold-Free 3D Culture. This diagram outlines the key stages from cell isolation to final product, highlighting the integration points for critical automation processes that ensure scalability and reproducibility.

Bioreactor Systems for Scaling and Maturation

Bioreactors provide the controlled, dynamic environment necessary for scaling up scaffold-free constructs beyond diffusion-limited dimensions.

The Role of Perfusion in 3D Construct Survival

A primary limitation of large-scale scaffold-free cultures is the **diffusion limit of oxygen and nutrients**, which constrains construct thickness to approximately **100-200 µm**—the maximum distance between adjacent capillaries *in vivo* [29]. Without adequate perfusion, constructs develop **hypoxic cores** leading to necrosis, growth arrest, and impaired functionality [29]. Bioreactor systems address this through:

- **Continuous Perfusion:** Mimicking native vascular supply, continuous media flow ensures sufficient delivery of oxygen and nutrients while removing metabolic wastes, enabling the survival of thicker tissues such as **12-layer cell sheets** [10].
- **Mechanical Stimulation:** Specific bioreactors provide mechanical cues (e.g., shear stress, compression) that enhance ECM production and tissue maturation, which is crucial for functional tissue engineering [68].
- **Scalability and Monitoring:** Modern industrial bioreactors incorporate **sensors and automation** to monitor parameters like temperature, pH, and oxygen in real-time, ensuring process stability and scalability from laboratory to industrial levels [68].

Advanced Bioreactor Strategies for Vascularization

To overcome diffusion limits in thick tissues, advanced bioreactor strategies focus on promoting vascularization:

- **Pre-vascularization via Co-culture:** Co-culturing **human umbilical vein endothelial cells (HUVECs)** with parenchymal cells (e.g., myoblasts) within cell sheets leads to the formation of capillary-like structures *in vitro*. Upon implantation, these pre-formed networks integrate with the host circulation, significantly increasing **neovascularization and graft survival** [10].
- **Engineered Vascular Beds:** Utilizing resected tissues (e.g., femoral muscles) or synthetic hydrogel beds within bioreactors provides a supportive scaffold for the formation of a functional, perfusable vasculature that can sustain multi-layered tissue constructs during extended culture periods [10].

Quantitative Comparison of Scalability Parameters

The selection of an appropriate scale-up strategy requires careful consideration of multiple, often competing, parameters. The table below provides a comparative analysis of key scalability factors across different platform technologies.

| Parameter                                     | Cell Sheet Engineering                                   | Spheroid (Hanging Drop)                           | Spheroid (Low-Adhesion)                           | 3D Bioreactors                 |
|-----------------------------------------------|----------------------------------------------------------|---------------------------------------------------|---------------------------------------------------|--------------------------------|
| Max Construct Thickness (without vasculature) | ~40-80 µm per layer; ~12 layers with perfusion [10] [29] | Limited by diffusion (~500 µm with necrosis) [29] | Limited by diffusion (~500 µm with necrosis) [29] | Higher, vessel-dependent [68]  |
| Culture Period for Maturation                 | Weeks (varies with layers) [10]                          | Days to weeks [5]                                 | Days to weeks [5]                                 | Weeks [10] [68]                |
| Relative Cell Number Requirement              | High (e.g., 104,000 cells/cm² for a 50 µm sheet) [10]    | Medium                                            | Medium                                            | Configurable/Variable [68]     |
| Ease of Vascularization Integration           | High (via co-culture in sheet) [10]                      | Low-Medium                                        | Low-Medium                                        | High (via perfusion flow) [29] |
| Automation Compatibility                      | High (robotic stacking) [10]                             | Medium (challenging medium exchange) [29]         | High [29] [2]                                     | High (built-in) [68]           |

Application Notes & Protocols

Protocol: Automated Generation of a Multi-Layered Myoblast Sheet for Tissue Repair

**Objective:** To reproducibly generate and stack multiple cell sheets using an integrated automation system for implantable tissue constructs.

Materials (The Scientist's Toolkit):

- **Temperature-Responsive Culture Dish:** pNIPAM-grafted surface (e.g., UpCell from Thermo Fisher) [10].

- **Robotic Manipulator Arm:** Custom or commercially available system with sterile enclosure.
- **Cell Culture Media:** Growth medium optimized for primary human myoblasts.
- **Perfusion Bioreactor System:** For post-stacking maturation under flow.

#### Methodology:

- **Cell Seeding and Expansion:** Seed human skeletal muscle myoblasts at a density of **100,000 - 150,000 cells/cm<sup>2</sup>** onto temperature-responsive surfaces. Culture to confluence under standard conditions (37°C, 5% CO<sub>2</sub>) for 3-5 days, allowing deposition of native ECM [\[10\]](#).
- **Automated Sheet Harvesting:** Activate the robotic system to reduce culture temperature to **<32°C** for 30-60 minutes. The hydrophilic transition of the pNIPAM surface allows gentle, enzymatic-free detachment of intact cell sheets with preserved cell-cell junctions and deposited ECM [\[10\]](#).
- **Robotic Sheet Stacking:** Using a robotic manipulator, sequentially transfer individual cell sheets onto a temporary or permanent support membrane. The procedure for stacking five layers should be completed within **~100 minutes** to maintain cell viability. The native ECM acts as a biological adhesive, eliminating the need for sutures or fibrin glue [\[10\]](#).
- **Maturation in Perfusion Bioreactor:** Transfer the stacked construct to a perfusion bioreactor. Culture under continuous medium flow (**0.5 - 2 mL/min**) for 7-14 days to promote tissue maturation, enhance mechanical integrity, and ensure survival of inner layers [\[10\]](#).

#### Troubleshooting:

- **Incomplete Detachment:** Ensure temperature is uniformly maintained below the LCST of 32°C.
- **Sheet Tearing:** Optimize robotic handling speed and suction pressure. Confirm robust ECM deposition during the culture phase.

### Protocol: Scalable Spheroid Production in a Stirred-Tank Bioreactor for High-Throughput Screening

**Objective:** To produce uniform, size-controlled spheroids at a scale suitable for pharmaceutical high-throughput screening campaigns.

#### Materials (The Scientist's Toolkit):

- **Stirred-Tank Bioreactor:** Single-use or glass vessel with controlled agitation, pH, and DO (Dissolved Oxygen) [\[68\]](#).
- **Ultra-Low Attachment (ULA) Microcarriers** or use of forced-floating aggregation.
- **Specific Cell Line:** e.g., HepG2 for hepatotoxicity studies [\[5\]](#).
- **Automated Sampling & Imaging System:** For real-time monitoring of spheroid size and morphology.

#### Methodology:

- **Bioreactor Inoculation:** Inoculate the bioreactor with a single-cell suspension of the target cell line at a pre-optimized density (e.g., **1-5 x 10<sup>5</sup> cells/mL**) in ULA-specific medium [\[68\]](#) [\[5\]](#).
- **Aggregation Phase Initiation:** Initiate gentle agitation at **40-60 rpm** for 24-48 hours to promote uniform cell aggregation. This step is critical for achieving consistent spheroid size.
- **Spheroid Maturation Phase:** Once spheroids are formed (typically 24h), adjust agitation to **60-80 rpm** to prevent spheroid sedimentation and fusion while ensuring adequate nutrient/waste exchange. Maintain culture for up to 21 days, with regular medium exchanges or perfusion [\[68\]](#).
- **Automated Harvesting and Dispensing:** Use an integrated fluidic handling system to sample, size-filter, and dispense spheroids into assay plates for downstream screening applications.






Figure 2: Integrated Strategy to Overcome Scalability Challenges. This diagram maps the primary technical challenges in scaling scaffold-free 3D cultures to the synergistic solutions provided by automation and advanced bioreactor systems.

The seamless **integration of automation with advanced bioreactor systems** is no longer a luxury but a necessity for the industrial translation of scaffold-free 3D cell culture technologies. The convergence of these fields directly addresses the core challenges of **cell number requirements, culture time, and construct size** that have historically limited commercial application. Future developments will be shaped by trends such as the adoption of **AI-driven process optimization**, increased use of **single-use bioreactors** to reduce contamination risks, and the maturation of **3D bioprinting** for the precise assembly of scaffold-free modules [68] [67]. As these technologies mature and standardization improves, scalable scaffold-free systems are poised to fundamentally transform the production of clinically relevant tissues for regenerative medicine and highly predictive, human-relevant models for drug discovery.

Proof of Concept: Validating Predictive Power Against 2D and Scaffold-Based Models

The transition from traditional two-dimensional (2D) to three-dimensional (3D) cell culture represents a paradigm shift in preclinical research. While **2D culture**, growing cells in a single monolayer on flat surfaces, has been a workhorse for decades due to its low cost and ease of use, it forces cells into an unnatural state that poorly mimics the complex architecture of living tissues [69] [70]. **3D cell culture**, particularly **scaffold-free** methods that allow cells to self-assemble into structures like spheroids and organoids, provides a more physiologically relevant model [46] [3]. This application note provides a detailed, data-driven comparison of these two systems, focusing on critical outputs for drug discovery: **gene expression, proliferation rates, and drug response**. Framed within the context of scaffold-free 3D research, this document offers validated protocols and insights to help researchers select the most predictive model for their work.

Comparative Data Analysis: 2D vs. 3D Models

Quantifying Differences in Cellular Phenotypes

Extensive comparative studies across various cancer cell lines reveal consistent and significant differences between 2D and 3D culture systems. The table below summarizes key quantitative findings from recent research.

Table 1: Comparative Analysis of Cellular Phenotypes in 2D vs. 3D Cultures

| Parameter                | 2D Culture Findings                                                                                  | 3D Culture Findings                                                                                                        | Context (Cell Line/Study)                                       |
|--------------------------|------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------|
| Proliferation Rate       | Higher cell proliferation rate [71]                                                                  | Significantly (p < 0.01) lower cell proliferation rate [71] [72]                                                           | Colorectal cancer (CRC) cell lines [72]                         |
| Response to Chemotherapy | Increased sensitivity to paclitaxel, docetaxel, 5-fluorouracil, cisplatin, and doxorubicin [71] [72] | More resistant to paclitaxel, docetaxel, 5-fluorouracil, cisplatin, and doxorubicin [71] [72]                              | Prostate cancer (PC-3, LNCaP, DU145) & CRC cell lines [71] [72] |
| Gene Expression Profile  | Altered, less physiologically relevant profile [71] [69]                                             | More in vivo-like profile; significant (p-adj < 0.05) dissimilarity vs. 2D, with 1000s of genes up/downregulated [71] [72] | Prostate cancer & CRC cell lines [71] [72]                      |

| Parameter                                 | 2D Culture Findings                                                                        | 3D Culture Findings                                                              | Context (Cell Line/Study)                                       |
|-------------------------------------------|--------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|-----------------------------------------------------------------|
| Expression of Stemness Markers            | Lower expression of stem cell markers [73]                                                 | Up-regulation of NANOG and SOX2 [73]                                             | Head and Neck Squamous Cell Carcinoma (HNSCC) [73]              |
| Apoptosis Profile                         | Standard cell death phase profile [72]                                                     | Altered cell death phase profile [72]                                            | Colorectal cancer (CRC) cell lines [72]                         |
| Methylation Pattern & microRNA Expression | Elevated methylation rate and altered microRNA expression compared to in vivo samples [72] | Pattern shared with Formalin-Fixed Paraffin-Embedded (FFPE) patient samples [72] | Colorectal cancer (CRC) cell lines vs. patient FFPE blocks [72] |

### Visualizing the Tumor Microenvironment in 3D

The following diagram illustrates the key architectural and physiological features of a 3D tumor spheroid that contribute to the data in Table 1, such as gradient formation and heterogeneous cell populations.




Diagram 1: Microenvironment of a 3D Tumor Spheroid.

### Application Notes & Experimental Protocols

This section provides detailed methodologies for establishing scaffold-free 3D cultures and conducting key comparative assays.

#### Protocol 1: Establishing Scaffold-Free 3D Spheroids

**Method:** Hanging Drop or U-Bottom Ultra-Low Attachment (ULA) Plates [69] [72] [74].

**Principle:** These methods prevent cell attachment to a substrate, encouraging cells to self-aggregate into spheroids through gravity and natural cell-cell adhesion.

#### Procedure:

- Cell Preparation:** Harvest and resuspend cells in complete growth medium. Determine cell count and viability using a standard method like trypan blue exclusion.
- Seeding Concentration:** Adjust cell suspension to a concentration of **5,000 - 8,000 cells** in a 200 µL aliquot [72]. The optimal density may require empirical optimization for different cell lines.
- Spheroid Formation:**
  - ULA Plate Method:** Pipette the 200 µL cell suspension into individual wells of a 96-well U-bottom ultra-low attachment (ULA) microplate [72].
  - Hanging Drop Method:** Spot droplets of cell suspension (e.g., 20-40 µL) onto the lid of a culture dish. Invert the lid and place it over a dish filled with PBS to maintain humidity [74].
- Culture Maintenance:** Culture spheroids under standard conditions (37°C, 5% CO2, humidified). Perform three consecutive **75% medium changes every 24 hours** to maintain nutrient levels and remove waste products without disturbing the forming spheroids [72].
- Maturation:** Allow spheroids to mature for 3-7 days before initiating experiments. Monitor formation and size consistency using microscopy.

#### Protocol 2: Assessing Cell Proliferation

**Method:** MTS/Tetrazolium-Based Colorimetric Assay (e.g., CellTiter 96 AQueous Assay) [72].

**Principle:** Metabolically active cells reduce MTS tetrazolium compound into a colored, aqueous-soluble formazan product, the absorbance of which is proportional to the number of living cells.

**Procedure:**

- **Sample Preparation:** Culture cells in 2D monolayers and as 3D spheroids in 96-well plates at an identical initial seeding concentration (e.g.,  $5 \times 10^3$  cells/well) [72].
- **Assay Execution:** At desired time points, add 20  $\mu$ L of MTS/PMS mixture directly to each well containing 100  $\mu$ L of culture medium.
- **Incubation:** Incubate the assay plate for 1-4 hours at 37°C, protected from light.
- **Measurement:** Record the absorbance at 490 nm using a standard microplate reader.
- **Data Analysis:** Compare the absorbance values between 2D and 3D cultures over time to generate proliferation curves. The 3D cultures will typically show a lower proliferation rate [71] [72].

**Protocol 3: Evaluating Drug Response**

**Method:** Viability and Clonogenic Assays Post-Drug Treatment [72] [73].

**Principle:** To measure both the immediate cytotoxic effect (viability) and the long-term reproductive potential (clonogenic survival) of cells after drug exposure.

**Procedure:**

- **Pre-treatment Culture:** Seed cells in 2D and 3D formats as described in Protocol 1. For 3D spheroids, culture for 48 hours to allow for full spheroid formation before drug exposure [73].
- **Drug Treatment:** Add a concentration range of the anti-cancer drug (e.g., cisplatin, 5-fluorouracil, docetaxel) to the culture medium. Include untreated controls.
- **Incubation:** Expose cells to the drug for a defined period (e.g., 7 days), refreshing drug-containing medium as needed.
- **Viability Assessment (MTS):**
  - For 3D spheroids, gently dissociate into single cells using trypsin/EDTA before the assay to ensure accurate reading [73].
  - Perform the MTS assay as outlined in Protocol 2.
- **Clonogenic (Proliferation) Assessment:**
  - After drug treatment, dissociate 2D and 3D cultures into single cells.
  - Seed a known number of cells into a new standard culture dish and allow them to grow in drug-free medium for 7-10 days.
  - Fix and stain the resulting colonies with crystal violet (0.04% in 1% ethanol). Solubilize the dye and measure absorbance at 550 nm, or count colonies manually [73].
- **Data Analysis:** 3D cultures will consistently demonstrate **decreased sensitivity** and higher clonogenic survival post-treatment, indicating stronger drug resistance [71] [72] [73].

**The Scientist's Toolkit: Essential Research Reagents**

Table 2: Key Reagents for Scaffold-Free 3D Cell Culture & Assays

| Item                              | Function/Application                                                                      | Example Product/Catalog                                               |
|-----------------------------------|-------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
| Ultra-Low Attachment (ULA) Plates | Prevents cell attachment, enabling spheroid formation in U-bottom or flat-bottom formats. | Nunclon Sphera super-low attachment U-bottom 96-well microplates [72] |
| MTS/Tetrazolium Assay Kit         | Colorimetric measurement of cell viability and proliferation.                             | CellTiter 96 AQueous Non-Radioactive Cell Proliferation Assay [72]    |
| Annexin V Apoptosis Kit           | Flow cytometry-based detection of apoptotic and necrotic cell populations.                | FITC Annexin V Apoptosis Detection Kit I [72]                         |
| Spheroid Dissociation Reagent     | Enzymatic digestion of spheroids into single-cell suspensions for downstream assays.      | Trypsin-EDTA (0.025%) solution [72]                                   |
| Crystal Violet Stain              | Staining and quantification of cell colonies in clonogenic assays.                        | Crystal violet (0.04% in 1% ethanol) [73]                             |

**Discussion & Workflow Integration**

**Interpreting the Molecular and Functional Data**

The data unequivocally shows that 3D scaffold-free cultures recapitulate in vivo behaviors more accurately than 2D models. The **altered gene expression** in 3D cultures, including the upregulation of stemness markers like *NANOG* and *SOX2*, is a primary driver for the observed phenotypic differences [72] [73]. These genetic programs contribute to the formation of a heterogeneous spheroid architecture with internal nutrient and oxygen gradients, which in turn leads to the presence of dormant and hypoxic cell populations. This microenvironment is a key factor underlying the **significantly higher resistance to chemotherapeutic agents** seen in 3D models, as it mimics the physical and biological barriers drugs encounter in solid tumors [71] [73].

**Strategic Implementation in the R&D Pipeline**

The following diagram outlines a recommended tiered workflow for integrating 2D and 3D models to leverage the strengths of each system, maximizing both efficiency and predictive power.




Diagram 2: A tiered R&D workflow integrating 2D and 3D models.

This integrated approach allows labs to use **2D for high-speed, high-volume screening** to eliminate ineffective compounds early, and then deploy **3D models for realistic, predictive validation** of promising leads, ultimately de-risking the pipeline and increasing the clinical success rate [70].

The transition from traditional two-dimensional (2D) cell culture to three-dimensional (3D) models represents a fundamental paradigm shift in biomedical research, offering a more physiologically relevant context for studying cellular behavior, drug responses, and disease mechanisms [7] [74]. Within 3D culture systems, a critical division exists between **scaffold-based** and **scaffold-free** approaches, each presenting distinct trade-offs in recapitulating the native cellular microenvironment. This analysis examines the comparative advantages and limitations of these methodologies, focusing specifically on their capacity to mimic the **extracellular matrix (ECM)** and provide appropriate **mechanical support** within the context of advancing scaffold-free 3D cell culture research.

The essential differentiator between these approaches lies in their use of external supporting materials. Scaffold-based systems utilize natural or synthetic matrices to provide structural support, while scaffold-free methods rely on the innate ability of cells to self-assemble into tissue-like constructs such as spheroids and organoids [75] [2]. Understanding the nuanced trade-offs between these systems is crucial for researchers selecting appropriate models for specific applications in drug screening, disease modeling, and regenerative medicine.

**Scaffold-Based 3D Cell Culture Systems**

Scaffold-based approaches utilize a three-dimensional framework that serves as an artificial extracellular matrix, providing structural support that enables cells to attach, migrate, and proliferate in three dimensions [7] [76]. These systems are characterized by their use of external materials that mimic aspects of the native ECM environment.

- **Hydrogel-Based Scaffolds:** These water-swollen polymer networks constitute one of the most common scaffold categories, comprising both natural and synthetic variants. Natural hydrogels include **collagen** (a primary component of native ECM), **Matrigel** (a basement membrane extract), **fibrin**, **alginate**, and **hyaluronic acid** [75] [77]. These materials are inherently bioactive and promote cell adhesion and function but suffer from batch-to-batch variability and limited control over mechanical properties. Synthetic hydrogels include **poly(ethylene glycol) [PEG]**, **poly(vinyl alcohol)**, and other synthetic polymers that offer highly tunable mechanical properties and reproducibility but lack innate bioactivity unless modified with cell-adhesion ligands [77].
- **Solid Polymer Scaffolds:** These include fibrous or spongelike structures made from materials such as **polystyrene** or biodegradable polyesters like **poly(lactic-co-glycolic acid) [PLGA]** and **polycaprolactone [PCL]** [15]. These scaffolds provide robust mechanical support and are particularly useful for engineering tissues requiring significant structural integrity, such as bone or cartilage.

Scaffold-Free 3D Cell Culture Systems

Scaffold-free techniques exploit the inherent propensity of cells to self-assemble and secrete their own ECM components, forming complex 3D structures without external matrix support [2] [3]. These systems generate tissue surrogates that often exhibit superior tissue-like organization and functionality.

- **Spheroid Cultures:** These 3D aggregates form via cellular self-assembly and can be generated using several techniques. The **hanging drop method** utilizes gravity to encourage cell aggregation at the bottom of a droplet [74]. **Ultra-low attachment plates** feature specially coated surfaces that prevent cell adhesion, forcing cells to aggregate in the suspension [2] [15]. **Agitation-based methods** using spinner flasks or orbital shakers maintain cells in suspension to prevent attachment and promote spheroid formation [74].
- **3D Cell Sheet Technology:** This approach utilizes temperature-responsive culture surfaces grafted with polymers like **poly(N-isopropylacrylamide [pNIPAM])** [10]. Cells proliferate and deposit their own ECM under standard culture conditions. When the temperature is reduced below 32°C, the surface becomes hydrophilic, prompting the detachment of an intact, contiguous cell sheet complete with preserved cell-cell junctions and endogenous ECM [10]. These sheets can be stacked or rolled to create more complex, multi-layered tissue structures.
- **Microfluidic Systems:** These "lab-on-a-chip" devices allow for precise control over the cellular microenvironment and fluid dynamics, facilitating the formation and maintenance of scaffold-free constructs under perfused conditions that enhance nutrient delivery and waste removal [75].

Comparative Analysis: Key Trade-offs

The choice between scaffold-based and scaffold-free 3D culture systems involves significant trade-offs across multiple parameters, with profound implications for experimental outcomes and physiological relevance.

Table 1: Comprehensive Comparison of Scaffold-Based vs. Scaffold-Free 3D Culture Systems

| Parameter                 | Scaffold-Based Systems                                                                                                                          | Scaffold-Free Systems                                                                                                   |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| ECM Mimicry               | Variable; depends on scaffold composition. Natural hydrogels (e.g., collagen, Matrigel) offer good biochemical mimicry [77].                    | <b>High physiological relevance;</b> cells secrete and organize their own native, tissue-specific ECM [2] [10].         |
| Mechanical Support        | <b>Precisely tunable</b> and typically high; mechanical properties (stiffness, elasticity) can be engineered to match target tissues [76] [77]. | <b>Limited and cell-dependent;</b> relies on self-produced ECM, often resulting in softer constructs [10].              |
| Structural Complexity     | Enables creation of complex architectures, especially with 3D bioprinting [75].                                                                 | Primarily forms spheroids, organoids, and sheets; complexity arises from self-organization [2].                         |
| Throughput & Scalability  | Good for high-throughput screening with standard formats; scalability can be challenging for larger constructs [76].                            | High-throughput spheroid formation possible with ULA plates; scaling thicker tissues requires vascularization [3] [10]. |
| Technical Reproducibility | <b>High</b> for synthetic scaffolds (e.g., PEG); <b>lower</b> for natural materials due to batch-to-batch variability [77].                     | Moderate; spheroids can show heterogeneity in size. Standardized protocols improving reproducibility [2].               |
| Bioactive Composition     | Can be ill-defined (natural) or require functionalization (synthetic); may include non-physiological degradation products [77].                 | <b>Fully biological, defined by cells;</b> contains native signaling moieties and avoids synthetic materials [10].      |
| Cost Considerations       | Varies; synthetic scaffolds can be costly to develop, while natural ones are expensive to source [76].                                          | Generally lower material costs, but specialized equipment (e.g., bioreactors) can be expensive [3].                     |

## Critical Trade-off 1: ECM Mimicry and Biochemical Fidelity

The capacity to accurately replicate the biochemical composition and topology of the native extracellular matrix is crucial for maintaining physiologically relevant cell behavior.

**Scaffold-Based Trade-offs:** While natural hydrogel scaffolds like collagen and Matrigel provide familiar adhesion motifs and biological cues that promote cell survival and function, they are complex and **ill-defined** [77]. This complexity makes it difficult to isolate specific ECM signals responsible for observed cellular behaviors. Furthermore, these materials exhibit inherent **batch-to-batch variability**, which can compromise experimental reproducibility and data interpretation [77]. Synthetic scaffolds, though highly reproducible, are largely inert and require deliberate functionalization with cell-adhesion peptides (e.g., RGD sequences) to support cell attachment, making them imperfect mimics of the diverse native ECM [77].


**Scaffold-Free Advantages:** Scaffold-free systems excel in ECM mimicry because cells themselves **secrete and organize their own tissue-specific ECM** [10]. This self-produced matrix contains the precise combination of proteins, glycosaminoglycans, and growth factors native to the cell type, creating a highly physiologically relevant microenvironment. This autonomy leads to superior cell differentiation, organization, and function, as evidenced by their ability to form complex organoids that closely resemble in vivo tissues [2]. The absence of artificial or animal-derived matrix components also reduces the risk of immunogenic reactions and xenogenic contamination, making this approach particularly attractive for clinical applications [10].

## Critical Trade-off 2: Mechanical Support and Microenvironment Control

The physical and mechanical properties of the 3D culture system profoundly influence cellular processes including differentiation, migration, and proliferation.

**Scaffold-Based Advantages:** A principal strength of scaffold-based systems is the **precise exogenous control** they offer over the mechanical microenvironment [77]. Researchers can fine-tune parameters such as stiffness, elasticity, and degradability to match specific tissue types—for example, creating a stiff matrix for bone tissue models or a soft, compliant matrix for neural or adipose tissues [76] [77]. This tunability is invaluable for studying mechanotransduction—the process by which cells convert mechanical stimuli into biochemical signals. Furthermore, scaffolds provide immediate structural integrity, enabling the engineering of large and complex tissue constructs.

**Scaffold-Free Limitations:** The mechanical properties of scaffold-free constructs are inherently **cell-mediated and limited** [10]. The stiffness and strength of the construct depend entirely on the cells' capacity to produce and remodel their own ECM. This often results in relatively soft microtissues that may lack the structural robustness needed for certain applications or for handling and implantation. A significant technological bottleneck is the **diffusion limit of oxygen and nutrients**, which restricts the viable thickness of scaffold-free constructs to approximately 40–80  $\mu\text{m}$  in the absence of a perfused vascular network [10]. Growing thicker, clinically relevant tissues requires sophisticated and costly strategies such as co-culture with endothelial cells to induce pre-vascularization or the use of advanced bioreactor systems for dynamic perfusion [10].





**Figure 1:** Decision framework for selecting between scaffold-free and scaffold-based 3D cell culture systems

## Application Notes and Experimental Protocols

### Protocol 1: Establishing Scaffold-Free Spheroid Cultures via Ultra-Low Attachment Plates

This protocol provides a robust and scalable method for generating uniform 3D spheroids, ideal for high-throughput drug screening and cancer research applications [2] [15].

#### Research Reagent Solutions:

- **Ultra-Low Attachment (ULA) Plates:** Multi-well plates with a covalently bonded hydrogel surface that prevents protein attachment and cell adhesion, forcing cellular self-assembly into spheroids.
- **Cell Culture Media:** Standard media appropriate for the cell type, often supplemented with specific factors to promote viability and ECM production in 3D.
- **Extracellular Matrix Staining Kit:** For example, phalloidin (for F-actin) and antibodies against collagen or fibronectin, to visualize the self-produced ECM.

#### Step-by-Step Workflow:

- **Cell Harvesting and Seeding:**
  - Harvest sub-confluent cell cultures using standard trypsinization techniques.
  - Centrifuge the cell suspension and resuspend the pellet in complete culture medium.
  - Count cells and adjust density to the optimal concentration for your cell type (typically 1,000 - 10,000 cells per well for 96-well ULA plates).
  - Seed the cell suspension into the ULA plates, ensuring homogeneous distribution.
- **Spheroid Formation and Culture:**
  - Centrifuge the sealed ULA plates at low speed ( $100 - 400 \times g$  for 1-3 minutes) to gently aggregate cells at the bottom of each well.
  - Carefully transfer the plates to a standard cell culture incubator ( $37^{\circ}\text{C}$ , 5%  $\text{CO}_2$ ).
  - Monitor spheroid formation daily under a light microscope. Compact, spherical structures should form within 24-72 hours.
- **Long-Term Maintenance and Analysis:**
  - Culture media can be partially (50-70%) replaced every 2-3 days without disrupting the spheroids, using careful pipetting.
  - Spheroids are typically ready for experimental analysis (e.g., drug treatment, histology, molecular analysis) within 3-7 days.
  - For ECM analysis, fix spheroids in paraformaldehyde, embed in paraffin or OCT compound, and section for immunohistochemical staining of self-secreted ECM proteins.

### Protocol 2: Generating 3D Constructs via Cell Sheet Engineering

This protocol leverages temperature-responsive culture dishes to produce intact, ECM-rich cell sheets for applications in regenerative medicine and complex tissue modeling [10].

#### Research Reagent Solutions:

- **Temperature-Responsive Culture Dishes:** Commercially available dishes (e.g., UpCell) grafted with pNIPAM.
- **Standard Cell Culture Reagents:** Including culture media, trypsin/EDTA, and phosphate-buffered saline (PBS).
- **Cell Sheet Handling Tools:** Customized supports, membranes, or pipettes designed for the gentle transfer of fragile cell sheets.

#### Step-by-Step Workflow:


- **Surface Seeding and Cell Expansion:**
  - Seed cells onto temperature-responsive culture dishes at a higher density than conventional culture (e.g., 104,000 cells/cm<sup>2</sup>) to promote rapid confluence and ECM deposition [10].
  - Culture the cells under standard conditions ( $37^{\circ}\text{C}$ ) until they reach confluence and continue culture for an additional 2-5 days to allow for robust ECM synthesis and sheet formation.
- **Cell Sheet Harvesting:**
  - Once a confluent sheet with significant ECM is established, remove the culture medium and gently wash the cell layer with PBS.
  - Add fresh culture medium and transfer the culture dish to a room temperature environment ( $\leq 20^{\circ}\text{C}$ ) for approximately 30-60 minutes.



- Observe the dish under a microscope. As the temperature-responsive polymer hydrates and expands, the intact cell sheet will spontaneously detach from the surface.

• **Cell Sheet Manipulation and Stacking:**

- Carefully transfer the floating cell sheet using pipettes, specialized supports, or by gently aspirating the medium.
- To create thicker 3D tissues, multiple cell sheets can be stacked layer-by-layer onto each other. The endogenous ECM acts as a biological adhesive, fusing the sheets together over 12-24 hours in culture.



**Figure 2:** Workflow for scaffold-free 3D cell sheet engineering

**The Scientist's Toolkit: Essential Research Reagents and Materials**

Successful implementation of 3D cell culture models requires specific reagents and tools. The following table details key solutions for both scaffold-free and scaffold-based approaches.

*Table 2: Essential Research Reagent Solutions for 3D Cell Culture*

| Category                | Product Examples                                                              | Function & Application                                                                                                  |
|-------------------------|-------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| Scaffold-Free Platforms | <b>Ultra-Low Attachment (ULA) Plates</b> (e.g., Corning Spheroid Microplates) | Surface modification prevents cell attachment, enabling spheroid formation in a high-throughput format [2] [15].        |
|                         | <b>Temperature-Responsive Dishes</b> (e.g., UpCell)                           | pNIPAM-grafted surface allows for non-enzymatic harvest of intact, ECM-rich cell sheets [10].                           |
|                         | <b>Hanging Drop Plates</b>                                                    | Platforms with accessible wells for creating individual droplets where cells aggregate into spheroids via gravity [74]. |
| Scaffold-Based Matrices | <b>Natural Hydrogels</b> (e.g., Matrigel, Collagen I, Alginate)               | Provide a biologically active, ECM-like environment for cell encapsulation and growth [7] [75] [77].                    |
|                         | <b>Synthetic Hydrogels</b> (e.g., PEG-based kits)                             | Offer defined, tunable mechanical and biochemical properties for controlled reductionist studies [77].                  |
| Specialized Equipment   | <b>Bioreactors</b> (e.g., spinner flasks, rotating wall vessels)              | Provide dynamic culture conditions to enhance nutrient/waste exchange for larger scaffold-free aggregates [74] [10].    |

| Category | Product Examples                                            | Function & Application                                                                                                          |
|----------|-------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
|          | <b>Microfluidic Systems</b> (e.g., Organ-on-a-Chip devices) | Enable precise control over microscale culture environments and fluid flow for both spheroids and hydrogel-embedded cells [75]. |

The analysis of scaffold-free and scaffold-based 3D cell culture systems reveals a landscape defined by complementary strengths and unavoidable trade-offs. The selection of an appropriate model must be guided by the specific scientific question, with a clear understanding that no single system perfectly recapitulates all aspects of the in vivo microenvironment.

**Scaffold-free models are the superior choice** for research where high-fidelity ECM composition, enhanced cell-cell signaling, and maximal physiological relevance of cellular responses are the primary objectives, particularly for drug screening and personalized medicine applications [2] [3]. Their main limitations in mechanical support and construct size are being actively addressed through emerging technologies. **Scaffold-based systems remain indispensable** when predefined mechanical properties, structural complexity, or the need to systematically deconstruct specific ECM cues are paramount to the experimental design [76] [77].

The future of 3D cell culture lies in the development of **advanced hybrid systems** and technological integrations. These include the incorporation of scaffold-free organoids into microfluidic organ-on-a-chip devices for enhanced perfusion, the use of 3D bioprinting to precisely position spheroids within supportive (but perhaps biodegradable) matrices, and the application of artificial intelligence to design next-generation biomaterials [75] [76]. Furthermore, ongoing efforts to standardize protocols and improve the scalability of scaffold-free production will be critical for their broader adoption in industrial drug discovery and regenerative medicine, solidifying their central role in the next generation of in vitro models.

Osteosarcoma (OS) is the most common primary malignant bone tumor in children and adolescents [78] [79]. Despite significant improvements in long-term survival with the introduction of combination chemotherapy, outcomes for patients with metastatic or recurrent OS remain poor, with survival rates stagnating over the past four decades [80]. A significant clinical challenge is the development of **chemoresistance**, which accounts for approximately 90% of treatment failures in cancer therapy [80].

Traditional two-dimensional (2D) cell culture models have proven insufficient for studying chemoresistance as they fail to recapitulate the complex three-dimensional (3D) architecture, cell-cell interactions, and cell-extracellular matrix (ECM) relationships of the native tumor microenvironment [78] [79]. Scaffold-free 3D spheroid models have emerged as a powerful **tumor engineering** approach that closely mimics the in vivo tumor milieu, providing a more physiologically relevant platform for investigating drug resistance mechanisms and screening novel therapeutic strategies [78] [81] [79]. This case study details the application of scaffold-free 3D osteosarcoma spheroid models for investigating the underlying mechanisms of chemoresistance.

The Advantage of 3D Spheroid Models in Recapitulating Chemoresistance

Compared to conventional 2D monolayer cultures, 3D OS spheroids demonstrate **significantly higher resistance** to chemotherapeutic agents, closely mirroring the response observed in clinical settings [81] [79]. The table below summarizes key comparative studies of drug responses in 2D versus 3D osteosarcoma models.

Table 1: Comparative Drug Responses in 2D vs. 3D Osteosarcoma Models

| Cell Line         | 3D Method                | Chemotherapeutic Agent                     | Finding in 3D vs 2D                                                              | Citation |
|-------------------|--------------------------|--------------------------------------------|----------------------------------------------------------------------------------|----------|
| SaOS2, HOS        | Hanging Drop             | Doxorubicin, Cisplatin, Taxol, Taurolidine | Significantly increased IC50 values                                              | [81]     |
| Multiple OS lines | Low Binding Plates       | Doxorubicin                                | Increased chemoresistance; Upregulation of cathepsin D                           | [79]     |
| U2OS              | Liquid Overlay (Agarose) | Doxorubicin, Cisplatin                     | Reduced drug permeability; Core densification acting as barrier                  | [79]     |
| MG-63             | Poly-HEMA-coated plates  | Doxorubicin, Cisplatin, Methotrexate       | Increased chemo- and radio-resistance in CSCs; Enhanced ABC transporter activity | [79]     |

The enhanced drug resistance observed in 3D spheroids is attributed to several key physiological factors that are absent in 2D cultures:

- **Gradient formation:** Development of chemical and physiological gradients (oxygen, nutrients, pH) from the spheroid periphery to the core [82].
- **Altered cell state:** Presence of quiescent cells in the spheroid core with reduced metabolic activity and proliferation rates [79].
- **Physical barrier:** Dense packing of cells and ECM components limits drug penetration and distribution [79].
- **CSC enrichment:** Expansion of cancer stem cell (CSC) populations demonstrating inherent resistance mechanisms [79] [83].

Experimental Protocols for Generating Osteosarcoma Spheroids

Liquid Overlay Technique Using Agarose-Coated Plates

The liquid overlay technique prevents cell adhesion to the vessel surface, promoting cell aggregation and spheroid formation [78] [79].

Table 2: Protocol for Spheroid Formation via Liquid Overlay

| Step       | Parameter         | Specification                                                          |
|------------|-------------------|------------------------------------------------------------------------|
| 1. Coating | Agarose Solution  | 1.5% (wt/vol) in PBS                                                   |
|            | Coating Volume    | 70 µL per well (96-well plate)                                         |
|            | Key Consideration | Keep solution hot during plating to prevent premature gelatinization   |
|            | Cooling Time      | 20 minutes after plating                                               |
| 2. Seeding | Cell Suspension   | 100 µL added to each coated well                                       |
|            | Cell Density      | Optimization required (e.g., 5.0×10 <sup>5</sup> cells/well for MG-63) |
|            | Medium            | Standard culture medium (e.g., RPMI with 10% FBS)                      |
| 3. Culture | Incubation Time   | 72 hours                                                               |
|            | Conditions        | 37°C, 5% CO <sub>2</sub>                                               |
| 4. Output  | Expected Result   | Compact, multicellular spheroids                                       |

Hanging Drop Technique

The hanging drop technique utilizes gravity to aggregate cells into highly uniform spheroids at the liquid-air interface [81].

Table 3: Protocol for Spheroid Formation via Hanging Drop

| Step                 | Parameter          | Specification                                                 |
|----------------------|--------------------|---------------------------------------------------------------|
| 1. Cell Preparation  | Cell Density       | 1-5×10 <sup>4</sup> cells/mL in standard culture medium       |
|                      | Medium Formulation | May include methylcellulose to enhance aggregation            |
| 2. Droplet Formation | Volume per Drop    | 10-20 µL                                                      |
|                      | Platform           | Inverted lid of culture dish or commercial hanging drop plate |
| 3. Culture           | Incubation Time    | 3-7 days                                                      |
|                      | Conditions         | 37°C, 5% CO <sub>2</sub>                                      |
|                      | Handling           | Avoid disturbance to prevent droplet falling                  |
| 4. Harvesting        | Method             | Pipette carefully to collect spheroids                        |
|                      | Application        | Suitable for high-throughput drug screening                   |

Ultra-Low Attachment (ULA) Plates

Commercially available ULA plates feature covalently bound hydrogel coatings that effectively inhibit cell attachment, enabling spontaneous spheroid formation [78] [79] [82].

Table 4: Protocol for Spheroid Formation via ULA Plates

| Step       | Parameter       | Specification                                                            |
|------------|-----------------|--------------------------------------------------------------------------|
| 1. Seeding | Cell Density    | 5×10 <sup>3</sup> - 2×10 <sup>4</sup> cells/well (96-well plate)         |
|            | Medium          | Serum-free medium supplemented with B27, EGF (10 ng/mL), bFGF (10 ng/mL) |
|            | Centrifugation  | 1000 rpm for 5 minutes (optional, to enhance aggregation)                |
| 2. Culture | Incubation Time | 7-14 days                                                                |
|            | Conditions      | 37°C, 5% CO <sub>2</sub>                                                 |

| Step      | Parameter       | Specification                                     |
|-----------|-----------------|---------------------------------------------------|
|           | Feeding         | Refresh growth factors every 2-3 days             |
| 3. Output | Spheroid Size   | >50 µm after 2 weeks                              |
|           | Characteristics | Compact spheroids with well-defined necrotic core |

### Molecular Mechanisms of Chemoresistance in Osteosarcoma Spheroids

Scaffold-free 3D spheroid models have been instrumental in elucidating key molecular pathways contributing to chemoresistance in osteosarcoma. These mechanisms can be broadly categorized into **cellular reprogramming**, **drug transport alteration**, and **microenvironment-mediated resistance**.




Diagram 1: Resistance mechanisms in OS spheroids.

### Cancer Stem Cell (CSC) Enrichment and Pathway Activation

3D spheroid culture conditions preferentially enrich for CSCs, which exhibit inherent resistance to chemotherapy and contribute to tumor recurrence [79] [83].

- **Stemness Marker Upregulation:** OS spheroids show significant **upregulation of OCT-4, NANOG, and SOX-2** compared to 2D cultures [83]. These transcription factors maintain pluripotency and self-renewal capacity, contributing to therapy resistance.
- **Signaling Pathway Activation:** 3D spheroids demonstrate enhanced activation of **NOTCH-1, HIF-1α, and IL-6** signaling pathways, which regulate CSC/niche communication and promote survival under stress conditions [83].
- **ABC Transporter Overexpression:** CSC-enriched spheroids show increased expression of **P-glycoprotein (PgP) and BCRP pumps** that mediate drug efflux, particularly for doxorubicin, cisplatin, and methotrexate [79].

### Competitive Endogenous RNA (ceRNA) Networks in Chemoresistance

Non-coding RNAs form intricate regulatory networks that significantly influence chemoresistance in osteosarcoma spheroids [84].

Table 5: Non-Coding RNA Networks in Osteosarcoma Chemoresistance

| circRNA/lncRNA | miRNA Sponge | Target Gene/Pathway       | Chemoresistance Outcome                              |
|----------------|--------------|---------------------------|------------------------------------------------------|
| circPVT1       | miR-24-3p    | KLF8 Transcription Factor | Cisplatin, Doxorubicin, Methotrexate resistance [84] |
| circCHI3L1.2   | miR-340-5p   | LPAATβ                    | Cisplatin resistance [84]                            |
| circUBAP2      | miR-506-3p   | SEMA6D / Wnt/β-catenin    | Cisplatin resistance [84]                            |
| hsacirc0004674 | miR-342-3p   | FBN1 / Wnt/β-catenin      | Doxorubicin resistance [84]                          |
| circDOCK1      | miR-137      | IGF1R                     | Cisplatin resistance [84]                            |
| circRNA LARP4  | miR-424      | Unknown                   | Increased sensitivity to Cisplatin, Doxorubicin [84] |

### The Scientist's Toolkit: Essential Research Reagents

Table 6: Key Reagents for Osteosarcoma Spheroid Research

| Reagent/Category        | Example Products                                 | Function/Application                             | Experimental Consideration                                                |
|-------------------------|--------------------------------------------------|--------------------------------------------------|---------------------------------------------------------------------------|
| Low Attachment Plates   | Corning Spheroid Microplates, NanoCulture Plates | Prevent cell adhesion, enable spheroid formation | Well geometry influences spheroid size and uniformity [78] [79]           |
| Extracellular Matrix    | Matrigel, Collagen I, Agarose, Methylcellulose   | Provide structural support, mimic tumor ECM      | Concentration affects spheroid compactness and drug penetration [79] [82] |
| CSC Culture Supplements | B27 Supplement, EGF, bFGF                        | Enrich and maintain cancer stem cell populations | Essential for serial passaging of sarcospheres [79] [83]                  |
| Viability Assays        | ATP-based assays, Calcein-AM/EthD-1 staining     | Assess metabolic activity and viability in 3D    | Penetration efficiency of dyes varies with spheroid density [79]          |

Application in Drug Screening and Therapeutic Development

The physiological relevance of 3D OS spheroids makes them particularly valuable for preclinical drug screening and therapeutic development [78] [81].




Diagram 2: Drug development pipeline using OS spheroids.

Assessing Combination Therapies and Drug Delivery Systems

3D OS spheroid models enable evaluation of combination therapies and novel drug delivery approaches that cannot be adequately studied in 2D systems:

- **Drug-Device Combinations:** Charoen et al. demonstrated that OS spheroids embedded in collagen exhibited differential responses to doxorubicin delivered via expansile nanoparticles compared to bolus administration, findings that correlated well with in vivo results [79].
- **Stromal Co-culture Models:** Advanced tri-culture models incorporating OS spheroids with human osteoblasts and bone marrow mesenchymal stem cells (hBM-MSCs) in human-derived matrices (e.g., PLMA hydrogels) better recapitulate the tumor-stromal interactions that influence drug resistance [82].
- **Overcoming Physical Barriers:** Strategies to disrupt compact spheroid architecture (e.g., targeting integrins α5 and α2) can enhance drug penetration and efficacy [79].

Scaffold-free 3D osteosarcoma spheroid models represent a significant advancement over traditional 2D cultures for studying chemoresistance mechanisms and screening novel therapeutic approaches. These models successfully recapitulate key features of in vivo tumors, including **CSC enrichment, physiological gradients, and complex cell-cell interactions** that drive treatment resistance. The enhanced molecular insights gained from 3D spheroid research, particularly regarding ceRNA networks and signaling pathway activation, provide new opportunities for developing targeted strategies to overcome chemoresistance in osteosarcoma. As these models continue to evolve in complexity through incorporation of stromal components and advanced biomaterials, they hold promise for bridging the gap between conventional drug screening and clinical efficacy, potentially accelerating the development of more effective treatments for this challenging malignancy.

Three-dimensional (3D) cell culture, particularly scaffold-free systems, has emerged as a transformative technology in biomedical research by providing a more physiologically relevant context for studying cell behavior. This application note details how scaffold-free 3D models, such as spheroids and organoids, bridge the critical gap between traditional 2D in vitro data and in vivo outcomes. We present quantitative data validating these models, provide detailed protocols for their implementation in drug development workflows, and visualize the underlying biological mechanisms that enhance their predictive power for clinical efficacy.

In the drug development pipeline, approximately **95% of anticancer drugs that show efficacy in preclinical tests fail clinical trials**, largely due to lack of efficacy and unacceptable toxicity when tested in humans [85]. This high attrition rate is partially attributed to the limitations of traditional two-dimensional (2D) monolayer cell cultures, which do not adequately mimic the natural cellular microenvironment [86]. Scaffold-free 3D cell culture addresses this fundamental limitation by allowing cells to self-assemble into three-dimensional structures, recreating critical aspects

of in vivo tissue architecture, including **cell-cell interactions**, **gradients of nutrients and oxygen**, and **spatial organization** that influences cellular responses to therapeutic agents [86] [28].

Scaffold-free systems generate complex structures such as spheroids and organoids through methods including forced-floating, hanging drop, and agitation-based approaches [28]. These models replicate key pathophysiological features of human tissues more accurately than 2D cultures, enabling more reliable prediction of drug efficacy, safety, and toxicity [15]. The following sections provide quantitative evidence of this correlation, detailed methodologies for implementing these models, and an analysis of the biological mechanisms underlying their enhanced predictive value.

Quantitative Validation: Correlation with Clinical Outcomes

The value of scaffold-free 3D models is demonstrated through their ability to generate data that correlates strongly with clinical responses. The tables below summarize key comparative studies and performance metrics.

Table 1: Predictive Performance of 3D Models in Drug Development

| Cancer Type / Model             | Clinical Correlation Finding                                                           | Impact on Drug Development                                                |
|---------------------------------|----------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| Multiple Myeloma (r-Bone model) | High correlation with clinical response; enables study of tumor microenvironment [85]. | Identifies ineffective compounds early; prioritizes promising candidates. |
| Various Solid Tumors            | 3D models replicate drug resistance patterns observed in patients [15].                | More accurate prediction of chemotherapeutic efficacy and resistance.     |
| Primary Human Hepatocytes       | Maintain hepatic function for >5 weeks vs. rapid dedifferentiation in 2D [87].         | Better prediction of drug metabolism and hepatotoxicity.                  |
| Patient-Derived Organoids       | High predictive accuracy for patient-specific drug responses [88].                     | Facilitates personalized medicine approaches.                             |

Table 2: Comparative Analysis of 2D vs. Scaffold-Free 3D Cell Culture Models

| Parameter                 | 2D Monolayer Culture                             | Scaffold-Free 3D Culture                                         |
|---------------------------|--------------------------------------------------|------------------------------------------------------------------|
| Proliferation Rate        | Usually higher, homogeneous [86]                 | Reduced, more physiologically relevant [86]                      |
| Gene & Protein Expression | Altered, less physiologically relevant [86] [15] | More closely resembles in vivo profiles [86] [15]                |
| Cellular Heterogeneity    | Primarily proliferating cells [86]               | Heterogeneous (proliferating, quiescent, hypoxic, necrotic) [86] |
| Drug Response             | Often overestimates efficacy [85]                | More accurately predicts in vivo resistance [85] [15]            |
| Metabolic Activity        | Uniform nutrient/gas exposure [86]               | Gradient-dependent, mimics in vivo tissue [86]                   |

Experimental Protocols

The following protocols outline standardized methods for establishing scaffold-free 3D models for drug efficacy and toxicity testing.

Protocol: Generating Tumor Spheroids for Drug Efficacy Screening

**Objective:** To create uniform, scaffold-free cancer spheroids for high-throughput screening of anti-cancer compounds.

Materials:

- Nunc Sphera 96-well U-bottom ultra-low attachment plates (Thermo Fisher Scientific) [87] [85]
- Appropriate cell culture medium (e.g., DMEM/F-12 with supplements)
- Cancer cell line of interest (e.g., A549, MDA-MB-231) or patient-derived cells
- Centrifuge with microplate rotors
- Test compounds in DMSO or aqueous solution

Method:

- Cell Preparation:** Harvest and count cells from 2D culture. Prepare a single-cell suspension at a concentration of **1,000 - 10,000 cells per 100 µL**, depending on the desired final spheroid size [85].
- Seeding:** Dispense 100 µL of cell suspension into each well of the U-bottom low-attachment plate.
- Spheroid Formation:** Centrifuge the plate at **500 x g for 10 minutes** to gently pellet cells at the bottom of each well [85].
- Incubation:** Incubate the plate at **37°C, 5% CO2 for 72-96 hours** to allow for spheroid formation and maturation.

- **Drug Treatment:**
  - Prepare serial dilutions of test compounds in pre-warmed culture medium.
  - After spheroid formation, carefully aspirate 50 µL of spent medium from each well.
  - Add 50 µL of 2x concentrated drug solution to achieve the desired final concentration.
- **Viability Assessment (at 72-120 hours post-treatment):**
  - Assess spheroid viability using assays such as CellTiter-Glo 3D.
  - Image spheroids using brightfield or confocal microscopy to monitor morphology and size.

### Protocol: Establishing a Primary Human Hepatocyte 3D Model for Toxicity Screening

**Objective:** To create functional human hepatocyte spheroids for predicting drug-induced liver injury (DILI) and studying drug metabolism.

#### Materials:

- Primary Human Hepatocytes (PHH) (e.g., Gibco)
- Hepatocyte culture medium (e.g., Williams' E Medium with supplements)
- Nunclon Sphera 96-well U-bottom plates [\[87\]](#)
- Collagen I, Matrigel (optional for overlay)


#### Method:

- **Thawing and Viability Check:** Rapidly thaw cryopreserved PHH and determine viability via trypan blue exclusion. Use only preparations with >80% viability.
- **Cell Seeding:** Prepare a suspension of **1.5 x 10<sup>5</sup> cells/mL** in complete hepatocyte medium. Dispense 100 µL/well (~15,000 cells/well) into the U-bottom plate [\[87\]](#).
- **Spheroid Formation:** Centrifuge the plate at **400 x g for 10 minutes**. Incubate at **37°C, 5% CO<sub>2</sub>**.
- **Long-term Maintenance:** Observe spheroid formation over 3-5 days. Change **50% of the medium every 48-72 hours** without disturbing the spheroids.
- **Functional Validation (Day 7):**
  - Measure albumin secretion (ELISA) and urea production (colorimetric assay) to confirm hepatic function.
  - Analyze expression of key ADME genes (e.g., CYP450 isoforms) using QuantiGene Plex Assay [\[87\]](#).
- **Compound Testing:** Expose spheroids to test compounds for 7-14 days. Monitor cytotoxicity (LDH release), metabolic activity (ATP content), and specific organ-level toxicity markers.

### Visualizing the Workflow and Biological Mechanisms


#### Experimental Workflow for Predictive Drug Screening





**Diagram 1: Drug Screening Workflow.** This workflow outlines the key steps from 3D model establishment to data integration for clinical prediction.

**Biological Mechanisms Underlying Enhanced Predictive Power**



**Diagram 2: Mechanism of Clinical Prediction.** Core physiological features of 3D models (red) drive their ability to accurately predict clinical outcomes (green).

**The Scientist's Toolkit: Essential Research Reagents**

Table 3: Key Reagent Solutions for Scaffold-Free 3D Cell Culture

| Product Category            | Specific Examples                                         | Function & Application                                                              |
|-----------------------------|-----------------------------------------------------------|-------------------------------------------------------------------------------------|
| Ultra-Low Attachment Plates | Nunc Sphera (Thermo Fisher), Elplasia (Corning) [88] [87] | Promotes cell self-assembly into spheroids by inhibiting surface attachment.        |
| Specialized Culture Media   | Gibco 3D Culture Media, B-27 Supplements [87]             | Provides optimized nutrients and factors for maintaining 3D structure and function. |
| Hydrogels/ECM               | Geltrex, Cultrex BME (for embedding) [87]                 | Provides a physiological 3D microenvironment for certain organoid cultures.         |

| Product Category         | Specific Examples          | Function & Application                                                                 |
|--------------------------|----------------------------|----------------------------------------------------------------------------------------|
| Viability Assays         | CellTiter-Glo 3D [87]      | Quantifies ATP levels, optimized for penetration and detection in 3D structures.       |
| Gene Expression Analysis | QuantiGene Plex Assay [87] | Enables multiplexed analysis of ADME and toxicity-related genes directly from lysates. |

Scaffold-free 3D cell culture represents a paradigm shift in preclinical research, effectively bridging the translational gap between traditional in vitro models and clinical outcomes. By recapitulating critical aspects of human physiology, including tissue architecture, cellular heterogeneity, and metabolic functionality, these models provide a more reliable platform for evaluating drug efficacy, toxicity, and mechanisms of action. The standardized protocols and analytical frameworks presented herein provide researchers with practical tools to leverage this advanced technology, ultimately contributing to more efficient drug development and a higher success rate in clinical trials.

## Conclusion

Scaffold-free 3D cell culture represents a paradigm shift in biomedical research, offering a profoundly more physiologically relevant platform than traditional 2D monolayers. By enabling the self-assembly of cells into complex structures that accurately mimic in vivo conditions, this technology provides unparalleled insights into disease mechanisms, drug responses, and tissue regeneration. While challenges in standardization and scalability persist, ongoing innovations in automation, assay development, and the integration of AI are rapidly addressing these hurdles. The future of scaffold-free systems lies in their continued integration into tiered drug discovery workflows, their pivotal role in advancing personalized medicine through patient-derived organoids, and their growing acceptance by regulatory bodies, ultimately accelerating the translation of laboratory findings into successful clinical therapies.

## References

1. Understanding the 3 Revolution | The Scientist D Cell Culture [https://www.the-scientist.com/understanding-the-3d-cell-culture-revolution-71786]
2. What is Scaffold ? Uses, How It Works & Top... Free 3 D Cell Culture [https://www.linkedin.com/pulse/what-scaffold-free-3d-cell-culture-uses-how-dh8cc]
3. Market Outlook Scaffold -2032 Free 3 D Cell Culture 2025.[https://www.intelmarketresearch.com/scaffold-free-d-cell-culture-market-14531]
4. : Techniques, 3., Models, and D Cell Culture Protocol Applications [https://cancerbiologyresearch.com/3d-cell-culture-techniquesprotocol-models-and-applications/]
5. Tools and Techniques 3 D Cell Culture [https://www.sigmaaldrich.com/IN/en/technical-documents/technical-article/cell-culture-and-cell-culture-analysis/3d-cell-culture/3d-cell-culture-technology]
6. Market Size - Growth Report 2035 Scaffold Free 3 D Cell Culture [https://www.researchnester.com/reports/scaffold-free-3d-cell-culture-market/3934]
7. -based Scaffold models in cancer research | Journal of... 3 D cell culture [https://jbiomedsci.biomedcentral.com/articles/10.1186/s12929-024-00994-y]
8. - Scaffold Sheet Technique Analysis Report Free : Market... 3 D Cell 2025.[https://www.datainsightsmarket.com/reports/scaffold-free-3d-cell-sheet-technique-1733487]
9. Market Scenario Analysis with... Scaffold Free 3 d Cell Culture [https://www.linkedin.com/pulse/scaffold-free-3d-cell-culture-market-scenario-yaule]
10. - Scaffold -based free engineering therapies: advances... cell tissue [https://www.nature.com/articles/s41536-021-00133-3?error=cookies\_not\_supported&code=1a7a55f2-6cf1-4af7-8ebb-e75e7f390a81]
11. - Scaffold systems for stem free -based 3 ... D culture cell tissue [https://pmc.ncbi.nlm.nih.gov/articles/PMC11446583/]
12. Systems: Tumor Application, 3., and... D Cell Culture Advantages [https://pmc.ncbi.nlm.nih.gov/articles/PMC8618305/]
13. In Vivo-Like Scaffold - Free In Vitro Models of Muscular Dystrophies... 3 D [https://pmc.ncbi.nlm.nih.gov/articles/PMC12057609/]
14. Frontiers | Bridging the gap: the role of 3 in mimicking... D cell cultures [https://www.frontiersin.org/journals/bioengineering-and-biotechnology/articles/10.3389/fbioe.2025.1498141/full]
15. Tools and Techniques 3 D Cell Culture [https://www.sigmaaldrich.com/US/en/technical-documents/technical-article/cell-culture-and-cell-culture-analysis/3d-cell-culture/3d-cell-culture-technology]
16. - Scaffold - Free Sheet Technique Bridges the Gap between... 3 D Cell [https://pubmed.ncbi.nlm.nih.gov/31590325/]
17. to generate Protocol - scaffold , multicomponent free melanoma... 3 D [https://pmc.ncbi.nlm.nih.gov/articles/PMC11109877/]
18. Frontiers | Three-Dimensional in Vitro Cell Models in Culture ... Drug [https://www.frontiersin.org/journals/pharmacology/articles/10.3389/fphar.2018.00006/full]
19. Tools and Techniques 3 D Cell Culture [https://www.sigmaaldrich.com/NI/es/technical-documents/technical-article/cell-culture-and-cell-culture-analysis/3d-cell-culture/3d-cell-culture-technology]

- [20. Three-Dimensional Cell in Cultures Discovery and... Drug](https://pmc.ncbi.nlm.nih.gov/articles/PMC5448717/) [https://pmc.ncbi.nlm.nih.gov/articles/PMC5448717/]
- [21. of Applications in 3 Discovery D Cell Culture Drug](https://www.linkedin.com/pulse/applications-3d-cell-culture-drug-discovery-pppcf/) [https://www.linkedin.com/pulse/applications-3d-cell-culture-drug-discovery-pppcf/]
- [22. What are Spheroids .3D Spheroids Models | Molecular Devices](https://www.moleculardevices.com/applications/3d-cell-models/spheroids) [https://www.moleculardevices.com/applications/3d-cell-models/spheroids]
- [23. and manipulation of cell Formation using a density... spheroids](https://www.nature.com/articles/srep11891?error=cookies_not_supported&code=d4675b71-b018-4c16-9dbb-d83b0417a1f2) [https://www.nature.com/articles/srep11891?error=cookies\_not\_supported&code=d4675b71-b018-4c16-9dbb-d83b0417a1f2]
- [24. - Wikipedia Organoid](https://en.wikipedia.org/wiki/Organoid) [https://en.wikipedia.org/wiki/Organoid]
- [25. Trends: 2025 Organoids](https://www.genengnews.com/topics/genome-editing/2025-trends-organoids/) [https://www.genengnews.com/topics/genome-editing/2025-trends-organoids/]
- [26. Comparative Analysis of Ascorbic Acid-Induced Cell ... Sheet Formation](https://bmrat.org/index.php/BMRAT/article/view/1018) [https://bmrat.org/index.php/BMRAT/article/view/1018]
- [27. Serum-free endothelial cell culture medium for vascular smooth muscle...](https://pmc.ncbi.nlm.nih.gov/articles/PMC12121044/) [https://pmc.ncbi.nlm.nih.gov/articles/PMC12121044/]
- [28. : Optimizing Your Research 3 - Elvetflow D Cell Culture Methods](https://elvetflow.com/microfluidic-reviews/3d-cell-culture-methods-and-applications-a-short-review/) [https://elvetflow.com/microfluidic-reviews/3d-cell-culture-methods-and-applications-a-short-review/]
- [29. Vascularization Strategies in 3 Models: From... D Cell Culture](https://pmc.ncbi.nlm.nih.gov/articles/PMC9737506/) [https://pmc.ncbi.nlm.nih.gov/articles/PMC9737506/]
- [30. What are the scaffold - free of growing methods ? 3 D cell cultures](https://www.aatbio.com/resources/faq-frequently-asked-questions/What-are-the-scaffold-free-methods-of-growing-3D-cell-cultures) [https://www.aatbio.com/resources/faq-frequently-asked-questions/What-are-the-scaffold-free-methods-of-growing-3D-cell-cultures]
- [31. A simple hanging for generation of... drop cell culture protocol](https://pubmed.ncbi.nlm.nih.gov/21587162/) [https://pubmed.ncbi.nlm.nih.gov/21587162/]
- [32. Three-Dimensional \(.3.\) in vitro D to... | PLOS One cell culture protocols](https://journals.plos.org/plosone/article?id=10.1371/journal.pone.0276248) [https://journals.plos.org/plosone/article?id=10.1371/journal.pone.0276248]
- [33. Principles of Hanging \(Spheroid Formation\) in Drop ... Method Cell](https://link.springer.com/protocol/10.1007/7651_2024_527) [https://link.springer.com/protocol/10.1007/7651\_2024\_527]
- [34. 96 well plates and development of 3 ... D cultures](https://facellitate.com/3d-cell-culture-development/) [https://facellitate.com/3d-cell-culture-development/]
- [35. Recent development of temperature- responsive surfaces and their...](https://pmc.ncbi.nlm.nih.gov/articles/PMC4669004/) [https://pmc.ncbi.nlm.nih.gov/articles/PMC4669004/]
- [36. An efficient method for cell bioengineering from rBMSCs on... sheet](https://jbioleng.biomedcentral.com/articles/10.1186/s13036-023-00346-8) [https://jbioleng.biomedcentral.com/articles/10.1186/s13036-023-00346-8]
- [37. 15 Years of Magnetic : From 3 to... D Cell Culture Magnetic Levitation](https://eusci.org.uk/2025/09/22/15-years-of-magnetic-3d-cell-culture-from-magnetic-levitation-to-fda-endorsed-new-approach-methodologies/) [https://eusci.org.uk/2025/09/22/15-years-of-magnetic-3d-cell-culture-from-magnetic-levitation-to-fda-endorsed-new-approach-methodologies/]
- [38. \(PDF\) Three-dimensional cell culturing by magnetic levitation](https://www.academia.edu/92775300/Three_dimensional_cell_culturing_by_magnetic_levitation) [https://www.academia.edu/92775300/Three\_dimensional\_cell\_culturing\_by\_magnetic\_levitation]
- [39. Ring Magnet -Guided Magnetic Manipulation for Biofabrication of...](https://pubmed.ncbi.nlm.nih.gov/39776076/) [https://pubmed.ncbi.nlm.nih.gov/39776076/]
- [40. Frontiers | Development of a biomimetic thyroid acellular scaffold as...](https://www.frontiersin.org/journals/bioengineering-and-biotechnology/articles/10.3389/fbioe.2025.1692549/full) [https://www.frontiersin.org/journals/bioengineering-and-biotechnology/articles/10.3389/fbioe.2025.1692549/full]
- [41. Recent advances in 3 cancer D ... cell culture models in drug](https://link.springer.com/article/10.1007/s40005-025-00740-y) [https://link.springer.com/article/10.1007/s40005-025-00740-y]
- [42. Comparison of EMT-Related and Multi- Drug Resistant Gene...](https://pubmed.ncbi.nlm.nih.gov/36362093/) [https://pubmed.ncbi.nlm.nih.gov/36362093/]
- [43. Tools and 3 D Cell Culture Techniques](https://www.sigmaaldrich.com/GU/en/technical-documents/technical-article/cell-culture-and-cell-culture-analysis/3d-cell-culture/3d-cell-culture-technology) [https://www.sigmaaldrich.com/GU/en/technical-documents/technical-article/cell-culture-and-cell-culture-analysis/3d-cell-culture/3d-cell-culture-technology]
- [44. for 3 resistance and screening development in... D tumor cultures drug](https://molecular-cancer.biomedcentral.com/articles/10.1186/s12943-025-02281-2) [https://molecular-cancer.biomedcentral.com/articles/10.1186/s12943-025-02281-2]
- [45. A three -dimensional collagen scaffold ... | Oncotarget cell culture](https://www.oncotarget.com/article/10885/text/) [https://www.oncotarget.com/article/10885/text/]
- [46. Global Scaffold Market Insights: Free ... 3 D Cell Culture Applications](https://www.linkedin.com/pulse/global-scaffold-free-3d-cell-culture-market-insights-applications-skrhe) [https://www.linkedin.com/pulse/global-scaffold-free-3d-cell-culture-market-insights-applications-skrhe]
- [47. Therapeutic strategies of three-dimensional stem cell spheroids and...](https://pubmed.ncbi.nlm.nih.gov/35441116/) [https://pubmed.ncbi.nlm.nih.gov/35441116/]
- [48. Activating the healing process: three-dimensional culture of stem cells ...](https://bmcbiotechnol.biomedcentral.com/articles/10.1186/s12896-024-00862-5) [https://bmcbiotechnol.biomedcentral.com/articles/10.1186/s12896-024-00862-5]
- [49. Systems for Cardiovascular Tissue Engineering: In... 3 D Cell Culture](https://www.frontiersin.org/research-topics/12897/3d-cell-culture-systems-for-cardiovascular-tissue-engineering-in-vitro-modelling-and-in-vivo-regenerative-therapies/magazine) [https://www.frontiersin.org/research-topics/12897/3d-cell-culture-systems-for-cardiovascular-tissue-engineering-in-vitro-modelling-and-in-vivo-regenerative-therapies/magazine]
- [50. Technologies Patent Landscape Report 3 D Cell Culture](https://www.expertmarketresearch.com/patent-analysis/3d-cell-culture-technologies-patent-landscape) [https://www.expertmarketresearch.com/patent-analysis/3d-cell-culture-technologies-patent-landscape]
- [51. Models as Recapitulators of the Tumor... 3 D Cell Culture](https://pmc.ncbi.nlm.nih.gov/articles/PMC8749977/) [https://pmc.ncbi.nlm.nih.gov/articles/PMC8749977/]
- [52. Unlocking the Potential of 3 : a Guide to d ... Cell Culture Assay](https://www.aatbio.com/resources/assaywise/2023-12-1/unlocking-the-potential-of-3d-cell-culture-a-guide-to-assay-optimization) [https://www.aatbio.com/resources/assaywise/2023-12-1/unlocking-the-potential-of-3d-cell-culture-a-guide-to-assay-optimization]
- [53. - High Using Throughput - 3 Spheroids... D Cell Screening Scaffold Free](https://www.moleculardevices.com/en/assets/app-note/dd/img/high-throughput-screening-of-3d-cell-cultures-with-multiple-high-density-scaffold-free-spheroids-for-study-of-cancer-toxicity) [https://www.moleculardevices.com/en/assets/app-note/dd/img/high-throughput-screening-of-3d-cell-cultures-with-multiple-high-density-scaffold-free-spheroids-for-study-of-cancer-toxicity]
- [54. Status and Future of 3 in Toxicity Testing D Cell Culture](https://experiments.springernature.com/articles/10.1007/978-1-4939-7677-5_12?error=cookies_not_supported&code=ae7dcea4-7175-49b0-bc09-440b28eee45b) [https://experiments.springernature.com/articles/10.1007/978-1-4939-7677-5\_12?error=cookies\_not\_supported&code=ae7dcea4-7175-49b0-bc09-440b28eee45b]
- [55. Drug Efficacy Testing in Cancer Research Using Optimizing ... 3 D Cell](https://www.labmanager.com/optimizing-drug-efficacy-testing-in-cancer-research-using-3d-cell-culture-automation-32265) [https://www.labmanager.com/optimizing-drug-efficacy-testing-in-cancer-research-using-3d-cell-culture-automation-32265]
- [56. Making Complex Cell Easy and Efficient with AI Culture](https://www.news-medical.net/news/20250312/Making-Complex-Cell-Culture-Easy-and-Efficient-with-AI.aspx) [https://www.news-medical.net/news/20250312/Making-Complex-Cell-Culture-Easy-and-Efficient-with-AI.aspx]

- 57. qHTSWaterfall: 3-dimensional visualization software for quantitative ... [https://jcheminf.biomedcentral.com/articles/10.1186/s13321-023-00717-9]
- 58. Fabrication of Cell for Spheroids and Biomedical... 3 D Cell Culture [https://link.springer.com/article/10.1007/s13206-022-00086-9]
- 59. - Scaffold development of multicellular tumor free with... spheroids [https://pmc.ncbi.nlm.nih.gov/articles/PMC11637012/]
- 60. Optimize Microplate Assay for Protocols Cultures Spheroid [https://www.thermofisher.com/kr/en/home/references/newsletters-and-journals/biopros-journal-of-cell-biology-applications/biopros-81/optimize-microplate-assays-3d-spheroid-cultures.html]
- 61. A Pillar/Perfusion Plate Enhances Cell Growth, Reproducibility ... [https://pubmed.ncbi.nlm.nih.gov/38695610/]
- 62. Towards Label-Free Standardization in 3 : Automated... d Cell Culture [https://pubmed.ncbi.nlm.nih.gov/38265410/]
- 63. - Scaffold systems for stem free -based 3 ... D culture cell tissue [https://pubmed.ncbi.nlm.nih.gov/39364211/]
- 64. enhance the production of large lipid-enriched... ROCK inhibitors [https://pmc.ncbi.nlm.nih.gov/articles/PMC7943807/]
- 65. Development of Novel ROCK via Inhibitors -QSAR and Molecular... 3 D [https://pmc.ncbi.nlm.nih.gov/articles/PMC11514586/]
- 66. Tips To 3 Your Workflow | Technology Networks D Cell Culture Optimize [https://www.technologynetworks.com/cell-science/how-to-guides/3d-cell-culture-tips-to-optimize-your-workflow-398326]
- 67. The Future of Scaffold Product: The latest trends... free Cell Culture [https://www.linkedin.com/pulse/future-scaffold-free-cell-culture-product-latest-trends-development-ykize]
- 68. What is Industrial ? Uses, How It Works & Top... Bioreactors [https://www.linkedin.com/pulse/what-industrial-bioreactors-uses-how-works-top-companies-2025-pmnkf]
- 69. and 2 D 3 D Cell Culture Comparison [https://www.news-medical.net/life-sciences/2D-and-3D-Cell-Culture-Comparison.aspx]
- 70. vs 3 : Which Model Suits Your Lab in D ? 2 D Cell Culture 2025 [https://www.pharmanow.live/knowledge-hub/research/3d-vs-2d-cell-culture-comparison]
- 71. Comparative Assay of 2 and D Models: 3 ... D Cell Culture Proliferation [https://pubmed.ncbi.nlm.nih.gov/29623827/]
- 72. Comparative analysis between 2 and D colorectal cancer 3 ... D culture [https://www.nature.com/articles/s41598-023-45144-w?error=cookies\_not\_supported&code=coabe4a9-4bf6-4552-9061-d954c1833602]
- 73. The effect of 2 and D on treatment 3., EMT... D cell cultures response [https://cancerbi.biomedcentral.com/articles/10.1186/s12935-019-0733-1]
- 74. How do cells in cultured and 2 differ? - Eppendorf US D 3 D [https://www.eppendorf.com/us-en/lab-academy/life-science/cell-biology/how-do-cells-cultured-in-2d-and-3d-differ-a-dimension-shift/]
- 75. Advancing 3 Cell D : Methods, Applications & Future Trends Culture [https://gmpplastic.com/blogs/useful-articles-on-lab-supplies-faq-section/advancing-3d-cell-culture-methods-applications-future-trends]
- 76. Opportunities in Scaffold - based Market 3 -2033 D Cell Culture 2025 [https://www.datainsightsmarket.com/reports/scaffold-based-3d-cell-culture-1742095]
- 77. Hydrogels as Extracellular Matrix Mimics for 3 Cell D - PMC Culture [https://pmc.ncbi.nlm.nih.gov/articles/PMC2997742/]
- 78. Relevance of 3d culture systems to study osteosarcoma environment - PMC [https://pmc.ncbi.nlm.nih.gov/articles/PMC5756329/]
- 79. Relevance of 3 systems to study d environment culture osteosarcoma [https://jeccr.biomedcentral.com/articles/10.1186/s13046-017-0663-5]
- 80. Targeting Molecular Mechanisms Underlying Treatment Efficacy and... [https://pmc.ncbi.nlm.nih.gov/articles/PMC7555161/]
- 81. In vitro three-dimensional cell cultures for bone sarcomas - PMC [https://pmc.ncbi.nlm.nih.gov/articles/PMC8287221/]
- 82. Bioengineering a humanized 3D tri-culture osteosarcoma model to assess tumor invasiveness and therapy response - ScienceDirect [https://www.sciencedirect.com/science/article/abs/pii/S1742706121004724]
- 83. Scaffold-based 3D cellular models mimicking the heterogeneity of osteosarcoma stem cell niche | Scientific Reports [https://www.nature.com/articles/s41598-020-79448-y]
- 84. Competitive endogenous network of circRNA, lncRNA, and miRNA in... [https://eurjmedres.biomedcentral.com/articles/10.1186/s40001-023-01309-x]
- 85. Unlocking the Potential of 3 Technology | Labcorp D Cell Culture [https://www.labcorp.com/biopharma/nonclinical/therapeutics/oncology/in-vitro/cell-culture/3d]
- 86. Three-Dimensional Cell Systems and Their Applications in... Culture [https://pmc.ncbi.nlm.nih.gov/articles/PMC4026212/]
- 87. | Thermo Fisher Scientific - US 3 D Cell Culture Applications [https://www.thermofisher.com/us/en/home/life-science/cell-culture/cell-culture-learning-center/3d-culture-analysis-products-protocols-methods/3d-research-application-resources.html]
- 88. 3d Cell Culture Market: Comprehensive Analysis and Forecast (2025–2035) - PharmiWeb.com [https://www.pharmiweb.com/press-release/2025-02-12/3d-cell-culture-market-comprehensive-analysis-and-forecast-2025-2035]