## A Guide To LiPo Batteries

And Chargers!

#### What LiPo Batteries actually are?

**Lithium Polymer** batteries are a newer type of battery now used in many consumer electronics devices.



#### **General Purpose LiPo Batteries**








**7.4V** 

**11.1V** 

14.8V

#### All about LiPo Battery Rating



#### Nominal Voltage of a Cell

 LiPo batteries are fully charged when they reach 4.2v/cell.

• Their minimum safe charge, is 3.0v/cell.

 3.7v is pretty much in the middle, and that is the nominal charge of the cell.

#### **Voltage / Cell Count**

- A LiPo cell has a nominal voltage of 3.7V.
- **3S** Means 3 Cell in Series = **3.7** + **3.7** + **3.7** = **11.1V**
- **3S1P** Means 3 Cells in **S**eries and 1 Cell in **P**arallel = 3X1 = 3 Cells In Total = **3.7** + **3.7** + **3.7** = **11.1V**
- **3S2P** Means 3 Cells in **S**eries and 2 Cells in **P**arallel = 3X2 = 6 Cells in Total = **3.7** + **3.7** + **3.7** = **11.1V**

# Question

# What does 2P2S mean?

# Answer

# 2 Series 2 Parallel

**7.4V** 

**Next Parameter: CAPACITY** 

Capacity means how much power the battery can hold. Obviously!

1000mAh = 1 Amp Hour (1Ah)

#### **Discharge Rating: C Rating**

The C Rating is simply a measure of how fast the battery can be discharged safely and without harming the battery.

#### **C Rating Continued**



$$50C = 50 \times Capacity (in Amps)$$

Calculating the C-Rating of our example battery:

 $50 \times 5 = 250A$ 

#### **Charging of a LiPo Battery**

They charge using a system called **CC/CV** charging. It stands for **C**onstant **C**urrent / **C**onstant **V**oltage.

The safest charge rate for most LiPo batteries is

| 1C, or 1 X capacity of battery in Amps

#### **iMAX B6 Battery Charger**



- Supports Up To 6 Cells
- Ensures maximum safety

# Charging A LiPo Using iMAX B6

- Connect the plugs to the iMAX B6 First [Connect the battery last] (Yellow part)
- Then connect the LiPo Charging leads with the charger's. (Red part)
- Connect the balance plugs. (Green part)




- Turn on the charger
- Select LiPo from the option, set Balance Charging.
- Select Rating according to the connected LiPo
- Press and Hold ENTER for 3 seconds to enable charging prompt.
- Press **ENTER** again to start charging



# Charger will beep 3\* times upon completion.

Disconnect everything in the reverse order.



### **Troubleshooting**

- Sometimes LiPo might be discharged to below 3V then the iMAX B6 will refuse to charge.
- The workaround for that is to charge it using NiMH charging method.
  - Check out the video.

#### **DON'Ts**

DISCHARGE THE LIPO THROUGH BALANCE PORTS




DISCHARGE THE LIPO UNDER 3.0V PER CELL

#### **DON'Ts**

- GO AWAY WHILE THE LIPO IS BEING CHARGED.
- SHORT THE LIPO
- LEFT UNUSED FOR A LONG TIME
- UNPACK THE LIPO (LIPO CAN CARRY HIGH AMOUNT OF CHARGE EVEN AFTER BEING DESTROYED)

#### **DOs**

• MAKE SAFE CONNECTORS BY SOLDERING T/DEAN CONNECTOR



#### **DOs**

- USE THE LIPO EVERY NOW AND THEN
- DISPOSE THE LIPO PROPERLY IF IT DOESN'T WORK ANYMORE
- KEEP PACKED WHEN NOT USING

#### Reference

Best lipo guide:

https://rogershobbycenter.com/lipoguide/

Charging Discharging Safety:

https://www.maxamps.com/lipo-care.php

Official iMAX B6 Manual:

http://www.skyrc.com/download/IMAX\_B6\_Manual.pdf.80 80e517a1de969503f0992b5b056363