
(1) Draw and explain the internal architecture of 8085.

- The architecture of 8085 Microprocessor is shown in figure given below. The internal architecture of 8085 includes following section
 - ALU-Arithmetic and Logic unit
 - Timing and control unit
 - Instruction register and decoder,
 - Register array,
 - Interrupt control and serial I/O control.



ALU:-

- The ALU performs the arithmetic and logical operations.
- The operations performed by ALU of 8085 are addition, subtraction, increment, decrement, logical AND, OR, EXCLUSIVE -OR, compare, complement and left / right shift.
- The accumulator and temporary register are used to hold the data during an arithmetic / logical operation.
- After an operation the result is stored in the accumulator and the flags are set or reset according to the result of the operation.

TIMING & CONTROL UNIT:

• The timing and control unit synchronizes all the microprocessor operations with the clock and generates the control signals necessary for communication between the microprocessor and peripherals.

INSTRUCTION REGISTER & DECODER:

 When an instruction is fetched from memory it is placed in instruction register. Then it is decoded and encoded into various machine cycles.

REGISTER ARRAY:

- Apart from Accumulator (A-register), there are six general-purpose programmable registers B, C, D, E,
 H and L. They can be used as 8-bit registers or paired to store l6-bit data. The allowed pairs are B-C,D-E
 and H-L.
- The temporary registers W and Z are intended for internal use of the processor and it cannot be used by the programmer.

STACK POINTER (SP):

 The stack pointer SP holds the address of the stack top. The stack is a reserved portion of memory where information can be stored or taken back.

PROGRAM COUNTER (PC):

- The program counter (PC) keeps track of program execution.
- It holds the address of program memory.
- To execute a program the starting address of the program is loaded in program counter.
- The PC sends out an address to fetch a byte of instruction from memory and increment its content automatically. Hence, when a byte of instruction is fetched, the PC holds the address of the next byte of the instruction or next instruction.

INTERRUPT CONTROL:

• interrupt control provide control for following interrupt INT, INTA, RST5.5, RST6.5, RST7.5, TRAP

SERIAL I/O CONTROL:


- IT provide two pin for serial communication SOD-Serial output data and SID-Serial input data
- (2) Draw the PIN DIAGRAM of 8085 & explain the detail of each pin OR Draw & explain 8085 Pin out signals OR Explain function of HOLD and HLDA pin in brief OR List the function of flowing pins of 8085 (i) ALE, (ii) CLK (iii) Ready OR List the interrupt pins of 8085.

X1 & X2

• These are also called Crystal Input Pins. To generate clock signals internally, 8085 requires external inputs from X1 and X2.

RESET IN:

- It is used to reset the microprocessor. It is active low signal. When the signal on this pin is low (for at least 3 clocking cycles), it forces the microprocessor to reset itself.
- Resetting the microprocessor means:
 - Clearing the PC and IR.
 - o Disabling all interrupts (except TRAP).
 - o Disabling the SOD pin.
 - o All the buses (data, address, control) are *tristated*. Gives HIGH output to RESET OUT pin.



RESET OUT:

o It is an output signal. It is an active high signal. The output on this pin goes high whenever RESET IN is given low signal. This signal used to indicate that microprocessor is reset.

SID (Serial Input Data):

o It takes 1 bit input from serial port of 8085 and Stores the bit at the 8th position (MSB) of the Accumulator.RIM (Read Interrupt Mask) instruction is used to transfer the bit.

SOD (Serial Output Data):

It takes 1 bit from the 8th position (MSB) of the Accumulator to serial port of 8085. SIM (Set Interrupt Mask) instruction is used to transfer the bit.

Interrupt Pin:

1. TRAP:-

- o It is a non-maskable interrupt.
- o It has the highest priority.
- o It cannot be disabled.
- o It is both edge and level triggered.
- o It means TRAP signal must go from low to high and must remain high for a certain period of time.
- o TRAP is usually used for power failure and emergency shutoff.

2. RST 7.5:-

- o It is a maskable interrupt.
- It has the second highest priority.
- It is positive edge triggered only.
- o The internal flip-flop is triggered by the rising edge.
- o The flip-flop remains high until it is cleared by RESET IN.

3. RST 6.5:-

- o It is a maskable interrupt.
- It has the third highest priority.
- It is level triggered only.
- o The pin has to be held high for a specific period of time.RST 6.5 can be enabled by EI instruction.
- It can be disabled by DI instruction.

4. RST 5.5:-

- It is a maskable interrupt.
- It has the fourth highest priority.
- It is also level triggered.
- o The pin has to be held high for a specific period of time.
- o This interrupt is very similar to RST 6.5.

5. INTR:-

- o It is a maskable interrupt.
- It has the lowest priority.
- It is also level triggered.
- It is a general purpose interrupt. By general purpose we mean that it can be used to vector microprocessor to any specific subroutine having any address.

INTA:

It stands for interrupt acknowledge. It is an outgoing signal. It is an active low signal. Low output on this pin indicates that microprocessor has acknowledged the INTR request.

Address and Data Pins

AD0 – AD7:- (Bidirectional)

- These pins have dual purpose of transmitting lower order address and data byte.
- During 1st clock cycle, these pins act as lower half of address.
- In remaining clock cycles, these pins act as data bus.
- The separation of lower order address and data is done by address latch.

A8 – A15:-(Unidirectional)

• These pins carry the higher order of address bus. The address is sent from microprocessor to memory.

ALE:- (Output)

- It is used to enable Address Latch.
- It indicates whether bus functions as address bus or data bus.
- If ALE = 1 then Bus functions as address bus.
- If ALE = 0 then Bus functions as data bus.

S0 and S1 :-(output)

S0 and S1 are called Status Pins. They tell the current operation which is in progress in 8085.

S0	S1	Operation		
0	0	Halt		
0	1	Write		
1	0	Read		
1	1	Opcode		

IO/M:-

- This pin tells whether I/O or memory operation is being performed. If IO/M = 1 then I/O operation is being performed.
- If IO/M = 0 then Memory operation is being performed.

RD:

- RD stands for Read.
- It is an active low signal.
- It is a control signal used for Read operation either from memory or from Input device.
- A low signal indicates that data on the data bus must be placed either from selected memory location or from input device.

WR:

- WR stands for Write.
- It is also active low signal.
- It is a control signal used for Write operation either into memory or into output device.
- A low signal indicates that data on the data bus must be written into selected memory location or into output device.

READY:-

This pin is used to synchronize slower peripheral devices with fast microprocessor

HOLD:-

- HOLD pin is used to request the microprocessor for DMA transfer.
- A high signal on this pin is a request to microprocessor to come off from the hold on buses. This request
 is sent by DMA controller.

HLDA:-


- HLDA stands for Hold Acknowledge.
- The microprocessor uses this pin to acknowledge the receipt of HOLD signal.
- When HLDA signal goes high, address bus, data bus, \overline{RD} , \overline{WR} , $\overline{IO/M}$ pins are *tri-stated*. This means they are cut-off from external environment. The control of these buses goes to DMA Controller.

VSS and VCC:-

• +5V power supply is connected to VCC. Ground signal is connected to VSS.

(3) Explain how to demultiplex address from multiplex address/Data line. OR Describe Demultiplexed address data bus and control signals.

- ➤ AD0- AD7 lines are use for dual purpose i.e. Address bus and Data bus and they need to be demultiplexed to get all the information.
- The high order bits of the address remain on the bus for three clock periods. However, the low order bits remain for only one clock period and they would be lost if they are not saved externally.
- To make sure we have the entire address for the full three clock cycles, we will use an external latch to save the value of AD7–AD0 when it is carrying the address bits. We use the ALE signal to enable this latch.
- ➤ The address AD7 –AD0 is connected as inputs to the latch 74LS373.
- ➤ The ALE signal is connected to the enable (G) pin of the latch and the OC –Output control –of the latch is grounded
- ➤ ALE operates as a pulse during T1, when this signal goes low, the address is saved and the AD7-AD0 lines can be used for data bus



(4) Explain flag register of 8085.

- Flag is flip-flops that indicate some condition produce by the arithmetic and logical instruction. This flip-flop can set or reset according to the result of an operation.
- These flags are Zero (Z), Carry (CY), Sign (S), Parity (P), and Auxiliary Carry (AC) flags.
- > The bit position for the flags in flag register is,

D7	D6	D5	D4	D3	D2	D1	D0
S	Z	X	AC	X	P	X	CY

Sign Flag:- this flag is set when sign is negative and reset when sign is positive.

Zero Flag:-This flag is set if result obtained after an operation is 0.and Reset if Result is non Zero.

Carry Flag:-This flag is set if there is a carry or borrow from arithmetic operation.

Auxiliary Carry Flag: -This flag is set if there is a carry out of bit 3.


Parity Flag:-This flag is set if parity is even (even numbers of 1s) and reset if parity is odd (odd numbers of 1s).

(5) <u>Discuss the bus organization of 8085.</u>

The 8-bit 8085 CPU (or MPU – Micro Processing Unit) communicates with the other units using a 16-bit address bus, an 8-bit data bus and a control bus.

Address Bus

- It consists of 16 address lines: $A_0 A_{15}$
- It operates in **unidirectional** mode: The address bits are always sent from the MPU to peripheral devices in one direction, not reverse.



- MPU uses the address bus to perform first function: identifying a peripheral or a memory location.16 address lines are capable of addressing a Total of 2¹⁶=65,536 (64k) memory locations. Address locations: 0000 (hex) to FFFF (hex)
- When the 8085 wants to access a peripheral or a memory location, it places the 16-bit address on the address bus and then sends the appropriate control signals.

Data Bus

- It consists of 8 data lines: $D_0 D_7$
- It operates in **bidirectional** mode: The data bits are sent from the MPU to peripheral devices, as well as from the peripheral devices to the MPU.
- The MPU uses the data bus to perform second function : Transfer binary information (data and instructions)


Data range: 00 (hex) - FF (hex)

Control Bus

- The control bus is used for sending control signals to the memory and I/O devices.
- Some of the control bus signals are:
 - o Memory read
 - Memory write
 - o I/O read
 - o I/O write
- It comprised of various single lines that carry synchronization signals.
- The MPU uses such lines to perform third function: Provide timing or synchronization signals (control signals)

(6) Explain registers organization of 8085. OR Explain Internal Operation perform by the microprocessor

The 8085 can perform a number of internal operations. Such as: storing data, Arithmetic & Logic operations, testing for condition, etc. To perform these operations, the microprocessor needs an internal architecture similar to the following:



Registers

- Six general purpose 8-bit registers: B, C, D, E, H, L
- They can also be combined as register pairs to perform 16-bit operations: BC, DE, and HL
- Registers are programmable (data load, move, etc.)

Accumulator

- Single 8-bit register that is part of the ALU
- Used for arithmetic / logic operations the result is always stored in the accumulator.

Flag Bits

- Indicate the result of condition tests. Carry, Zero, Sign, Parity, etc.
- Conditional operations (IF / THEN) are executed based on the condition of these flag bits.

The Program Counter (PC)

- This is a register that is used to control the sequencing of the execution of instructions.
- This register always holds the address of the next instruction.
- Since it holds an address, it must be 16 bits wide.

The Stack pointer

- The stack pointer is also a 16-bit register that is used to point into memory.
- The memory this register points to be a special area called the stack.
- The stack is an area of memory used to hold data that will be retrieved soon.
- The stack is usually accessed in a Last in First out (LIFO) fashion.

(7) <u>Explain Microprocessor initiated</u>, <u>externally initiated operations and</u> <u>Internal Data Manipulation in 8085 microprocessor</u>.

Microprocessor-Initiated Operations

Microprocessor performs primarily four operations as a part of communication process between MPU and peripheral devices.

- 1. Memory Read : Reads data (instructions) from memory
- 2. Memory Write: Writes data (instructions) in to memory
- 3. I/O Read: Accepts data from input devices.
- 4. I/O Write: Sends data to output devices

To communicate with a peripheral, the MPU need to perform following steps:-

- 1. Identify the peripherals or the memory location (with its address)
- 2. Transfer binary information (data and instructions)
- 3. Provide timing or synchronization signals (control signals)


Memory Read Operation

To read the contents of a memory location, the following steps take place:

- The microprocessor places the 16-bit address of the memory location on the address bus.
- The microprocessor activates a control signal called "memory read" which enables the memory chip.
- The memory decodes the address and identifies the right location.
- The memory places the contents on the data bus.

• The microprocessor reads the value of the data bus after a certain amount of time.

Similar steps carried out for memory write operation, I/O read Operation, I/O write operation



Peripheral-Initiated Operations OR external operation

External devices can initiate (start) one of the 4 following operations:

1. Reset

All operations are stopped and the program counter is reset to 0000.

2. Interrupt

The microprocessor's operations are interrupted and the microprocessor executes what is called a "service routine". This routine "handles" the interrupt, (perform the necessary operations). Then the microprocessor returns to its previous operations and continues.

3. Ready

The 8085 has a pin called RDY. This pin is used by external devices to stop the 8085 until they catch up. As long as the RDY pin is low, the 8085 will be in a wait state.

4. Hold

The 8085 has a pin called HOLD. This pin is used by external devices to gain control of the busses. When the HOLD signal is activated by an external device, 8085 stop executing current instructions. This would allow external devices to control the information on the busses. Example DMA.

Internal Data Manipulation:

The 8085 performs following operations

- Store 8 bit data
- Perform arithmetic and logical operations
- Test for certain conditions
- Sequence the execution of instructions
- Store data temporarily in stack during execution