## AmbientLightSensor

- photodiode
- ▶light to current




image source: wikipedia

## AmbientLightSensor

- Dambient light level
- **▶**illuminance
- ■lux

