

cat063 category specification

Release 2020-08-04, 1.6

Sensor Status Reports

2020-08-04

CONTENTS:

| 1 | Preamble | 3 |
|---|--|----------------------------|
| 2 | Description of standard data items 2.1 I063/010 - Data Source Identifier 2.2 I063/015 - Service Identification 2.3 I063/030 - Time of Message 2.4 I063/050 - Sensor Identifier 2.5 I063/060 - Sensor Configuration and Status 2.6 I063/070 - Time Stamping Bias | 5 5 5 6 6 8 |
| | 2.10 I063/091 - PSR Azimuth Bias | 10 11 |
| | 2.13 I063/SP - Special Purpose Field | 13 13 |

category: 063
edition: 1.6

date: 2020-08-04

CONTENTS:

2 CONTENTS:

CHAPTER ONE

PREAMBLE

Surveillance data exchange.

DESCRIPTION OF STANDARD DATA ITEMS

2.1 I063/010 - Data Source Identifier

Definition: Identification of the radar station from which the data are received.

Structure:

1063/010/SAC - System Area Code

- 8 bits [.....]
- · raw value

I063/010/SIC - System Identification Code

- 8 bits [.....]
- raw value

Note: The defined SACs are on the EUROCONTROL ASTERIX website (www.eurocontrol.int/asterix)

2.2 I063/015 - Service Identification

Definition: Identification of the service provided to one or more users.

Structure:

- 8 bits [.....]
- · raw value

The service identification is allocated by the SDPS

2.3 I063/030 - Time of Message

Definition: Absolute time stamping of the message, in the form of elapsed time since last midnight, expressed as UTC.

Structure:

- 24 bits [......]
- unsigned quantity
- scaling factor: 1
- fractional bits: 7
- unit: "s"

• LSB = $1/2^7$ s = 1/128 s ≈ 0.0078125 s

The time of the day value is reset to zero at every midnight.

2.4 I063/050 - Sensor Identifier

Definition: None

Structure:

I063/050/SAC - System Area Code

- 8 bits [.....]
- · raw value

I063/050/SIC - System Identification Code

- 8 bits [.....]
- · raw value
- The up-to-date list of SACs is published on the EUROCONTROL Web Site (http://www.eurocontrol.int/asterix).
- If the SAC/SIC refers to an SDPS used as input, the respective sensor status information will be transmitted using the Reserved Expansion Field.

2.5 I063/060 - Sensor Configuration and Status

Definition: Configuration and status of the sensor

Structure:

Extended item with first part 8 bits long and optional 8 bits extends.

I063/060/CON

- 2 bits [...]
- values:
 - 0: Operational
 - 1: Degraded
 - 2: Initialization
 - 3: Not currently connected

I063/060/PSR

- 1 bit [.]
- · values:
 - 0: PSR GO
 - 1: PSR NOGO

I063/060/SSR

- 1 bit [.]
- values:
 - 0: SSR GO
 - 1: SSR NOGO

1063/060/MDS

- 1 bit [.]
- values:
 - 0: MDS GO
 - 1: MDS NOGO

I063/060/ADS

- 1 bit [.]
- · values:
 - 0: ADS GO
 - 1: ADS NOGO

I063/060/MLT

- 1 bit [.]
- values:
 - 0: MLT GO
 - 1: MLT NOGO

(FX)

- · extension bit
 - 0: End of data item
 - 1: Extension into next extent

I063/060/OPS - Operational Release Status of the System

- 1 bit [.]
- · values:
 - 0: System is released for operational use
 - 1: Operational use of System is inhibited

I063/060/ODP - Data Processor Overload Indicator

- 1 bit [.]
- · values:
 - 0: Default, no overload
 - 1: Overload in DP

I063/060/OXT - Transmission Subsystem Overload Status

- 1 bit [.]
- · values:
 - 0: Default, no overload
 - 1: Overload in transmission subsystem

I063/060/MSC - Monitoring System Connected Status

- 1 bit [.]
- values:
 - 0: Monitoring system connected
 - 1: Monitoring system disconnected

1063/060/TSV - Time Source Validity

• 1 bit [.]

- values:
 - 0: Valid 1: Invalid

I063/060/NPW - No Plot Warning

- 1 bit [.]
- values:
 - 0: Default (no meaning)
 - 1: No plots being received

I063/060/(spare)

• 1 bit [.]

(FX)

- · extension bit
 - 0: End of data item
 - 1: Extension into next extent
- 1. GO/NOGO information from PSR, SSR, Mode S, ADS and MLT is derived from monosensor categories and has a meaning only for operational sensors, whereas (CON) is derived by the SDPS.
- 2. The information (OPS), (ODP), (OXT), (MSC) and (TSV) are only related to CNS/ATM Ground Station and are derived from monosensor category (ASTERIX Cat 023).

2.6 1063/070 - Time Stamping Bias

Definition: Plot Time stamping bias, in two's complement form

Structure:

- 16 bits [......]
- · signed quantity
- scaling factor: 1
- fractional bits: 0
- unit: "ms"
- LSB = 1 ms

2.7 I063/080 - SSR / Mode S Range Gain and Bias

Definition: SSR / Mode S Range Gain and Range Bias, in two's complement form.

Structure:

1063/080/SRG - Mode S Range Gain

- 16 bits [......]
- · signed quantity
- scaling factor: 0.00001
- fractional bits: 0

• LSB = 0.00001

I063/080/SRB - Mode S Range Bias

- 16 bits [.....]
- · signed quantity
- scaling factor: 1
- fractional bits: 7
- unit: "NM"
- LSB = $1/2^7$ NM = 1/128 NM ≈ 0.0078125 NM

Note:

The following formula is used to correct range:

$$\rho_{\rm corrected} = \frac{\rho_{\rm measured} - range_bias}{1 + range_gain}$$

2.8 I063/081 - SSR Mode S Azimuth Bias

Definition: SSR / Mode S Azimuth Bias, in two's complement form.

Structure:

- 16 bits [.....]
- · signed quantity
- scaling factor: 360
- fractional bits: 16
- unit: "deg"
- LSB = $360/2^{16}$ deg = 360/65536 deg ≈ 0.0054931640625 deg

Note:

The following formula is used to correct azimuth:

$$\theta_{\text{corrected}} = \theta_{\text{measured}} - azimuth_bias$$

2.9 I063/090 - PSR Range Gain and Bias

Definition: PSR Range Gain and PSR Range Bias, in two's complement form. Structure:

1063/090/PRG - PSR Range Gain

- 16 bits [.....]
- · signed quantity
- scaling factor: 0.00001
- fractional bits: 0
- LSB = 0.00001

I063/090/PRB - PSR Range Bias

• 16 bits [.....]

- · signed quantity
- scaling factor: 1
- fractional bits: 7
- unit: "NM"
- LSB = $1/2^7$ NM = 1/128 NM ≈ 0.0078125 NM

Note:

The following formula is used to correct range:

2.10 I063/091 - PSR Azimuth Bias

Definition: PSR Azimuth Bias, in two's complement form.

Structure:

- 16 bits [.....]
- signed quantity
- scaling factor: 360
- fractional bits: 16
- unit: "deg"
- LSB = $360/2^{16}$ deg = 360/65536 deg ≈ 0.0054931640625 deg

Note:

The following formula is used to correct azimuth:

$$\theta_{\text{corrected}} = \theta_{\text{measured}} - azimuth \ bias$$

2.11 I063/092 - PSR Elevation Bias

Definition: PSR Elevation Bias, in two's complement form.

Structure:

- 16 bits [......]
- signed quantity
- scaling factor: 360
- fractional bits: 16
- unit: "deg"
- LSB = $360/2^{16}$ deg = 360/65536 deg ≈ 0.0054931640625 deg

2.12 I063/RE - Reserved Expansion Field

Definition: Expansion

Structure: Explicit item

2.13 I063/SP - Special Purpose Field

Definition: Special Purpose Field

Structure: Explicit item

| at063 category specification, Release 2020-08-04, 1.6 | |
|---|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

CHAPTER

THREE

USER APPLICATION PROFILE FOR CATEGORY 063

- (1) I063/010 Data Source Identifier
- (2) I063/015 Service Identification
- (3) 1063/030 Time of Message
- (4) I063/050 Sensor Identifier
- (5) I063/060 Sensor Configuration and Status
- (6) I063/070 Time Stamping Bias
- (7) I063/080 SSR / Mode S Range Gain and Bias
- (FX) Field extension indicator
- (8) I063/081 SSR Mode S Azimuth Bias
- (9) I063/090 PSR Range Gain and Bias
- (10) I063/091 PSR Azimuth Bias
- (11) I063/092 PSR Elevation Bias
- •(12) (spare)
- (13) I063/RE Reserved Expansion Field
- (14) I063/SP Special Purpose Field
- (FX) Field extension indicator

| cat063 category specification, Release 2020-08-04, 1.6 |
|--|
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |

CHAPTER

FOUR

INDICES AND TABLES

- genindex
- modindex
- search