## **Chapter 1: Perspectives**

Copyright @ 2005-2008 Yan Solihin

#### Copyright notice:

No part of this publication may be reproduced, stored in a retrieval system, or transmitted by any means (electronic, mechanical, photocopying, recording, or otherwise) without the prior written permission of the author.

An exception is granted for academic lectures at universities and colleges, provided that the following text is included in such copy: "Source: Yan Solihin, Fundamentals of Parallel Computer Architecture, 2008".


# Module 1.1: The Switch to Multicore

#### **Definitions**

- Parallel Architecture = an architecture where CPUs are tightly integrated enough that they can work to solve a single problem
- What is a CPU (also known as a core)?
  - A CPU typically refers to a processing element capable of independently fetching and executing instructions from at least one instruction stream.
  - A core typically includes logic such as instruction fetch unit, program counter, instruction scheduler, functional units, register file, etc.
  - Does it include the L1 caches? Yes and no
  - Does it include the L2 cache? Yes and no

#### What is a Multicore?

- Multicore = a chip with multiple CPUs/cores integrated on a single die
- Most multicores are parallel architectures, parallel architectures typically have multicores as the smallest building blocks Multicore Parallel Arch



#### Recent Multicores

Table 1.2: Examples of recent multicore processors.


Aspects	Intel IvyBridge	Oracle Sparc T5	IBM Power7+		
# Cores	6 superscalar 2-way SMT cores	12 2-issue superscalar cores	8 superscalar, 4-way SMT, cores, plus accelerators		
Technology	22nm	28nm	32nm, 13 metal layers, 567mm <sup>2</sup> , 2.1B transistors		
Clock Freq	up to 4.0GHz	3.6GHz	up to 4.4GHz		
Caches	64KB L1, 256KB L2 (per core), up to 15MB L3 (shared)	16KB L1 (per core), 128KB L2 (per core), 8MB L3 (shared)	256KB L2 (per core), 80MB eDRAM L3 (shared)		

- Ranging from 6-16 cores, often capable of running multiple threads per core
- 3 levels of cache hierarchy, L3 cache 8MB-80MB


#### A Closer Look: Oracle T5

- 16 cores
- 8 L3 cache banks
- L1 and L2 caches are "implied" as parts of a core

 Starting 2001-2005, chipmakers turned to multicore design approach. Why?



#### Feature Size Scaling



 Result of scaling: 2,300 transistors (1971) to 2.3 billion transistors (2012)

# Evolution in Microprocessors Table 1.1: Evolution of Intel Processors. Other chipmakers also enjoy a similar transistor

integration progress scaling according to Moore's law.

Year	Processor	Specifications	New Features			
1971	4004	740 KHz, 2300 transistors, 10μm, 640B addressable memory, 4KB program memory				
1978	8086	16-bit, 5–10MHz, 29,000 transistors at $3\mu m$ , 1MB addressable memory				
1982	80286	8–12.5MHz	Virtual memory and protection mode			
1985	386	32-bit, 16-33MHz, 275K transistors, 4GB addressable memory	Pipelining			
1989	486	25-100MHz, 1.2M transistors	FPU integration			
1993	Pentium	60-200MHz	on chip L1 caches SMP support			
1995	Pentium Pro	16KB L1 caches, 5.5M transistors	out-of-order execution			
1997	Pentium MMX	233-450MHz, 32KB L1 cache, 4.5M transistors	dynamic branch prediction, MMX instruction sets			
1999	Pentium III	450-1400MHz, 256KB L2 cache on chip, 28M transistors	SSE instruction sets			
2000	Pentium IV	1.4-3GHz, 55M transistors	hyper-pipelining, SMT			
2006	Pentium Dual-Core	64-bit, 2GHz, 167M transistors, 4MB L2 cache on chip	Dual core, virtualization support			
2011	Sandy Bridge (i7)	64-bit, up to 3.5GHz, 2.37B transistors, up to 20MB L3 cache	graphics processor, TurboBoost			

#### Discussion

- Increasingly more and more components and features can be integrated on a single chip
- "Perhaps" transition from single core to multicore was just a matter of time
- But why did it happen in that sequence?
  - Why did pipelining, branch prediction, superscalar issue, and caches came BEFORE multicore?

- My Answer: Low Hanging Fruit Theory
  - The farmer picks up the low hanging fruits first because they require less efforts to pick up
  - ... that is until they run out of low hanging fruits

#### Parallel Multicore is Not Low Hanging

- For the most part, benefiting from multicore requires parallel programming
- Parallel programming requires additional effort over sequential programming
  - Program split into multiple instruction streams (threads)
  - Co-ordinate threads using synchronization
  - Communicate data across threads
  - Result: Thread Level Parallelism (TLP)
- vs. Instruction Level Parallelism (ILP)
  - No (or little) programming efforts
  - Programmers can use sequential paradigm, the way our brain likes it
- So why the switch from ILP to TLP? It must be because we run out of low hanging ILP fruits!

#### **ILP Fruits**

- Instruction Level Parallelism (ILP)
  - Pipelining: RISC, CISC with RISC backend
  - Superscalar
  - Out of order execution
- Memory hierarchy (Caches)
  - Exploiting spatial and temporal locality
  - Multiple cache levels

## ILP Technique: Pipelining

,	 ID	EX	MEM	WB			
В	IF	ID		MEM	WB		
С		IF	ID		MEM	WB	

## ILP Technique: Superscalar

Original:

```
LD F0, 34(R2)
ADDD F4, F0, F2
LD F7, 45(R3)
ADDD F8, F7, F6
```

Schedule as:

```
LD F0, 34(R2) | LD F7, 45(R3)
ADDD F4, F0, F2 | ADDD F8, F0, F6
```

- Moderate degree of parallelism (theoretically ~50, but realistically ~2 inst/cycle)
- Requires fast communication (register level)

## TLP Technique: loop parallelism

Each iteration can be computed independently

 Each iteration cannot be computed independently, thus does not have loop level parallelism

- Very high parallelism > 1K
- Often easy to achieve load balance
- Usu. requires splitting into multiple instruction streams
- Some loops are not parallel
- Some apps do not have many loops

#### TLP Technique: function parallelism

- Arbitrary code segments in a single program
- Across loops:

```
for (i=0; i<n; i++)
   sum = sum + a[i];
for (i=0; i<n; i++)
   prod = prod * a[i];
...</pre>
```

Subroutines:

```
Cost = getCost();
A = computeSum();
B = A + Cost;
```

- Threads: e.g. editor: GUI, printing, parsing
- Larger granularity => low overheads, communication
- Low degree of parallelism
- Hard to balance

## Program level parallelism

- Various independent programs execute together
- gmake:

```
gcc -c code1.c // assign to proc1
gcc -c code2.c // assign to proc2
gcc -c main.c // assign to proc3
gcc main.o code1.o code2.o
```

- + no communication
- Hard to balance
- Few opportunities

## No Longer Low Hanging?

- Increasing pipeline depth counter-productive [Hartstein & Puzak, 2002]
  - Latching overheads becoming significant
  - Too little time in a pipeline stage to do useful logic
  - Critical loop sizes increase proportionally to pipeline depth (branch misprediction loop, data dependence loop, cache miss loop)
- Increasing pipeline width incurs quadratic increase in complexity [Palacharla & Smith, 1996]
  - Dependence checking logic, wakeup & select logic, register ports, bypass logic, etc.
- Power efficiency declines significantly

#### Module 1.2: Power Wall

#### Basics of Power and Energy

- Energy = the ability of a physical system to do work on other physical systems (unit: joule)
  - 1 joule = energy to lift an apple to shoulder height
  - 4 joules = energy to heat a teaspoon of water by 1 degree Celcius
- Power = rate at which energy is transferred
  - Unit: 1 watt = 1 joule delivered in 1 second
  - Power = V \* I
- For a capacitor
  - Energy\_stored =  $0.5 \text{ C V}^2$
  - V is voltage, C is capacitance
- If capacitor is drained and charged at a frequency of f per second
  - Power = Energy/second =  $2 * 0.5 \text{ CV}^2 * f = \text{CV}^2 f$
  - The above is referred to as dynamic power consumption

## **Energy Efficiency**

- Energy efficiency
  - how much energy required to perform a work
    - Unit: energy unit/work unit,
    - e.g. EPI (Energy per Instruction)
  - ratio of how fast energy is consumed vs. how fast work gets done
    - Unit: power unit/throughput unit
      - E.g. Watt/IPC, Watt/IPS, Watt/FLOPS
    - Watt/IPS = (Joule/sec)/(Inst/sec) = Joule/Inst = EPI
    - Watt/thruput = (Joule/sec)/(work/sec) = Joule/work = amount of energy required to perform work

#### Other Metrics

- Two other metrics common in publications
- Energy Delay Product (EDP): what is it?
  - Energy/work most relevant in battery-powered systems
  - But performance matters, e.g. would you choose system A that gets work done at 0.5 watt in 2 seconds, or system B that gets work done at 1 watt in 1 second? Both use 1 joule of energy, but most will prefer the latter.
  - Hence, weight energy with delay by multiplying them.
- Energy Delay2 Product (ED2P): what is it?
  - Put even more emphasis on delay, favoring reduction in delay more than reduction in energy.

#### Power Wall Problem

- Power Consumption = Dynamic + Static
- Determined by packaging constraints (e.g. 65W for desktop)
- Dynamic Power
  - Power lost from charging/discharging capacitive loads

$$Pdyn = ACV^2 f$$

- A: fraction of gates actively switching
- C: total capacitance of all gates
- V: supply voltage, f: frequency of switching
- Static Power
  - Power lost from leakage

$$Pstatic = VI_{leak}$$


• I<sub>leak</sub>: leakage current

#### Power Wall Fundamentals

 Max frequency vs. threshold voltage

$$f_{\text{max}} \approx c \frac{(V - V_{thd})^{1.3}}{V}$$

 V<sub>thd</sub>: threshold voltage, minimum Voltage to make transistor conducive




Reducing threshold voltage increases maximum frequency almost linearly

#### Power Wall Fundamentals

- Static Power
   Consumption
  - Leakage current:

$$I_{leak} > e^{-\frac{qV_{thd}}{kT}}$$



Reducing threshold voltage increases static power consumption exponentially

## Threshold Voltage Dilemma

#### Dilemma

- Decreasing Vthd improves f<sub>max</sub> (and hence, performance)
- Decreasing Vthd increases leakage current (hence static power consumption) exponentially

## Old Scaling Rule

- Gate length (transistor size) scales by S = 0.7
- Capacitance scales by S = 0.7
- Original area scales by  $S^2 = 0.5$ ,
- number of transistors scales by  $1/S^2 = 2$
- Supply voltage (V) scales by S = 0.7
- Frequency (f) scales by 1/S = 1.4
- Dynamic power of chip remains constant:

$$DynP = ACV^{2}f$$

$$DynP' = A'C'V'^{2}f'$$

$$DynP' = (2A)(0.7C)(0.7V)^{2}(1.4f)$$

$$DynP' = ACV^{2}f = DynP$$

## **New Scaling Rule**

- Capacitance scales by S = 0.7
- Number of transistors scales by 1/S<sup>2</sup> = 2
- Supply voltage (V) cannot scale without also scaling Vthd
  - but scaling Vthd increases static power exponentially
- Frequency (f) scales by 1/S = 1.4
- Dynamic power of chip doubles every generation!

$$DynP = ACV^{2}f$$

$$DynP' = A'C'V'^{2}f'$$


$$DynP' = (2A)(0.7C)(V)^{2}(1.4f)$$

$$DynP' = 2 \cdot DynP$$

#### Implications for Architecture Design


- Increasing clock frequency has hit a dead end
- Area is abundant but power is scarce
- Declining power budget per core
- New architecture must improve energy efficiency
- Dominant metric: performance/watt or ops/joule

## Clock Frequency Stagnant?




• 2001-2005: same time as transition to multicore

## Computation per Pipeline Stage



• 2001-2005: pipelining started to *reverse* (in terms of amount of logic per pipeline stage

## Power Saving Mechanisms



- Keeping clock frequency constant is insufficient
- Other power saving techniques were employed to contain power: clock gating, etc.

#### Exercise

- 1. Suppose that instead of progressing at a ratio of 0.7, Moore's law slows down and transistor gate length scales at a ratio of 0.8 instead. Find the dynamic power consumption under unlimited and limited scaling for the next process generation.
- 2. With limited voltage scaling, suppose that we want to keep the dynamic power consumption constant in the next generation by keeping frequency constant and reduce die area. How much should we reduce die area to achieve that?

#### Answer (Q1)

- Old Scaling Rule
  - Gate length (transistor size) scales by S = 0.8
  - Capacitance scales by S = 0.8
  - Original area scales by S2 = 0.64,
  - allowing the number of transistors to scale by 1/S2 = 1.56
  - Supply voltage (V) scales by S = 0.8
  - Frequency (f) scales by 1/S = 1.25
  - Dynamic power of chip remains constant:

$$DynP = ACV^{2}f$$

$$DynP' = A'C'V'^{2}f'$$

$$DynP' = (1.56A)(0.8C)(0.8V)^{2}(1.25f)$$

$$DynP' = ACV^{2}f = DynP$$

## Answer (Q1)

- Under leakage-limited scaling:
  - Capacitance scales by S = 0.8
  - Number of transistors scales by 1/S2 = 1.56
  - Supply voltage (V) cannot scale without also scaling Vthd
    - but scaling Vthd increases static power exponentially
  - Frequency (f) scales by 1/S = 1.25
  - Dynamic power of chip increases 56% each generation

$$DynP = ACV^{2}f$$

$$DynP' = A'C'V'^{2}f'$$

$$DynP' = (1.56A)(0.8C)(V)^{2}(1.25f)$$

$$DynP' = 1.56 \cdot DynP$$

## Answer (Q2)

- Limited Voltage Scaling
  - Gate length (transistor size) scales by S = 0.7
  - Capacitance scales by S = 0.7
  - Original area scales by S<sup>2</sup> = 0.5,
  - Supply voltage (V) and frequency (f) are constant
  - Dynamic power of chip must remain constant:

$$DynP = ACV^{2}f$$

$$DynP' = A'C'V'^{2}f'$$

$$ACV^{2}f = A'(0.7C)V^{2}f$$

$$A = 0.7A'$$

• Die area shrinks by 1-1.4/2.0 = 30%

## Module 1.3: Parallel Computers

### What is a Parallel Architecture?

"A parallel computer is a collection of processing elements that can communicate and cooperate to solve a large problem fast."

-- Almasi & Gottlieb

# Parallel computers

- A parallel computer is a <u>collection of processing elements</u> that can <u>communicate</u> and <u>cooperate</u> to <u>solve a large problem fast</u>.
   [Almasi&Gottlieb]
- "collection of processing elements"
  - What is a processing element? Logic that fetches instructions from a single program counter and each instruction operates on a single set of data items.
  - How many? How powerful each? Scalability?
  - Few very powerful (e.g., Altix) vs. many small ones (BlueGene)
- "communicate"
  - How do PEs communicate? (shared memory vs. msg passing)
  - Interconnection network (bus, multistage, crossbar, ...)
  - Choices determine cost, latency, throughput, scalability, and fault tolerance

- "and cooperate"
  - Synchronization allows sequencing of operations to ensure correctness
  - Issues: granularity and mechanisms
  - Choices affect latency, load balance, scalability, and fairness
- "solve a large problem fast"
  - General vs. special purpose machine?
  - Any machine can solve certain problems well

# Usage of Parallel Computers

#### What domains?

- Highly (embarassingly) parallel apps
  - Many scientific codes
- Medium parallel apps
  - Many engineering apps (finite-elements, VLSI-CAD)
- Not parallel apps
  - Compilers, editors

# Why parallel computers?

- Absolute performance: Can we afford to wait?
  - Folding of a single protein takes years to simulate on the most advanced microprocessor. It only takes days on a parallel computer
  - Weather forecast: timeliness is crucial
- Cost-adjusted performance or Power-adjusted performance
  - Especially for small systems with 2-8 chips
  - The smallest system is a multicore processor
  - Large parallel computers are rarely cost-performance effective

# Why parallel computers were not mainstream until multicore

- Low hanging ILP fruits mean it was easy to scale performance through ILP
- This made parallel computers unattractive in terms of cost-performance
  - Expensive (cost and time) to design scalable parallel systems
  - Performance from parallelism eclipsed by ILP in just a few years
- This went on until ILP fruits were higher hanging than TLP

### Illustration

- 100-processor system with perfect speedup
- Compared to a single processor system
  - Year 1: 100x faster
  - Year 2: 62.5x faster
  - Year 3: 39x faster
  - **—** ...
  - Year 10: 0.9x faster
- Single processor performance catches up in just a few years!
- Even worse
  - It takes longer to develop a multiprocessor system
  - Low volume means prices must be very high
  - High prices delay adoption
  - Perfect speedup is unattainable

# Flynn Taxonomy


Table 1.3: Flynn's Taxonomy of Parallel Computers

		Number of Data Streams	
		Single	Multiple
Number of Instruction Streams	Single	SISD	SIMD
	Multiple	MISD	MIMD

- Instruction stream = instructions fetched from a single program counter
- Data stream = data items accessed by a single instruction


### SISD

- SISD = Single Instruction Stream, Single Data Stream
  - Only one program counter (fetched by Control Unit/CU)
  - Each instruction accesses one set of data (e.g. 2 operands and 1 result)
  - Data processed by Data Processing Unit (DPU)



### SIMD

- SIMD = Single Instruction Stream and Multiple Data Streams
- Examples: Vector processors, multimedia extension



- Multimedia extension use SIMD-style execution
  - Rather than operating on many sets of data items, data items are packed into a single set of regular registers

### Example SSE Code

#### SISD style

```
for (i=0;i<4;i++)
C[i] = A[i] + B[i]
```

#### SIMD style


```
C = A + B
```

#### Example SSE Code with 4 32-bit data packed into 128-bit register:

```
Vector4 SSE Add ( const Vector4 &Op_A, const Vector4 &Op_B )
{
        Vector4 Ret Vector;
        __asm
                MOV EAX Op A
                                                   // Load pointers into CPU regs
                MOV EBX, Op B
                                                   // Move unaligned vectors to SSE regs
                MOVUPS XMM0, [EAX]
                MOVUPS XMM1, [EBX]
                ADDPS XMM0, XMM1
                                                   // Add vector elements
                MOVUPS [Ret Vector], XMM0 // Save the return vector
        }
        return Ret Vector;
}
```


### **MISD**

- MISD = Multiple Instruction Streams and Single Data Stream
- e.g. Systolic arrays



# Systolic Arrays (contd.)


Example: Systolic array for Matrix Multiplication



 Intel manufactured iWARP, using general processors with dedicated interconnect channels for transferring data from register to register

### **MIMD**

- Independent processing elements connected together
  - Each PE fetches from its own instruction stream and processes its own data stream
- Most parallel computers today are MIMD



### Variants of MIMD

 Variants of MIMD differ in physical organization: which memory hierarchy level is shared?




Figure 1.7: Classes of MIMD parallel computers: shared cache (a), uniform memory access (b), non-uniform memory access (c), and distributed system (d).


# Top 500 Parallel Computers

- Maintained at http://www.top500.org
- Fast changing
  - Earth Simulator #1 in 2004 became #10 two years
     later
- Engineering marvel, consuming as much electricity as a city
- Building, plumbing, and cooling often codesigned with the computers

# Earth Simulator (2004)

• "The machine room sits at approximately 4th floor level. The 3rd floor level is taken by hundreds of kilometers of copper cabling, and the lower floors house the air conditioning and electrical equipment. The structure is enclosed in a cooling shell, with the air pumped from underneath through the cabinets, and collected to the two long sides of the building. The aeroshell gives the building its "pumped-up" appearance. The machine room is electromagnetically shielded to prevent interference from nearby expressway and rail. Even the halogen light sources are outside the shield, and the light is distributed by a grid of scattering pipes under the ceiling. The entire structure is mechanically isolated from the surroundings, suspended in order to make it less prone to earthquake damage. All attachments (power, cooling, access walkways) are flexible. "

Filindamentals of Computer Architecture - Chapter 1 53



- Linpack performance: 40 TFlops, 80% peak
- Real world performance: 33-66% peak (vs. less than 15% for clusters)
- Cost? Hint: starts with 4
- Maintenance \$15M per year
- Failure one processor per week
- Distributed Memory Parallel Computing System which 640 processor nodes interconnected by Single-Stage Crossbar Network

# Fastest (#1 as of June 2013)

- Tianhe-2 (National University of Defense Technology of China)
- 33.8 tera floating point operations per second (TFlops) with Linpack
- 3,120,000 cores, organized into 16,000 nodes
- Each node has 195 cores (2 Intel Xeon IvyBridge + 3 Xeon Phi)
- ~18 MW of electricity

