ET1035 Reference Design Address Map			
	ET1035: Single Core		
Component	Start Address	End Address	
Boot ROM	0x0001_0000	0x0001_7FFF	
Internal RAM	0x0020_0000	0x0023_FFFF	
UARTO	0x1000_0100	0x1000_01FF	

