

Internal Combustion Engines I: Fundamentals and Performance Metrics

Prof. Rolf D. Reitz, Engine Research Center, University of Wisconsin-Madison

2018 Princeton-Combustion Institute Summer School on Combustion Course Length: 9 hrs

(Mon.- Wed., June 25-27)

Copyright ©2018 by Rolf D. Reitz.

This material is not to be sold, reproduced or distributed without prior written permission of the owner, Rolf D. Reitz.





Short course outline:

Internal Combustion (IC) engine fundamentals and performance metrics, computer modeling supported by in-depth understanding of fundamental engine processes and detailed experiments in engine design optimization.

Day 1 (Engine fundamentals)

Hour 1: IC Engine Review, Thermodynamics and 0-D modeling

Hour 2: 1-D modeling, Charge Preparation

Hour 3: Engine Performance Metrics, 3-D flow modeling

Day 2 (Computer modeling/engine processes)

Hour 4: Engine combustion physics and chemistry

Hour 5: Premixed Charge Spark-ignited engines

Hour 6: Spray modeling

Day 3 (Engine Applications and Optimization)

Hour 7: Heat transfer and Spray Combustion Research

Hour 8: Diesel Combustion modeling

Hour 9: Optimization and Low Temperature Combustion





1-D compressible flow

Mass conservation:

$$g = 1$$
 dMg/dt)_{System} = 0

cv fixed $0 = \int_{cv} \left\{ \frac{\partial (\rho A)}{\partial t} + \nabla \cdot (\rho A \mathbf{V}) \right\} dx$

1.
$$\frac{\partial(\rho A)}{\partial t} + \frac{\partial(\rho AV)}{\partial x} = 0$$

Momentum conservation:


2.
$$\frac{\partial V}{\partial t} + V \frac{\partial V}{\partial x} + \frac{1}{\rho} \frac{\partial P}{\partial x} + 2 f V^2 / D = 0$$

Energy conservation:

3.
$$\frac{\partial e}{\partial t} + V \frac{\partial e}{\partial x} = \dot{q} + 2 f V^3 / D - \frac{P}{\rho A} \frac{\partial (VA)}{\partial x}$$

Reynolds Transport Equation

$$\frac{dMg}{dt})_{system} = \frac{d}{dt} \int_{system} \rho g d \forall = \frac{d}{dt} \int_{cv} \rho g d \forall + \int_{cs} \rho g \mathbf{V}_{rel} \cdot \mathbf{n} \, dA$$



Supplementary:

4.
$$P = \rho RT$$
State

5. $e = c_v T$

$$f = \tau_w / \rho V^2 / 2$$


$$\dot{Q} = \dot{q} \rho A dx$$

5 unknowns U: ρ, V, e, P, and T 5 equations for variation of flow variables in space and time





In 1-D models friction factors are used to account for losses at area change or bends by applying a friction factor to an "equivalent" length of straight pipe







1-D Modeling Codes

- 1-D codes (e.g., GT-Power, AVL-Boost, Ricardo WAVE) predict wave action in manifolds At high engine speed valve overlap can improve engine breathing
- → inertia of flowing gases can cause inflow even during compression stroke.

Variable Valve Actuation (VVA) technologies, control valve timing to change effective compression ratio (early or late intake valve closure), or exhaust gas re-induction (re-breathing) to control in-cylinder temperatures.

Residual gas left from the previous cycle affects engine combustion processes through its influence on charge mass, temperature and dilution.





1 ca deg = 0.1 ms @ 1800 rev/min



Numerical solution

To integrate the partial differential equations: Discretize domain with step size, Δx Time marches in increments of Δt from initial state U_i^0 : $\rho_i^n, V_i^n, e_i^n, P_i^n$, and T_i^n

$$t=n\Delta t$$
 $n=0, 1, 2, 3,$


$$\frac{\partial U(x,t)}{\partial x} = \frac{\Delta U(x_i, n \cdot dt)}{\Delta x_i} = \frac{U_{i+1}^n - U_i^n}{\Delta x_i}$$

$$\frac{\partial U(x,t)}{\partial t} = \frac{\Delta U(x_i, n \cdot dt)}{\Delta t} = \frac{U_i^{n+1} - U_i^n}{\Delta t}$$

Considerations of stability require the Courant-Friedrichs-Levy (CFL) condition


$$\Delta t \leq \min(\Delta x_i / (|V_i^n| + c_i^n))$$







Analytical solutions – Method of Characteristics



x – distance along duct



All points continuously receive information about both upstream and downstream flow conditions from both left and right-running waves. These waves originate from all points in the flow.



Analytical solutions – Method of Characteristics

R: right-running wave slope $\frac{dx}{dt} = V + c$ Wave diagram L: left-running wave t - time P: particle-path slope $\frac{dx}{dt} = V - c$ slope $\frac{dx}{dt} = V$

x – distance along duct

R:, L:, P:, are called Characteristic Lines in the flow

 $\Delta t \le \min(\Delta x_i / (|V_i^n| + c_i^n))$




Along R: $dP + \rho cdV = Fdt$

Along L: $dP - \rho cdV = Gdt$

Along P: $d\rho - dp/c^2 = Hdt$

$$F,G,H = Functions of (\dot{q} f, \ln A/dx)$$



The discrete versions are:

$$(P_{4} - P_{R}) + (\rho c)_{R}(V_{4} - V_{R}) = F_{R}\Delta t$$

$$(P_{4} - P_{L}) - (\rho c)_{L}(V_{4} - V_{L}) = G_{L}\Delta t$$

$$(\rho_{4} - \rho_{P}) - \left(\frac{1}{c^{2}}\right)_{P}(P_{4} - P_{P}) = H_{P}\Delta t$$

3 equations to solve for

$$\rho_4$$
, V_4 and P_4

Note: from Gibbs' equation

$$dS = \frac{c_P}{\rho} \left(\frac{dP}{c^2} - d\rho \right) = \frac{c_P}{\rho} H dt$$




X



Lagrange ballistics

Flow velocities in IC engine cylinders are usually << than the speed of sound. Lagrange ballistics shows that cylinder pressure and density is the same at all points within the combustion chamber.




L:
$$P_4 = P_L + (\rho c)_L (0 - V_L)$$

R:
$$P_4 = P_R - (\rho c)_R (V_{piston} - V_R)$$

P:
$$\rho_4 = \rho_P + (P_4 - P_P)/c^2)_P$$


Pressure increases by dP each wave reflection (dV < 0) in order to alternately ensure that the flow meets the boundary conditions: V=0 at head, and $V=V_{piston}$ at piston.

Order of magnitude analysis of L:, R:, and P: gives





For dV << c relative density change is small– density and pressure changes only in time





Steady Compressible flow – A review

Gibbs
$$\rightarrow Tds = dh - dp / \rho$$

Energy
$$\rightarrow$$
 $dh = -VdV$


Euler
$$\rightarrow dP = -\rho V dV$$

$$\rho AV = Const \Rightarrow \frac{d\rho}{\rho} + \frac{dA}{A} + \frac{dV}{V} = 0$$


$$\frac{dA}{A} = (M^2 - 1)\frac{dV}{V}$$

$$\frac{dA}{A} = \frac{(1 - M^2)}{\rho V^2} dP$$

Area-velocity relations



•				
	Subsonic nozzle	Subsonic diffuser	Supersonic diffuser	Supersonic nozzle
	dA<0	dA > 0	dA < 0	dA > 0
from ρAV	\rightarrow $dV>0$	dV < 0	dV < 0	dV > 0
from Euler	$\rightarrow dP < 0$	dP > 0	dP > 0	dP < 0
	kinetic energy	energy pressure recovery		kinetic energy



Traffic flow behaves like a supersonic flow!







Isentropic nozzle flows

$$\frac{T_0}{T_1} = 1 + \frac{\gamma - 1}{2} M_1^2$$


$$\frac{P_0}{P_1} = (1 + \frac{\gamma - 1}{2} M_1^2)^{\frac{\gamma}{\gamma - 1}}$$



Ex. Flow past throttle plate



Choked flow for $P_2 < 53.5 \text{ kPa} = 40.1 \text{cmHg}$



Manifold pressure, P₁ cmHg





Model passages as compressible flow in converging-diverging nozzles

$$\dot{m} = \rho AV = \frac{P}{RT} A \frac{V}{c} \sqrt{\gamma RT}$$

$$= P_0 \sqrt{\frac{\gamma}{RT_0}} AM(P/P_0) / (T/T_0)^{-1/2}$$


With M=1: Fliegner's formula

$$\dot{m}_{M=1} = \left(\frac{2}{\gamma+1}\right)^{\frac{\gamma+1}{2(\gamma-1)}} \sqrt{\frac{\gamma}{RT_0}} P_0 A^*$$

Area Mach number relations

$$\frac{A}{A^*} = \frac{1}{M} \left\{ \frac{2}{\gamma + 1} \left(1 + \frac{(\gamma - 1)}{2} M^2 \right) \right\}^{\frac{\gamma + 1}{2(\gamma - 1)}}$$

$$\frac{A}{A^*} = \left(\frac{P}{P_0}\right)^{\frac{1}{\gamma}} \left(\frac{2}{\gamma - 1} \left[1 - \left(\frac{P}{P_0}\right)^{\frac{\gamma - 1}{\gamma}}\right] \left(\frac{\gamma + 1}{2}\right)^{\frac{\gamma + 1}{\gamma - 1}}\right)^{1/2}$$







Application to turbomachinery

Fliegner's Formula:


$$\dot{m}_{M=1} = \left(\frac{2}{\gamma+1}\right)^{\frac{\gamma+1}{2(\gamma-1)}} \sqrt{\frac{\gamma}{RT_0}} P_0 A^*$$

"Corrected mass flow rate"

$$rac{\dot{m} \sqrt{T_{ref}/T_0}}{P_0/P_{ref}}$$

A measure of effective flow area

Variable Geometry Compressor/ turbine performance map



 P_0/P Total/static pressure ratio






Turbocharging

Pulse-driven turbine was invented and patented in 1925 by Büchi to increase the amount of air inducted into the engine.

- Increased engine power more than offsets losses due to increased back pressure
- Need to deal with turbocharger lag





Improved

- Fuel economy
- Torque
- Power density





Turbocharging

Purpose of turbocharging or supercharging is to increase inlet air density,

- increase amount of air in the cylinder.

Mechanical supercharging

- driven directly by power from engine.

Turbocharger - connected compressor/turbine

- energy in exhaust used to drive turbine.

Supercharging necessary in two-strokes for effective scavenging:


- intake P > exhaust P
- crankcase used as a pump

Some engines combine engine-driven and mechanical (e.g., in two-stage configuration).

Intercooler after compressor

- controls combustion air temperature.

Air Flow in the VW Twincharged TSI






belt


Electromagnetic




Turbocharging

Energy in exhaust is used to drive turbine which drives compressor






Charge air cooling after compressor further increases air density
- more air for combustion





W

Regulated two-stage turbocharger

Duplicated Configuration per Cylinder Bank











Automotive compressor

Centrifugal compressor typically used in automotive applications


Provides high mass flow rate at relatively low pressure ratio ~ 3.5

Rotates at high angular speeds

- direct coupled with exhaust-driven turbine
- less suited for mechanical supercharging

Consists of:


stationary inlet casing, rotating bladed impeller, stationary diffuser (w or w/o vanes) collector - connects to intake system









Compressor



Note: use exit static pressure and inlet total pressure, because kinetic energy of gas leaving compressor is usually not recovered





Air at stagnation state 0,in accelerates to inlet pressure, P_1 , and velocity V_1 .

Compression in impeller passages increases pressure to P_2 , and velocity V_2 .

Diffuser between states 2 and out, recovers air kinetic energy at exit of impeller producing pressure rise to, P_{out} and low velocity V_{out}


$$\dot{W}_{\scriptscriptstyle C} = \dot{m} \left(h_{\scriptscriptstyle out} - h_{\scriptscriptstyle in} \right)$$

$$\dot{W}_{c} = \frac{\dot{m} \cdot c_{P_{a}} \cdot T_{in}}{\eta_{c}} \left(\left(\frac{p_{out}}{p_{0,in}} \right)^{\frac{\gamma_{a}-1}{\gamma_{a}}} - 1 \right)$$




Compressor maps

Work transfer to gas occurs in impeller via change in gas angular momentum in rotating blade passage



Surge limit line - reduced mass flow due to periodic flow reversal/reattachment in passage boundary layers. Unstable flow can lead to damage

Pressure ratio evaluated using total-to-static pressures since exit flow kinetic energy is not recovered



Speed/pressure limit line

Non-dimensionalize blade tip speed (~ND) by speed of sound

At high air flow rate, operation is limited by choking at the minimum area point within compressor

Supersonic flow



Shock wave






Compressor selection

To select compressor, first determine engine breathing lines.

The mass flow rate of air through engine for a given pressure ratio is:

$$m_{\text{int }ake} = \left[\frac{\eta_{vol} \times D * N \times P_{ref}}{2 \times R \times T_{ref}} \right]$$



Where:

m_{intake} = Physical mass flow of air through engine (mass/time)

 η_{vol} = Volumetric efficiency (unitless)

D = Displacement of engine per cycle (length³/cycle)

N = Engine speed (rev/time)

 P_{ref} = Reference pressure (psi) = IMP = PR * atmospheric pressure (no losses)

R = Gas constant for air (length*force / mass*temperature)

 T_{ref} = Reference temperature (Rankin) = IMT = Roughly constant for given Speed



Hour 2: 1-D modeling, Charge Preparation **Engine breathing lines** Load/Torque Peak torque **Engine Breathing Lines** 1.4L Diesel, Air-to-Air AfterCooled, Turbocharged Rated speed 3.8 3.6 Torque Peak (1700rpm) Trq Peak Operating Pnt Speed 3.4 Rated (2300rpm) 3.2 Rated Operating Pnt 3 2.8 2.6 2.4 2.2 2 1.8 1.6 Parameter **Torque Peak** Units Rated 1.4 Horsepower 48 69 hp **BSFC** 0.377 0.401 lb/hp-hr 1.2



0.000

1.000

2.000

3.000

4.000

5.000

6.000

Compressor Pressure Ratio

Intake Mass Flow Rate (lb/min)

7.000

24.5

13.000 14.000

none

23.8


12.000

8.000

A/F

9.000


10.000




Compressor maps

GM 1.9L diesel engine









<u>Automotive turbines</u>

Naturally aspirated:

$$P_{intake} = P_{exhst} = P_{atm} (5-7-8-9-1)$$

Boosted operation:

Negative pumping work:

 $P_7 < P_1$ – but hurts scavenging

gative pumping work:
$$\dot{W}_t = \dot{m} \left(h_{in} - h_{0,out}\right)$$

$$\dot{P}_t = \dot{m} \left(h_{in} - h_{0,out}\right)$$

$$\dot{W}_t = \dot{m} \left(h_{in} - h_{0,out}\right)$$

$$\dot{W}_t = \dot{m} \left(h_{in} - h_{0,out}\right)$$

$$\dot{W}_t = \dot{m} \left(h_{in} - h_{0,out}\right)$$

$$\dot{P}_{o,out} = \dot{P}_{o,out}$$

$$\dot{P}_{o,out}$$


P-V diagram showing available exhaust energy - turbocharging, turbocompounding, bottoming cycles and thermoelectric generators further utilize this available energy




out

Turbochargers

Radial flow – automotive; axial flow – locomotive, marine





Casing -

Rotor-




Matching


Centering the Engine Map on the Compressor Map for Optimum Performance


The flow characteristics of rotary turbomachines and reciprocating engines are not ideally suited to operate of tandem.

- · Automotive engines
 - wide speed, load and flow range
 - positive displacement
 - discontinuous flow
- Turbochargers
 - high mass flow, with high design point efficiency.
 - narrow range
 - continuous flow no defined displacement



$$\left(\frac{p_2}{p_1}\right) = \left[1 + \frac{Cp_g \cdot T_3}{Cp_a \cdot T_1} \left(1 + \frac{m_{fuel}}{m_{air}}\right) \left(\eta_t \cdot \eta_c \cdot \eta_{mech}\right) \left(1 - \left(\frac{p_4}{p_3}\right)^{\frac{\gamma_g - 1}{\gamma_g - 1}}\right)\right]^{\frac{\gamma_a}{\gamma_a - 1}}$$







Summary

1-D models/codes based on thermodynamic models are available, and they are very useful for understanding charge preparation and engine breathing.

But, 1-D models require calibration against engine or theoretical data.

Turbocharging increases overall engine efficiency by using available energy in exhaust and by reducing pumping work.





References

- 1-2:3,7-9,11-14 J. D. Anderson, Modern Compressible Flow (With Historical Perspective), McGraw-Hill (2nd or 3rd Edition), 1990.
- 1-2:5 1-1:34-36 http://www.ricardo.com/en-GB/What-we-do/Software/Products/WAVE
- 1-2:9 F.J. Moody, Introduction to Unsteady Thermofluid Mechanics, John Wiley & Sons, 1989.
- 1-2:10 P.A. Thompson, Compressible Fluid Dynamics, McGraw-Hill, 1972.
- 1-2:20-21,27 J.B. Heywood, Internal Combustion Engine Fundamentals, McGraw Hill, 1988.
- 1-2:24 Serrano J.R., Arnau F.J., Dolz V., Tiseira A., and Cervello C., "A model of turbocharger radial turbines appropriate to be used in zero- and one-dimensional gas dynamics codes for internal combustion engines modeling", Energy Conversion and Management, 49 (2008) 3729–3745, 2008.
- 1-2:25 Reitz, R.D., and Hoag, K.H., "Reciprocating Engines (Diesel and Gasoline)," Encyclopedia of Energy Engineering and Technology (EEE), B. Capehart, Editor, Marcel Dekker Publishing, New York, 2007.

