Sockets, TCP/IP and Bluetooth

Lecture 3 Feb 15, 2006 Larry Rudolph







A little history

- Simple case: two devices, one cable (2 wires)
 - e.g. first telephone
 - one device puts pulses on wire, the other senses them. Went from analog
 digital
- Generalize: multiple devices, one wire
 - why do we want this?



Bus

- signal broadcast (all devices "sense" it)
- first broadcast an address
- device with that address receives data
 - and ack's it
- Who knows the device's address?



Ethernet

- Ethernet is a type of bus -- easy to add devices
- Every ethernet device has a unique device address
 - how do you know it is unique?
 - a company sells you a unique address
 - this is known as a MAC
 - all devices listen for their mac on bus



What if devices is not on the bus?

Gateway or Bridge

- Special device that transfers packets from ethernet to the rest of the world
- How does it know where to send it?
 - Another address
 - IP address aaa.bbb.ccc.ddd
 - 4 fields of 8 bits (256 values) per field
 - last field is local network
- Where is that address specified?



Layers

- Need different layers
 - lowest (bottom) for physical transport
 - higher layers as get more removed
 - Which picture makes sense? (first bits on left)
 - (top Header (bot H B T) top Trailer)
 - (bot Header (top H B T) bot Trailer)



Lots of Layers

- seven official layers to ISO, but mostly three:
 - DNS name (domain name system)
 - blah.com blah.edu blah.sg stuff at the end
 - IP address
 - MAC address



What happens at end?

- message arrives at destination machine
- Operating system deals with it -- why?
 - places msg buffer in system memory
- How does OS know the associated app?
 - what are the choices?
 - must specify some type of name
 - done via agreement



Ports

- First allocate socket
- Message contains a port number
- Sending message:
 - must specify port in destination address
- Receiving message
 - application tells OS its associated port



the **Bind** command

Image removed due to copyright restrictions.



Protocols

- Lots of different protocols -- common two:
 - UDP (unreliable) & TCP (reliable)
- Why different protocols?
 - End-to-end argument
 - Don't put stuff in lower layers that may not be needed by the end-points.
 - What is an end-point?
- Specify in socket allocation, AF_INET,SOCK_STREAM

Setting things up

- Client & Server agree on Port number
- Server starts up first
 - specifies protocol, IP, port
 - activates the socket
 - waits for a client to connect
- Client starts up second
 - specifies protocol,
 - Connects to IP, Port



Server Code

```
s = socket.socket(socket.AF INET, socket.SOCK STREAM)
s.bind(("0.0.0.0", port))
s.listen(5)
(client, address) = s.accept()
while True:
  data = client.recv(1024)
  if len(data) == 0: break
client.close()
```



Client Code

```
s = socket.socket(socket.AF_INET, socket.SOCK_STREAM)
s.connect( (sys.argv[1], int(sys.argv[2]) ) )
while True:
    s.send(question)
    ans = s.recv(max_size)
```



Bluetooth

Nearly the same

```
from bluetooth import *
```

```
port = 1
server_sock = BluetoothSocket( RFCOMM )
server_sock.bind( "", port)
server_sock.listen(1)

client_sock, client_info = server_sock.accept()

data = client_sock.recv(1024)

client_sock.close(): server_sock.close()
```

