

## Honeycomb-like materials in nature: wood


- "materials" derives from Latin "materies, materia" means wood or trunk of a tree
- old Irish - names of first letters of the alphabet refer to woods

A	álem	= elm
B	beith	= birch
C	coll	= hazel
D	dair	= oak

## Wood - structure

- orthotropic (if neglect curvature of growth rings)
- $\rho^*/\rho_s$  ranges from 0.05 (balsa) to 0.80 (lignum vitae)
- trees have cambial layer, beneath bark
- cell division @ cambial layer
  - new cells on outer part of cambial layer  $\rightarrow$  bark
  - " " " inner " " " "  $\rightarrow$  wood

# Wood structure



Gibson, L. J., and M. F. Ashby. *Cellular Solids: Structure and Properties*. 2nd ed. Cambridge University Press, © 1997. Figure courtesy of Lorna Gibson and Cambridge University Press.

- living plant cells - plasma membrane + protoplast
- living cells secrete plant cell wall - analogous to extracellular matrix in animal tissues
- in trees, cells lay down cell wall over a few weeks, then die
- always retain a cambial layer of cells


### Cellular structure: softwoods

- tracheids - bulk of cells (90%), provide structural support
  - have holes in cell wall for fluid transport (pits)
  - ~ 25-70 mm long; 20-80  $\mu\text{m}$  across;  $t = 2-7 \mu\text{m}$
- rays - radial arrays of smaller parenchyma cells that store sugars


### Cellular structure: hardwoods

- fibers provide structural support ; 35-70 % of cells
- Vessels - sap channels - conduction of fluids 6-55% of cells
- rays - store sugars; 10-30% of cells

# Softwood: Cedar




tracheids



rays


Gibson, L. J., and M. F. Ashby. *Cellular Solids: Structure and Properties*. 2nd ed. Cambridge University Press, © 1997. Figure courtesy of Lorna Gibson and Cambridge University Press.

# Hardwood: Oak



fibers

vessels



ray

Gibson, L. J., and M. F. Ashby. *Cellular Solids: Structure and Properties*. 2nd ed. Cambridge University Press, © 1997. Figure courtesy of Lorna Gibson and Cambridge University Press.

## Structure: cell wall

- fiber reinforced composite
- cellulose fibers in matrix of lignin / hemi cellulose
- 4 layers, each with fibers at different orientation
- Between 2 cells: middle lamella

## Cell wall properties

- similar in different species of wood

$$\rho_s = 1500 \text{ kg/m}^3$$

(Note cellulose:  $E \sim 140 \text{ GPa}$   
 $\sigma_y \sim 750 \text{ MPa}$ )

$$E_{SA} = 35 \text{ GPa}$$

$$E_{ST} = 10 \text{ GPa}$$


A = axial direction

$$\sigma_{ysA} = 350 \text{ MPa}$$

T = transverse direction

$$\sigma_{ysT} = 135 \text{ MPa}$$

# Wood Structure



Modified; after Fig. 5.14 in Dinwoodie © Van Nostrand Reinhold. All rights reserved. This content is excluded from our Creative Commons license. For more information, see <http://ocw.mit.edu/help/faq-fair-use/>.

## Stress-strain curves

- $\sigma$ - $E$  curves resemble those for honeycombs
- mechanisms of deformation most easily identified on low density balsa
- curves + images for balsa
- tangential loading: formation of plastic hinges in bent cell walls
- radial loading: rays act as reinforcing; plastic yielding in cell walls
  - starts at platens + moves inward
- axial loading: axial def<sup>m</sup> of cell walls; then break end caps  
Serrations correspond to each layer of end caps breaking.


failure by plastic buckling + formation of kink bands also observed

- denser species


Douglas fir - tangential, radial compression

Norway spruce - axial compression

# Stress strain curves



(a)



(b)

Gibson, L. J., and M. F. Ashby. *Cellular Solids: Structure and Properties*. 2nd ed. Cambridge University Press, © 1997. Figure courtesy of Lorna Gibson and Cambridge University Press.

# Balsa

Figure removed due to copyright restrictions. See Figure 3: Easterling, K. E., R. Harrysson, et al. "[On the Mechanics of Balsa and Other Woods.](#)" *Proceedings The Royal of Society. A* 383, no. 1784 (1982): 31-41.

# Balsa: Tangential

Figure removed due to copyright restrictions. See Figure 4: Easterling, K. E., R. Harrysson, et al. "[On the Mechanics of Balsa and Other Woods](#)." *Proceedings The Royal of Society. A* 383, no. 1784 (1982): 31-41.

Figure removed due to copyright restrictions. See Figure 7: Easterling, K. E., R. Harrysson, et al. "[On the Mechanics of Balsa and Other Woods](#)." *Proceedings The Royal of Society. A* 383, no. 1784 (1982): 31-41.

# Balsa: Radial

Figure removed due to copyright restrictions. See Figure 5: Easterling, K. E., R. Harrysson, et al. "[On the Mechanics of Balsa and Other Woods.](#)" *Proceedings The Royal of Society. A* 383, no. 1784 (1982): 31-41.

# Balsa: Axial

Figure removed due to copyright restrictions. See Figure 6: Easterling, K. E., R. Harrysson, et al. "[On the Mechanics of Balsa and Other Woods](#)." *Proceedings The Royal of Society. A* 383, no. 1784 (1982): 31-41.

# Douglas Fir: Tangential Comp

Figure removed due to copyright restrictions. See Bodig, J., and B. A. Jayne.  
*Mechanics of Wood and Wood Composites*. Van Nostrand Reinhold, 1982.

# Douglas fir: Radial comp.

Figure removed due to copyright restrictions. See Bodig, J., and B. A. Jayne.  
*Mechanics of Wood and Wood Composites*. Van Nostrand Reinhold, 1982.

# Norway spruce: Axial comp

Images removed due to copyright restrictions. See Figure 5.14: Dinwoodie, J. M. *Timber: Its Nature and Behaviour*. Van Nostrand Reinhold, 1981.

## Data for wood

$$E^*/E_s \propto \rho^*/\rho_s \quad (\text{axial})$$

$$E^*/E_s \propto (\rho^*/\rho_s)^3 \quad (\text{tangential}; \text{ radial somewhat stiffer})$$

$$\sigma^*/\sigma_{ys} \propto (\rho^*/\rho_s) \quad (\text{axial})$$

$$\sigma^*/\sigma_{ys} \propto (\rho^*/\rho_s)^2 \quad (\text{tangential/radial})$$

$$v_{RT}^* \sim 0.5 - 0.8$$

$$v_{RA}^* \sim 0.02 - 0.07$$

$$v_{AR}^* \sim 0.25 - 0.5$$



$$v_{TE}^* \sim 0.2 - 0.6$$

$$v_{TA}^* \sim 0.01 - 0.04$$

$$v_{AT}^* \sim 0.35 - 0.5$$

## Modelling wood properties

- very simplified model - first order
- does not attempt to capture finer details (e.g. softwoods vs. hardwoods)
- cell wall has been modelled as fiber composite; it is itself anisotropic
- we normalize all properties with respect to  $E_s, \sigma_{ys}$  axial
- constant of proportionality also reflects cell wall anisotropy



Gibson, L. J., and M. F. Ashby. *Cellular Solids: Structure and Properties*. 2nd ed. Cambridge University Press, © 1997. Figure courtesy of Lorna Gibson and Cambridge University Press.

# Model for wood microstructure

Figure removed due to copyright restrictions. See Figure 2: Easterling, K. E., R. Harrysson, et al. "[On the Mechanics of Balsa and Other Woods](#)." *Proceedings The Royal of Society. A* 383, no. 1784 (1982): 31-41.

## Linear elastic moduli

- tangential loading - model as honeycomb - cell wall bending

$$E_T^* / E_S \propto (\rho^*/\rho_s)^3$$

- rays, end caps act to stiffen wood - data lie slightly above  $(\rho/\rho_s)^3$

- radial loading - rays act as reinforcing plates + are higher density than ~~fibers~~

$V_R$  = volume fraction of rays

$$E_R^* = V_R R^3 E_T^* + (1-V_R) E_T^*$$

$$R = (\rho^*/\rho_s)_{\text{rays}} / (\rho^*/\rho_s)_{\text{fibers}} \approx 1.1 \text{ to } 2$$

$$\approx 1.5 E_T^*$$

$E_R^*$  slightly larger than  $E_T^*$ ;  $\propto (\rho/\rho_s)^3$

- axial loading

- axial deformation in cell wall

$$E_A^* / E_S \propto (\rho^*/\rho_s)$$

- explains, to first order, density dependence
  - anisotropy

## Modelling - Poisson's ratios

$$\begin{array}{lll} \nu_{ER}^* = 0.5 - 0.8 & | & \text{constraining effect of} \\ \nu_{TR}^* = 0.2 - 0.6 & | & \text{rays + end caps} \end{array}$$

$$\nu_{RA}^* = 0.02 - 0.07 \quad | \quad 0$$

$$\nu_{TA}^* = 0.01 - 0.04 \quad | \quad 0$$

$$\nu_{AR}^* = 0.25 - 0.5 \quad | \nu_s \quad \text{data close to } 0.4 \sim \nu_s$$

$$\nu_{AT}^* = 0.35 - 0.5 \quad | \nu_s$$

## Modelling - compressive strength

- tangential loading - bending, plastic hinges  $\sigma_T^* / \sigma_{ys} \propto (\rho^*/\rho_s)^2$

$$\text{- radial loading} - \sigma_R^* = V_R R^2 \sigma_T^* + (1-V_R) \sigma_T^*$$



$$\text{balsa: } V_R \sim 0.14 \quad R \sim 2 \quad \sigma_R^* = 1.4 \sigma_T^*$$

higher density woods - R smaller

$\sigma_R^*$  slightly larger than  $\sigma_T^*$ ; both  $\propto (\rho^*/\rho_s)^2$

- axial loading = initial failure by axial yield (then end cap fracture, or buckling)

$$\sigma_A^* / \sigma_{ys} \propto \rho^*/\rho_s$$



Gibson, L. J., and M. F. Ashby. *Cellular Solids: Structure and Properties*. 2nd ed. Cambridge University Press, © 1997. Figure courtesy of Lorna Gibson and Cambridge University Press.

## Modelling: cell wall + cellular structure

- cell wall can be modelled as a fiber composite

cellulose  $E \sim 140 \text{ GPa}$       lignin/hemicellulose  $E \sim 2 \text{ GPa}$

composite upper + lower bounds give envelope at right of figure


measured values for  $E_s$  Axial = 35 GPa     $E_s$  transverse = 10 GPa

- can also show cellular solids model on same plot
- overall, plot shows how wood hierarchical structure, density variation give wood moduli that vary by a factor of 1000
- Can make similar plot for strength

# Wood: Honeycomb Models

$$\frac{E^*}{E_{\text{along}}} = \frac{\rho^*}{\rho_s}$$

$$\frac{E^*}{E_{\text{across}}} = \left( \frac{\rho^*}{\rho_s} \right)^3$$



Cell wall:  
Fiber  
Composite  
Model

# Wood: Honeycomb Models

Diagram removed due to copyright restrictions. See Figure 5b: Gibson, L. J. "[The Hierarchical Structure and Mechanics of Plant Materials](#)." *Journal of the Royal Society Interface* 9 (2012): 2749-66.

## Material selection

- for a beam of a given stiffness,  $P/\delta$ , length,  $l$ , square cross-section with edge length,  $t$ , what material minimizes the mass,  $m$ , of the beam?

$$m = \rho t^2 l$$


$$\delta = \frac{Pl^3}{CEI} \quad \frac{P}{\delta} = \frac{CEt^4}{l^3} \quad t^2 = \left[ \left( \frac{P}{\delta} \right) \frac{l^3}{CE} \right]^{1/2}$$

$$m = \rho \left[ \left( \frac{P}{\delta} \right) \frac{l^3}{CE} \right]^{1/2} l$$

to minimize mass, choose material with min.  $\rho/E^{1/2}$  or maximize  $E^{1/2}/\rho$ .

- material selection chart : plot  $\log E$  vs  $\log \rho$
- line of constant  $E^{1/2}/\rho$  shown in red on plot
- materials with largest values of  $E^{1/2}/\rho$  at upper left of plot
- woods have similar values of  $E^{1/2}/\rho$  as engineering composites
- note that tree trunks, branches, loaded primarily in bending.
- also note, from models,  $\frac{(E^*)^{1/2}}{\rho^*} = \frac{E_s^{1/2}}{\rho_s} \cdot \left( \frac{\rho_s}{\rho} \right)^{1/2}$
- $\Rightarrow$  performance index for wood higher than that for the solid cell wall
- similarly for strength in bending


# Wood in Bending: $E^{1/2}/\rho$



$$\frac{(E^*)^{1/2}}{\rho^*} = \frac{(E_s)^{1/2}}{\rho_s} \left( \frac{\rho_s}{\rho^*} \right)^{1/2}$$

Stiffness performance index for wood in bending is similar to that for best engineering composites

# Wood in Bending: $\sigma_f^{2/3}/\rho$



$$\frac{(\sigma_f^*)^{2/3}}{\rho^*} = \frac{(\sigma_{ys})^{2/3}}{\rho_s} \left( \frac{\rho_s}{\rho^*} \right)^{1/3}$$

Strength performance index for wood in bending is similar to that for best engng composites

## Wood Use in Design

### Historical example: 17<sup>th</sup> century wooden ships

- colonial times, importance of navies to colonial powers
- used particular species for different parts of ship, based on their properties
- oak - used for much of the hull, ribs, knees, planking  $\Rightarrow$  dense wood;   
 "straight oak" - straight pieces, cut from trunk stiff + strong  
 "Compass oak" - curved pieces from trunk + branch, so that grain runs along curved, cut piece  $\Rightarrow$  max E, O  
 - used for knees, wing transom - curved pieces of ship hull.
- eastern white pine - British Royal Navy used for masts, Imported from New England
  - England had run out of tall straight trees for masts
  - strategic resource - ship speed, size depended on size of mast + sail area
  - Eastern white pine known for straight, tall trunks; some over 100' tall
- lignum vitae - densest wood; acts as own lubricant
  - used in block + tackle
  - also used in clock gears ~1760
  - John Harrison's chronometer - storm of Longitude, Davis Sled

H4 1759 lost 5 seconds  
in 81 days at sea

Figure removed due to copyright restrictions. See *The international book of wood*. Bramwell, M, ed. Artists House, 1982. pp 186-87.

## Modern example: glue laminated timber

- glue long pieces of wood, typically 1-2" thick, together
- select strips to avoid defects (eg. knots)
- glu-lam has better mechanical properties than sawn lumber.
- also, can make curved members by using curved molds & clamps during bonding process
  - ⇒ grain runs along the curve - exploits high stiffness + strength of wood
  - ⇒ architecturally attractive along the grain

Image of graceful glued-laminated timber arch bridge removed due to copyright restrictions. See Figure 13: *Engineered Wood Products: A Guide for Specifiers, Designers and Users*. Smulski, S., ed. PFS Research Foundation, 1997.

Engineered Wood Products: A Guide for Specifiers, Designers and Users,  
S. Smulski Ed. PFS Research Foundation, 1997

MIT OpenCourseWare  
<http://ocw.mit.edu>

3.054 / 3.36 Cellular Solids: Structure, Properties and Applications

Spring 2015

For information about citing these materials or our Terms of Use, visit: <http://ocw.mit.edu/terms>.