

Exp No: 11 STUDY OF GPIO & BIT ADDRESSING IN AT89C51

PROGRAM:

```
#include <reg51.h>
```

```
sbit LED1 = P1^0;
```

```
sbit LED2 = P1^1;
```

```
void delay(void)
```

```
{
```

```
    unsigned int i, j;
```

```
    for(i = 0; i < 500; i++)
```

```
    {
```

```
        for(j = 0; j < 500; j++);
```

```
    }
```

```
}
```

```
void main(void)
```

```
{
```

```
    P1 = 0x00;    // Initialize Port 1
```

```
    while(1)
```

```
    {
```

```
        LED1 = 1;    // P1.0 = HIGH
```

```
        LED2 = 0;    // P1.1 = LOW
```

```
        delay();
```

```
        LED1 = 0;    // P1.0 = LOW
```

```
        LED2 = 1;    // P1.1 = HIGH
```

$$\left. \begin{array}{l} \} \\ \} \end{array} \right\}$$
