Chapter 1

Individual spread Footing

1.1 Introduction

Clause 34 of the Code gives the provisions governing the design of reinforced concrete footings. These provisions are similar to those given by the ACI code. The design of footings in accordance with IS: 456—2000 differs from that by the old code in the following aspects.

- 1. Perimeter shear stress must not exceed the allowable value. This aspect was not given in the old code. But it is similar to the familiar concept of punching shear stress.
- 2. Bond-stress-criterion was given in the old code, but it is omitted in the new code. Instead, development length of footing bars is required to be checked at the sections where bending moment is critical.
- 3. 25% excess pressure on edge of footing was allowed by the old code when a footing is eccentrically loaded. This concession is withdrawn by the new Code, thereby adding to the cost of eccentrically loaded footings.

The Code requires footings to be designed for the following limit states.

- 1. Perimeter shear
- 2. Bending moment
- 3. Beam shear
- 4. Development length of footing bars.
- 5. Development length of column bars.

1.1.1 Types of individual Footings

Individual spread footings can be either square or rectangular in plan, the area of a rectangular footing with sides A and B being given by,

$$AXB = \frac{p}{p}(cm^2) \tag{1.1}$$

where P is the column load in kN and p denotes the net allowable soil pressure in kN/cm2. In this development, self-weight of footing may not be considered. This involves only a small error in that, the weight of the concrete of footing is assumed here to be approximately equal to the weight of the earth displaced by it. Further, it is assumed here that the soil pressure under the footing is uniform. This is a reasonable assumption as discussed elsewhere.

The individual spread footings can be of the following types (Fig. 12.1).

Diagrams

With the area of footing known from equation (1.1), dimensions A and B are easily finalised. The only dimension of footing which remains to be known in the depth (D) of the footing. A common way of design of footing is to assume D, rather generously, with a view to reduce steel area as well as to help provide fixity to the column base, in the order to be close to the assumptions made in the frame analysis of superstructure.

1.2 Design for Perimeter Shear

Depth of footing is fixed from the consideration of perimeter shear stress which depends on concrete quality, being independent of types of reinforce steel. For a square footing of uniform depth with a square column of side a (Fig 12.1 a), perimeter shear tv is given by

$$Tv = \frac{Vu}{b_0 \cdot d} = \frac{1.5 \quad S_p}{4(a+d)d} \tag{1.2}$$

Where

$$S_p = P - p.(a+d)^2 (1.3)$$

and b0 = Perimeter of criticle closed section

The allowable perimeter shear stress T_a (clause 31.6.3 of the code) is given by,

diagrams

Where, fck is to be put in N/m^2 .

ks = 1.0 for square columns and also for rectangular with aspect ratio $(\frac{b}{a}) \le 2.0$. For the condition Tv = Ta, equation (12.2) and (12.4) give,

$$\frac{\left[1 - \left(\frac{a}{A}\right)^2 - 2\left(\frac{a}{A}\right)\left(\frac{d}{A}\right) - \left(\frac{d}{A}\right)^2\right]}{\left[\left(\frac{a}{A}\right)\left(\frac{d}{A}\right) + \left(\frac{d}{A}\right)^2\right]} = \frac{0.067\sqrt{fck}}{p} = k(say)$$
(1.4)

For a square sloped footing with a square column of side a (Fig. 12.2 b),

$$Tv = \frac{Vu}{b_0 \cdot d''} = \frac{15.0 \quad S_p}{4(a+d)d''} \cdot \alpha - k(say)$$
(1.5)

Assuming $d = \alpha . d$, the condition $T_v = T_a$ gives,

$$\frac{\left[1 - \left(\frac{a}{A}\right)^2 - 2\left(\frac{a}{A}\right)\left(\frac{d}{A}\right) - \left(\frac{d}{A}\right)^2\right]}{\left[\left(\frac{a}{A}\right)\left(\frac{d}{A}\right) + \left(\frac{d}{A}\right)^2\right]} = \frac{0.067\sqrt{fck}}{p} = k(say)$$
(1.6)

 $\alpha = 1.0$ for footings of Types (a), (b) and (d) (Fig. 12.1), while alpha; 1.0 for sloped footings of Type (c). The overall depth of footing is given by,

$$D = d + c + \phi \tag{1.7}$$

Here, d is regarded as an average value for either steel layer. For sloped footings (Fig. 12.2 b), simple geometry gives,

$$\alpha = \frac{d"}{d} = \frac{D_m}{d} + \frac{D - D_m}{d} \cdot \frac{\left(1 - \frac{a}{A} - \frac{d}{A}\right)}{\left(1 - \frac{a}{A}\right)} \tag{1.8}$$

Chart 12.1 is developed on the basis of equations (12.5) and (12.7) and it applies to both uniformly deep and sloped square footings. It can also be used for rectangular footings with rectangular columns by using average values of a and A, provided an equal overhang is left on all sides of column, which requires,

$$(b-a) = (B=A) \tag{1.9}$$

Solution of numerical examples gives an idea that it is possible to develop thumb rules for xing depth of footings. It may be noted that there is no dire need of exactness in xing the value of depth of footing, only it should be more than adequate for the actions imposed on a footing. Table 12.1, based on equation (12.5), is developed for footings of Types (a) and (b) (Fig.12.1).

It gives values of $\frac{D}{A}$ for various practicable values of p. It is seen that, for safety in beam

shear, these values are to be increased by 10% in case of steel types Fe 415 and Fe 500. For sloped and stepped footings (Types c and d), the depth of footing given by Table 12.1 may be increased by 20%. The depth at the free end of a footing may be restricted to 15 cm, which is the minimum prescribed by the Code for spread footings.

1.3 Design for Moment and Beam Shear

Section 1-1 in Fig. 12.3 is the critical Section for bending moment. The bending moment for full width B is given by,

$$M_1 - 1 = p.B. \frac{(A-a)}{8} (KNcm)$$
 (1.10)

For footings of uniform depth and also stepped footings, the concrete compression zone is rectangular and charts of Chapter 2 are used to calculate the required area of steel. But for slopped footings, the concrete compression zone is of a trapezoidal shape and Chart 4.1 of Chapter 4 is to be used for nding steel area. Chart 4.1 can be used for both uniformly deep ($\gamma = 0$) and sloped footings. The calculated steel area should not be less than the spec1ed minimum steel area (Table 11.4 of Chapter 11) for spread footings which may be regarded as slabs for this purpose.

Section 2-2 in Fig. 12.3 is the critical section for beam shear. The shear force and moment at section 2-2 for the full width of footing is given by,

$$S_2 - 2 = p.B. \left[\frac{A-a}{2} - d \right] (kN)$$
 (1.11)

$$M_2 - 2 = p \cdot \frac{B}{2} \cdot \left[\frac{A - a}{2} - d \right]^2 (kNcm)$$
 (1.12)