

v2.6.2 2023-04-07



Copyright

© 2023 Hanwha Vision Co., Ltd. All rights reserved.

Restriction

Do not copy, distribute, or reproduce any part of this document without written approval from Hanwha Vision Co., Ltd.

Disclaimer

Hanwha Vision Co., Ltd. has made every effort to ensure the completeness and accuracy of this document, but makes no guarantee as to the information contained herein. All responsibility for proper and safe use of the information in this document lies with users. Hanwha Vision Co., Ltd. may revise or update this document without prior notice.

Contact Information

Hanwha Vision Co., Ltd. Hanwha Vision 6, Pangyo-ro 319beon-gil, Bundang-gu, Seongnam-si, Gyeonggi-do, 13488, KOREA www.hanwhavision.com

Hanwha Vision America 500 Frank W. Burr Blvd. Suite 43 Teaneck, NJ 07666 hanwhavisionamerica.com

Hanwha Vision Europe Heriot House, Heriot Road, Chertsey, Surrey, KT16 9DT, United Kingdom hanwhavision.eu

Hanwha Vision Middle East FZE Jafza View 18, Office 2001-2003, Po Box 263572, Jebel Ali Free Zone, Dubai, United Arab Emirates www.hanwhavision.com/ar

Table of Contents

1.	Overview	. 3
	1.1. attributes.cgi	. 3
2.	Attributes	. 4
	2.1. Overview	. 4
	2.2. Attribute request	. 4
	2.3. Group and category	. 4
	2.4. Example data	. 4
	2.5. Attributes	. 6
	2.5.1. System Group	. 6
	2.5.2. Network Group	. 8
	2.5.3. Transfer Group	. 9
	2.5.4. Security Group	. 9
	2.5.5. Media Group	10
	2.5.6. Image Group	12
	2.5.7. PTZSupport Group	17
	2.5.8. Recording Group	19
	2.5.9. EventSource Group	21
	2.5.10. IO Group	28
3.	CGI	29
	3.1. Overview	29
	3.2. Examples	29

Chapter 1. Overview

1.1. attributes.cgi

The attributes and capabilities of Hanwha Vision video surveillance devices are requested by using **attributes.cgi**.

The following CGI command returns device attributes and CGI information including parameters and allowed value ranges in XML format.

```
http://<Device IP>/stw-cgi/attributes.cgi
```

The XML contains two sections.

- attributes
- cgi

Each section can be requested separately. It will be explained in detail in Chapter 2 and Chapter 3.

Chapter 2. Attributes

2.1. Overview

The attributes section of the XML contains a few high-level attributes of the features that the device supports.

2.2. Attribute request

The following command returns only the attributes data.

http://<Device IP>/stw-cgi/attributes.cgi/attributes

2.3. Group and category

Attributes are grouped based on the relevant feature and the CGI that is used. The groups are organized by features and have names such as **System**, **Network**, **Transfer**, etc. Each group is further divided into the following categories:

- **Property**: Whether or not the attribute is supported by the device.
- **Support**: Whether or not the feature is supported.
- **Limit**: The limits of the device regarding the feature e.g. the number of video channels the device has or the maximum number of users it allows.

2.4. Example data

Below is the attributes part of the XML file.

The **attributes** part consists of groups such as System, Network, IO, etc. The System group has 3 categories: Property, Support, and Limit. It provides information such as the NIC count and the maximum number of channels (shown in the Limit category) as well as whether or not system configurations or firmware updates are supported (shown in the Support category).

```
<attributes>
<group name="System">
 <category name="Property">
   <attribute name="ISPVersion" type="bool" value="True" accesslevel="guest" />
   <attribute name="PTZBoardVersion" type="bool" value="False"</pre>
        accesslevel="guest" />
   <attribute name="InterfaceBoardVersion" type="bool" value="False"</pre>
        accesslevel="guest" />
 </category>
 <attribute name="ConfigRestore" type="bool" value="True" accesslevel="admin"/>
   <attribute name="ConfigBackup" type="bool" value="True" accesslevel="admin" />
   <attribute name="FWUpdate" type="bool" value="True" accesslevel="admin" />
<attribute name="NICCount" type="int" value="1" accesslevel="guest" />
   <attribute name="MaxChannel" type="int" value="1" accesslevel="guest" />
...</category>
</group>
```

2.5. Attributes

The following is an attribute table.

2.5.1. System Group

Category	Attribute	Туре	Access Level			
			Camera	NVR	Decoder	Encoder
Property	MicomVersion	bool		User	User	
	ISPVersion	bool	Guest			Guest
	PTZBoardVersion	bool	Guest			Guest
	InterfaceBoardVersion	bool	Guest			Guest
	TrackingVersion	bool	Guest			Guest
	BootLoaderVersion	bool	Guest			Guest
	ModelName	string	Guest	User	User	Guest
	ONVIFVersion	string	Guest	User	User	Guest
	SUNAPIVersion	string	Guest	User	User	Guest

Category	Attribute	Туре		Acce	ess Level	
	FirmwareVersion	string	Guest	User	User	Guest
	ModelType	enum	Guest			
Support	GlobalConfiguration	bool		User	User	
	RS422	bool	Admin			Admin
	ConfigRestore	bool	Admin	Admin	Admin	Admin
	ConfigRestore.ExcludeGroups	enum	Admin	Admin	Admin	Admin
	ConfigRestore.ExcludeGroups.Net work.Selectable	bool	Admin	Admin	Admin	Admin
	ConfigRestore.ExcludeGroups.Ca mera.Selectable	bool		Admin	Admin	
	ConfigRestore.ExcludeGroups.Aut hority.Selectable	bool		Admin	Admin	
	ConfigBackup	bool	Admin	Admin	Admin	Admin
	FWUpdate	bool	Admin	User	User	Admin
	Shutdown	bool		User	User	
	Restart	bool	Admin			Admin
	GPS	bool		User		
	AutoBackup	bool		User		
	DigitalSignage	bool		User		
	OpenSDK	bool	Admin			Admin
	FreeStyleSplitMode	bool			User	
	DisplayMerge	CSV			User	
	SDCardEncryption	bool	Suser			
	FullDuplex	bool		User		
	OneOpenAppPerChannel	bool	Suser			
	SupportChannelExpansionFeature	bool	Guest			
	LogServer	bool	Admin	User		Admin
	AIFeatures	bool		User		
	AIEngine	bool		User		
	Stratocast	bool	Admin			
	HybridThermal	bool	Guest			
	ManufacturerChange	bool	Admin			
	SSDStorage	bool	Admin			

Category	Attribute	Туре		Acces	s Level	
	LocalVMS	bool	Admin			
	VirtualCropChannel	bool	Guest			
	MultiLanguageEventSchema	bool	Admin			
	LiveEventDisplay	bool		User		
	PowerMode	bool	Guest			
Limit	MaxHDMIOut	int	Guest			Guest
	NICCount	int	Guest	User	User	Guest
	MaxChannel	int	Guest	User	User	Guest
	MaxPOS	int		User		
	MaxVGAOut	int			User	
	MaxHDMIOut	int	ADMIN	User	User	ADMIN
	MaxHDMIIn	int			User	
	MaxLiveSession	int		User		
	MaxSearchSession	int		User		
	MaxBackupSession	int		User		
	OpenSDK.MaxApps	int	Admin			Admin
	MaxSSDStorage	int	Admin			
	MaxPartitionPerSSD	int	Admin			
	MaxAnalog	int		User		
	MaxVGASpotCount	int		User		
	MaxAnalogSpotCount	int		User		
	ChannelExpansionLimit	int	Guest			
	MaxAudioSubDevices AMS ONLY	int	Guest			
	MaxSpeakerGroups AMS ONLY	int	Guest			

2.5.2. Network Group

Category	Attribute	Туре	Access Level			
			Camera	NVR	Decoder	Encoder
Limit	MaxIPv4Filter	int	Guest	User	User	Guest
	MaxIPv6Filter	int	Guest	User	User	Guest
	MaxIPv4QoS	int	Guest	User	User	Guest

Category	Attribute	Туре		Acces	s Level	
	MaxIPv6QoS	int	Guest	User	User	Guest
	MaxNetCam	int		User		
	MaxSIPAccountCount	int	Guest			
	MaxRecipientCount	int	Guest			
	MaxRecipientInGroup		Guest			
Support	BandwidthControl	bool		User	User	
	POE	bool		User	User	
	WiFi	bool	Admin	User	User	Admin
	TUTK	bool		User	User	
	POEExtender	bool	Admin			
	MTUSize	bool	Guest			
	SIP	bool	Admin			
	DDNSP2P	bool		User		
	MQTT	bool	Admin			

2.5.3. Transfer Group

Category	Attribute	Туре	Access Level			
			Camera NVR Decoder Er		Encoder	
Support	port SMTP bool		Admin	User		Admin
	НТТР	bool	Admin	User Admi		Admin
	FTP	bool	Admin	User		Admin
	DataServer	bool	Guest			
Limit	SMTP.MaxRecipients		Admin			Admin

2.5.4. Security Group

Category	Attribute	Туре		Access Level		
			Camera NVR Decoder Er		Encoder	
Limit	MaxAdditionalPasswords	int		User	User	
	MaxUser	int	Guest	User	User	Guest
	MaxGroup	int		Admin	Admin	
	MaxUserPerGroup	int		Admin	Admin	
	MaxSMTPGroup	int		User	User	
	MaxSMTPUser	int		User	User	

Category	Attribute	Туре		Access Level	
	MaxSMTPUserPerGroup	int	User User		User
Support	AdminIDChangeable	bool	Admin	User	User
	ClientCertificateAuthentication	bool	Admin		
	AdminAccess	bool	Admin		
	MaxSelfSignedCertificates	int	Guest		
	NewPasswordPolicy	bool	Guest User		
	CurrentPasswordVerification	enum			

2.5.5. Media Group

Categor y	Channel	Attribute	Туре		Acc	ess Level	
				Camera	NVR	Decoder	Encoder
Limit	Channel.	MaxAudioInput	int	Guest	User	User	Guest
		MaxAudioOutput	int	Guest	User	User	Guest
		MaxProfile	int	Guest	User	User	Guest
		MaxResolution	enum	Guest			Guest
	Streamin gMetada ta		CSV		User		
	Streamin gProfiles		CSV		User		
	MaxVide oOutput		int	Guest			
	MaxAudi oInput		int	Guest			
Support	Channel.	WiseStream	bool	Guest			Guest
		DynamicGOV	bool	Guest			Guest
		DynamicFPS	bool	Guest			
		Protocol.SUNAPI	bool		User	User	
		ChannelAudioOutput	bool		User	User	
		DeviceAudioOutput	bool	Suser			Suser
		MultiAudioOutput	Bool	Admin			Admin
		AudioIn	bool	Suser	User	User	Suser

Categor y	Channel	Attribute	Туре		Acces	s Level	
J		VideoOut	bool	Suser			
		ATC	bool	Guest			Guest
		Crop	bool	Guest			Guest
		VideoEncodingType	enum	Guest	User	User	Guest
		AudioEncodingType	enum	Guest	User	User	Guest
		VideoSetting	bool	Admin			Admin
		ExactTimeStamp	bool	Guest			Guest
		Live	bool	Guest	User		Guest
		FixedProfileCodecChange	bool	Guest			Guest
		ShowNonVideoProfile	bool	Guest			Guest
		ProfileAddByIndex	bool	Admin			Admin
		Stream.UDP	bool	Guest	User		Guest
		Stream.TCP	bool	Guest	User		Guest
		Stream.Multicast	bool	Guest	User		Guest
		Stream.MulticastIPV6	bool	Guest			
		Stream.RTPOverRTSPOverTCP	bool	Guest	User		Guest
		Stream.RTSPOverHTTP	bool	Guest	User		Guest
		Stream.RTSPOverHTTPS	bool	Guest	User		Guest
		Stream.MultiProfiles	bool		User		
		Stream.Metadata	bool		User		
		Stream.SRTP.UDP	bool	Guest			
		Stream.SRTP.TCP	bool	Guest			
		Stream.SRTP.Multicast	bool	Guest			
		Stream.SRTP.RTSPOverRTSPO verTCP	bool	Guest			
		Stream.SRTP.RTSPOverHTTP	bool	Guest			
		Stream.SRTP.RTSPOverHTTPS	bool	Guest			
		Stream.RTSPBlocksize	bool	Guest			
		Stream.BackchannelOverPost	bool		admin		
		Metadata.ImageType	CSV	Guest			
		Metadata.ImageTransfer	bool	Guest			
		Metadata.ClassTypes	bool	Guest			

Categor y	Channel	Attribute	Туре	Access Level
		Metadata.ClassTypeDetails	bool	Guest
		SensorCaptureMode	bool	Guest
		DynamicPrivacyMask	bool	Guest
	GlobalSe nsorMod e		bool	Guest
	Metadat aShare		bool	Guest
	Dynamic PrivacyM ask		bool	Guest

2.5.6. Image Group

Categor y	Channel	l Attribute	Туре	Access Level				
				Camera	NVR	Decoder	Encoder	
Limit	Channel.	MaxSmartCodecArea	int	Guest			Guest	
		MaxPrivacyMask	int	Guest			Guest	
		MaxPrivacyMask.Rectangle	int	Guest			Guest	
		MaxPrivacyMask.Polygon	int	Guest			Guest	
		MaxOSDTitles	int	Guest			Guest	
		MaxOSDDates	int	Guest			Guest	
		ViewModes	int	Guest			Guest	
		ViewModes.MaxActive	int	Guest			Guest	
		MaxIRZoneCountInCeilingMo de	int	Guest				
		MaxIRZoneCountInWallMode	int	Guest				
		MaxFocusPreset	int	Guest				
		MaxIRZoneCount	int	Guest				
Support	Channel.	Defog	bool	Admin	User		Admin	
		ProfileBasedDewarpedView	bool	Guest	User		Guest	
		MultiImager	bool	Guest	User		Guest	
		OSDLanguages	CSV	Guest			Guest	

Categor y	Channel	Attribute	Туре	Access Level		
		Gamma	bool	Admin		Admin
		Saturation	bool	Admin		Admin
		Sharpness	bool	Admin		Admin
		Brightness	bool	Admin		Admin
		ResetFocus	bool		User	
		SimpleFocus	bool		User	
		SimpleFocus.FocusArea	bool	Admin		Admin
		PrivacyMask.ZoomThreshold	bool	Suser		Admin
		Privacy.MaskColor.Global	bool	Suser		Admin
		FocusAdjust	bool	Admin		
		ZoomAdjust	bool	Admin		
		IRLED	bool	Admin		
		ZoneBasedIRLED	bool	Guest		
		DIS	bool	Admin		
		P-Iris	bool	Admin		
		DayNight	bool	Admin		
		FisheyeLens	bool	Guest	User	
		DewarpedView	bool	Guest	User	
		ThermalFeatures	bool	Guest		
		PTRZ	bool	Suser		
		ViewModes.360Panorama	bool	Guest		
		ViewModes.360Panorama.Sub Views	int	Guest		
		ViewModes.360Panorama.PTZ	bool	Guest		
		ViewModes.360Panorama.PTZ .Features	CSV	Guest		
		ViewModes.OneOverviewAndT ripleView	bool	Guest		
		ViewModes.OneOverviewAndT ripleView.SubViews	int	Guest		
		ViewModes.OneOverviewAndT ripleView.PTZ	bool	Guest		

Categor y	Channel	Attribute	Туре	Access Level		
		ViewModes.OneOverviewAndT ripleView.PTZ.Features	CSV	Guest		
		ViewModes.OneOverviewAnd OctaView	bool	Guest		
		ViewModes.OneOverviewAnd OctaView.SubViews	int	Guest		
		ViewModes.OneOverviewAnd OctaView.PTZ	bool	Guest		
		ViewModes.OneOverviewAnd OctaView.PTZ.Features	CSV	Guest		
		ViewModes.Overview	bool	Guest		
		ViewModes.Overview.SubView s	int	Guest		
		ViewModes.Overview.PTZ	bool	Guest		
		ViewModes.Overview.PTZ.Feat ures	CSV	Guest		
		ViewModes.LeftHalfView	bool	Guest		
		ViewModes.LeftHalfView.SubV iews	int	Guest		
		ViewModes.LeftHalfView.PTZ	bool	Guest		
		ViewModes.LeftHalfView.PTZ.F eatures	CSV	Guest		
		ViewModes.RightHalfView	bool	Guest		
		ViewModes.RightHalfView.Sub Views	int	Guest		
		ViewModes.RightHalfView.PTZ	bool	Guest		
		ViewModes.RightHalfView.PTZ .Features	CSV	Guest		
		ViewModes.SingleView	bool	Guest		
		ViewModes.SingleView.SubVie ws	int	Guest		
		ViewModes.SingleView.PTZ	bool	Guest		
		ViewModes.SingleView.PTZ.Fe atures	CSV	Guest		
		ViewModes.QuadView	bool	Guest		

Categor y	Channel	Attribute	Туре	Access Level	
		ViewModes.QuadView.SubVie ws	int	Guest	
		ViewModes.QuadView.PTZ	bool	Guest	
		ViewModes.QuadView.PTZ.Fea tures	CSV	Guest	
		ViewModes.QuadView.#	bool	Guest	
		ViewModes.QuadView#.SubV iews	int	Guest	
		ViewModes.QuadView#.PTZ	bool	Guest	
		ViewModes.QuadView#.PTZ.F eatures	CSV	Guest	
		ViewModes.Panorama	bool	Guest	
		ViewModes.Panorama.SubVie ws	int	Guest	
		ViewModes.Panorama.PTZ	bool	Guest	
		ViewModes.Panorama.PTZ.Fe atures	CSV	Guest	
		ViewModes.DoublePanorama	bool	Guest	
		ViewModes.DoublePanorama. SubViews	int	Guest	
		ViewModes.DoublePanorama. PTZ	bool	Guest	
		ViewModes.DoublePanorama. PTZ.Features	CSV	Guest	
		ViewModes.CropView	bool	Guest	
		ViewModes.CropView.SubView s	int	Guest	
		ViewModes.CropView.PTZ	bool	Guest	
		ViewModes.CropView.PTZ.Feat ures	CSV	Guest	
		NormalizedOSDRange	bool	Guest	Guest
		AutoImageAlignmentSupport	bool	Guest	
		ImageSettings	bool	Admin	
		Iris	bool	Admin	
		Iris-Fno	bool	Admin	

Categor y	Channel	Attribute	Туре	Access Level
		LDC	bool	Admin
		Crop	bool	Admin
		DynamicArea	bool	Guest
		AutoFocus	bool	Admin
		DirectionIndicator	bool	Suser
		OSDArrow	bool	Suser
		Contrast	bool	Admin
		WhiteBalance	bool	Admin
		BackLight	bool	Admin
		DayNightSwitchThresholdAdju st	bool	Admin
		XCE	bool	Admin
		FocusContinuousAdjust	bool	Admin
		ZoomContinuousAdjust	bool	Admin
		AntiFlicker	bool	Guest
		AGC	bool	Guest
		ShutterControl	bool	Guest
		ThermalVariationSensitivity	bool	Guest
		FocusPreset	bool	Guest
		HorizontalFlip	bool	Guest
		VerticalFlip	bool	Guest
		Rotate	enum	Guest
		UnifiedFlip	bool	Guest
		RotateAndLDCIncompatible	bool	Admin
		RotateAndVideoOutIncompati ble	bool	Admin
		PrivacyIndexReorder	bool	Guest
		ImageAlignment	CSV	Guest
		ThermalNUC	bool	Guest
		PrivacyAndDISIncompatible	bool	Admin
	GlobalRo tateView		bool	Guest

Categor y	Channel	Attribute	Туре	Access Level		
	GlobalLD CMode		bool	Guest		
	GlobalM askPatte rn		bool	Guest		
	GlobalM ultiImag eOSD		bool	Guest		

2.5.7. PTZSupport Group

Categor y	Channel	Attribute	Туре		Acces	s Level	
				Camera	NVR	Decoder	Encoder
Support	Channel.	Preset	Bool	Suser	User	User	Suser
		Swing	Bool	Suser	User	User	Suser
		Group	Bool	Suser	User	User	Suser
		DigitalZoom	Bool	Suser			Suser
		Trace	bool	Suser	User	User	Suser
		AutoRun	bool	Suser	User	User	Suser
		Home	bool	Suser	User	User	Suser
		Tour	bool	Suser	User	User	Suser
		PresetRename	bool	Admin	User	User	Admin
		PTZLimit	bool	Admin	User	User	Admin
		AreaZoom	bool	Suser	User	User	Suser
		Query.Pan	bool	Suser	User	User	Suser
		Query.Tilt	bool	Suser	User	User	Suser
		Query.Zoom	bool	Suser	User	User	Suser
		Query.Focus	bool	Suser	User	User	Suser
		Query.Iris	bool	Suser	User	User	Suser
		OSDMenu.On	bool	Admin	User	User	Admin
		OSDMenu.Off	bool	Admin	User	User	Admin
		OSDMenu.Up	bool	Admin	User	User	Admin
		OSDMenu.Down	bool	Admin	User	User	Admin

Categor y	Channel	Attribute	Туре		Acces	s Level	
		OSDMenu.Right	bool	Admin	User	User	Admin
		OSDMenu.Left	bool	Admin	User	User	Admin
		OSDMenu.Select	bool	Admin	User	User	Admin
		OSDMenu.Return	bool	Admin	User	User	Admin
		Absolute.Pan	bool	Suser	User	User	Suser
		Absolute.Tilt	bool	Suser	User	User	Suser
		Absolute.Zoom	bool	Suser	User	User	Suser
		Absolute.Focus	bool	Suser	User	User	Suser
		Absolute.Iris	bool	Suser	User	User	Suser
		Absolute.PanSpeed	bool	Suser	User	User	Suser
		Absolute.TiltSpeed	bool	Suser	User	User	Suser
		Absolute.ZoomSpeed	bool	Suser	User	User	Suser
		Continuous.Pan	bool	Suser	User	User	Suser
		Continuous.Tilt	bool	Suser	User	User	Suser
		Continuous.Zoom	bool	Suser	User	User	Suser
		Continuous.Focus	bool	Suser	User	User	Suser
		Continuous.Iris	bool	Suser	User	User	Suser
		Continuous.PanSpeed	bool	Suser	User	User	Suser
		Continuous.TiltSpeed	bool	Suser	User	User	Suser
		Continuous.ZoomSpeed	bool	Suser	User	User	Suser
		Relative.Pan	bool	Suser	User	User	Suser
		Relative.Tilt	bool	Suser	User	User	Suser
		Relative.Zoom	bool	Suser	User	User	Suser
		Relative.Focus	bool	Suser	User	User	Suser
		Relative.Iris	bool	Suser	User	User	Suser
		3AxisPTZ	bool	Suser	User	User	Suser
		Azimuth	bool	Suser			Suser
		ProfileBasedDigitalPTZ	bool	Suser			
		DigitalAutoTracking	bool	Suser	User	User	Suser
		DigitalPTZ	bool	Suser	User	User	Suser
		ExternalPTZ	bool	Suser			Suser
		RealPTZ	bool	Suser			Suser

Categor y	Channel	Attribute	Туре		Access Level				
		ZoomOnly	bool	Suser			Suser		
		AuxCommands	CSV	Suser	User	User			
		PanTiltOnly	bool	Suser					
		PanZeroPosition	bool	Suser					
		SmartZoom	bool	Suser					
		PTCorrection	bool	Suser					
		AIAutoTracking	bool	Suser					
		PresetImageConfig	bool	Suser					
		PresetVideoAnalysis	bool	Suser					
		MountPosition	bool	Suser					
	GlobalPT ZMode		bool	Suser					
	DigitalRT ZOnlyInD efaultSet tings		bool	Suser					
Limit	Channel.	MaxPreset	int	Guest	User	User	Guest		
		MaxGroupCount	int	Guest	User	User	Guest		
		MaxTourCount	int	Guest	User	User	Guest		
		MaxTraceCount	int	Guest	User	User	Guest		
		MaxPresetCountPerGroup	int	Guest	User	User	Guest		
		MaxGroupCountPerTour	int	Guest	User	User	Guest		

2.5.8. Recording Group

Categor y	Channel or Attribute	Attribute	Туре	Access Level			
				Camera	NVR	Decoder	Encoder
Support	Channel.#	QueueManagemen t	bool	Admin			
		SearchVideoSumm ary	bool		User		
		Backup	bool	Admin	User		
		SearchCalendar	bool	Admin	User		

Categor y	Channel or Attribute	Attribute	Туре		Access Level
		SearchTimeline	bool	Admin	User
		SearchEvent	bool	Admin	User
		SearchMotionGrid	bool		User
		PeopleCountSearch	bool	Admin	
		SmartSearch	bool		User
		SearchHeatMap	bool		User
		AISearchTypes	CSV		User
		SearchBookmark	bool		User
	SearchMetadata		bool		User
	ContinuousPlayNVR		bool		User
	RecordStreamLimit ation		bool	Guest	
	RAID		bool		User
	FailOverRecording		bool		User
	SearchPOS		bool		User
	SearchPeriod		bool		User
	Recording		bool	Admin	User
	ManualRecordingSt art		bool		User
	ManualRecordingSt op		bool		User
	RecordingStatus		bool	Admin	User
	Overlapped		bool	Admin	User
	PlaybackType		enum	Admin	User
	PlaybackSpeed		enum	Admin	User
	NAS		bool	Admin	
	iSCSI		bool	Admin	User
	SearchByUTCTime		bool	Admin	User
	HeatMapGridArea		string		User
	RecordPriorityOrde r		CSV		User
	DualTrackRecordin g		bool		Guest

Categor y	Channel or Attribute	Attribute	Туре		Access Level		
	DiskUtility		CSV		User		
	DistributedRecordi ng		bool		User		
	GlobalRecordFileTy pe		bool	Guest			
Limit	MaxPlaybackChann els		int		User		
	MaxSmartSearchDa ys		int		User		
	MaxMetadataSearc hDays		int		User		
	MaxSmartSearchIn cludeAreas		int		User		
	MaxSmartSearchEx cludeAreas		int		User		
	MaxSmartSearchLin es		int		User		
	NumberOfStorage Devices		int	Admin	User		
	PreferRecordingCo dec		enum	Admin			
	RecordingGOVLeng thMultiplierFactor		float	User			

2.5.9. EventSource Group

Categor y	Channel or Attribute	Attribute	Туре		Access Level				
				Camera	NVR	Decoder	Encoder		
Limit	Channel.#	MaxROI.Include	int	Guest			Guest		
		MaxROI.Exclude	int	Guest			Guest		
		MaxIVRule.Area.Incl ude	int	Guest			Guest		
		MaxIVRule.Area.Exc lude	int	Guest			Guest		
		MaxIVRule.Line	int	Guest			Guest		

Categor y	Channel or Attribute	Attribute	Туре		Access Level			
		MaxFaceDetection. Area.Include	int	Guest			Guest	
		MaxFaceDetection. Area.Exclude	int	Guest			Guest	
		MaxParkingArea	int	Guest				
		MaxExcludeParking Area	int	Guest				
	MaxQueues		int	Guest			Guest	
	MaxPeopleCountRu le		int	Guest				
	MaxHeatMap.Area. Exclude		int	Guest				
	MaxROI		int	Guest			Guest	
	MaxFaceDetectionA rea		int	Guest			Guest	
	MaxTamperingDete ctionArea		int	Guest			Guest	
	MaxTrackingArea		int	Guest			Guest	
	MaxAlarmInput		int	Guest	User	User	Guest	
	MaxNetworkAlarmI nput		int		User	User		
	MaxIVRule		int	Guest			Guest	
	MaxIVRule.Line		int	Guest			Guest	
	MaxIVRule.Area		int	Guest			Guest	
	ROICoordinate.Min X		int	Guest			Guest	
	ROICoordinate.Min Y		int	Guest			Guest	
	ROICoordinate.Max		int	Guest			Guest	
	ROICoordinate.Max Y		int	Guest			Guest	
	MaxIVRule.Area.Incl ude		int	Guest			Guest	
	MaxIVRule.Area.Exc		int	Guest			Guest	

Categor y	Channel or Attribute	Attribute	Туре		Acces	s Level	
	MaxROI.Include		int	Guest			Guest
	MaxROI.Exclude		int	Guest			Guest
	MaxCoordinate.Defi nedArea.AppearDis appear		int	Guest			Guest
	MaxCoordinate.Defi nedArea.Entering		int	Guest			Guest
	MaxCoordinate.Defi nedArea.Exiting		int	Guest			Guest
	MaxHeatMapLevel		int	Guest			Guest
	MaxBoxTemperatur eDetectionArea		int	Guest			
	MaxBodyTemperat ureDetectionArea		int	Guest			
	MaxDTMFCodeCou nt		int	Guest			
	MaxDynamicRule		int	Admin			
	MaxDynamicRule.E ventSource		int	Admin			
	MaxScheduleCount		int	Admin			
	MaxMQTTMessage Count		int	Admin			
	MaxMQTTSubscript ionCount		int	Admin			
	MaxAudioFiles AMS ONLY		int	Guest			
	MaxTTSFiles AMS ONLY		int	Guest			
Support	Channel.#	VideoAnalytics	CSV	Guest	User	User	Guest
		AudioAnalytics	CSV	Guest	User	User	Guest
		ThermalGridArea	string	Admin			Admin
		IVRule	bool	Admin			Admin
		GetIVRule	bool	Admin			Admin
		OverlayIVRule	bool	Guest			Guest

Categor y	Channel or Attribute	Attribute	Туре		Acces	s Level	
		AdjustMDIVRuleOn FlipMirror	bool	Guest			Guest
		ObjectDetection	bool	Guest	Admin		
		ObjectTypes	CSV		Admin		
		ObjectDetection.Ev entActions	CSV	Guest			
		FaceDetection	bool	Guest			Guest
		HeadDetection	bool	Guest			
		FaceDetection.Even tActions	CSV	Guest			Guest
		Tracking	bool	Guest			Guest
		Tracking.EventActio	CSV	Guest			Guest
		Metadata	bool	Admin	User	User	Admin
		AdvancedMotionDe tection	bool		User	User	
		BodyTemperatureD etection	bool	Guest			
		BodyTemperatureD etection.EventActions	CSV	Guest			
		BoxTemperatureDe tection	bool	Guest			
		TamperingDetectio n.DarknessDetectio n	bool	Guest			
		MaskDetection	bool	Guest			
		MaskDetection.Eve ntActions	CSV	Guest			
		ParkingDetection	bool	Guest			
		ParkingDetection.E ventActions	CSV	Guest			
		LEDIndicator	bool	Guest			
		LEDIndicator.Sourc eChannel	CSV	Guest			
		CallRequest	bool	Guest			

Categor y	Channel or Attribute	Attribute	Туре	Access Level			
		CallRequest.EventA ctions	CSV	Guest			
		TamperingSwitch	bool	Guest			
		TamperingSwitch.E ventActions	CSV	Guest			
		DTMF	bool	Guest			
		DTMF.EventActions	CSV	Guest			
		ProximitySensor	bool	Guest			
		ProximitySensor.Ev entActions	CSV	Guest			
		SocialDistancingViol ation	bool	Guest			
		SocialDistancingViol ation.EventActions	CSV	Guest			
	ROIType		enum	Admin			Admin
	TamperingDetectio n		bool	Guest			Guest
	NetworkAlarmInput		bool		User	User	
	AlarmInput		bool	Guest	User	User	Guest
	AlarmOutput		bool	Guest	User	User	Guest
	AudioDetection		bool	Guest	User	User	Guest
	UserInput		bool	Guest			Guest
	UserInput.EventActi ons		CSV	Guest			Guest
	NetworkDisconnect		bool	Guest	User	User	Guest
	VideoLoss		bool		User	User	
	VA.Passing		bool	Guest			Guest
	VA.Enter		bool	Guest			Guest
	VA.Exit		bool	Guest			Guest
	VA.Appear		bool	Guest			Guest
	VA.Disappear		bool	Guest			Guest
	VA.MotionDetection		bool	Guest			Guest
	VA.MotionDetection .Overlay		bool	Guest			Guest

Categor y	Channel or Attribute	Attribute	Туре		Acc	ess Level	
	VA.MotionDetection .ObjectSize		bool	Guest			Guest
	VA.AppearDisappea rType		enum	Admin			Admin
	VA.Intrusion		bool	Guest			Guest
	VA.Loitering		bool	Guest			Guest
	TamperingDetection.EventActions		CSV	Guest	User	User	Guest
	AlarmInput.EventAc tions		CSV	Guest	User	User	Guest
	AudioDetection.Eve ntActions		CSV	Guest	User	User	Guest
	NetworkDisconnect .EventActions		CSV	Guest	User	User	Guest
	VideoLoss.EventActi ons		CSV	Guest	User	User	Guest
	VA.MotionDetection .EventActions		CSV	Guest	User	User	Guest
	Timer		bool	Guest			Guest
	Timer.EventActions		CSV	Guest			Guest
	DefocusDetection		bool	Guest			Guest
	DefocusDetection.E ventActions		CSV	Guest	User	User	Guest
	OpenSDK		bool	Guest			Guest
	OpenSDK.EventActi		CSV	Guest			Guest
	FogDetection		bool	Guest			Guest
	FogDetection.Event Actions		CSV	Guest	User	User	Guest
	TemperatureChang eDetection		bool	Guest			Guest
	TemperatureChang eDetection.EventAc tions		CSV	Guest			Guest
	ShockDetection		bool	Guest			Guest

Categor y	Channel or Attribute	Attribute	Туре	Access Level			
	ShockDetection.Eve ntActions		CSV	Guest			Guest
	AudioAnalysis		bool	Guest			Guest
	WaterLevelWarning		bool	Guest			
	HousingTampering		bool	Guest			
	BoxTemperatureDe tection.EventAction s		CSV	Guest			
	BodyTemperatureD etection		bool	Guest			
	BodyTemperatureD etection.EventActions		CSV	Guest			
	TamperingDetectio n.DarknessDetectio n		bool	Guest			
	ChannelBasedROIC oordinate		bool	Guest			
	GlobalAudioDetecti on		bool	Guest			
	GlobalAudioAnalysi s		bool	Guest			
	CallRequest		bool	Guest			
	CallRequest.EventA ctions		CSV	Guest			
	TamperingSwitch		bool	Guest			
	TamperingSwitch.E ventActions		CSV	Guest			
	DTMF		bool	Guest			
	DTMF.EventActions		CSV	Guest			
	ProximitySensor		bool	Guest			
	ProximitySensor.Ev entActions		CSV	Guest			
	DynamicRule		bool	Admin			

2.5.10. IO Group

Category	Attribute	Туре	Access Level				
			Camera	NVR	Decoder	Encoder	
Limit	MaxAlarmOutput	int	Guest	User	User	Guest	
	MaxAux	int	Guest	User	User	Guest	
	MaxConfigurableIO	bool	Guest				
Support	AlarmOutput	bool	Suser	User	User	Suser	
	Aux	bool	Suser	User	User	Suser	
	RS485	bool	Suser	User		Suser	
	AlarmReset	bool	Admin	User		Admin	
	PowerRelayIndices	int	Suser				
	ConfigurableIO	bool	Suser				

Chapter 3. CGI

3.1. Overview

Each CGI part of the XML represents the submenus, actions and parameters available in the corresponding CGI. The XML data contains the parameter data type, allowed ranges/values and type of parameter (request/response).

The following command returns only the cgi part of the XML.

http://<Device IP>/stw-cgi/attributes.cgi/<cgi name>

3.2. Examples

The following example shows a request for only the system-related submenus and parameters of the device.

REQUEST

http://<Device IP>/stw-cgi/attributes.cgi/system

RESPONSE

HTTP Code: 200 OK

Content-Type: text/xml

<Body>

```
<cgi name="system">
<submenu name="deviceinfo">
     <action name="view" accesslevel="guest">
              <parameter name="Model" request="false" response="true">
            <dataType>
                                        <string maxlen="31" />
            </dataType>
       </parameter>

cparameter name="FirmwareVersion" request="false" response="true">
             <dataType>
                             <string maxlen="15" />
          </dataType>
              </action>
      <action name="set" accesslevel="admin">
                  <parameter name="DeviceName" request="true" response="true">
                            <dataType>
                                      <string maxlen="8" />
            </dataType>
      </parameter>

continue | continue 
             <dataTvpe>
                         <enum>
                                       <entry value="English" />
                                      <entry value="Korean" />
                         </enum>
           </dataType>
                </action>
</submenu>
```

```
<submenu name="date">
 <action name="view" accesslevel="guest">
  <parameter name="LocalTime" request="false" response="true">
        <string format="YYYY-MM-DD hh:mm:ss"/>
 </dataType>
 </parameter>
 </action>
 માનુકાનુકાર
<action name="set" accesslevel="admin">
   <parameter name="SyncType" request="true" response="true">
  <dataType>
    <enum>
       <entry value="NTP"/>
       <entry value="Manual"/>
     </enum>
  </dataType>

  <dataType>
     <csv>
       <entry value="MaxEntries=5"/>
     </csv>
       </dataType>
  </action>
</submenu>
<submenu name="systemlog">
</submenu>
</cgi>
```