

Crack remediation procedures:

1. Clean the surface...
2. Apply filler...
3. Cure for 24 hours.

Root cause: thermal stress. Similar cases: crack_0.jpg, crack_1.jpg