
PUMP_1
PRV-1
PRV-2
PRV-3
Main zone (fed by PRV-1, PRV-2)
Sub-zone (fed by PRV-3)
Tank zone (fed by PUMP_1, T1)
PRV or pump
Pressure sensor
Reservoir
Tank