IQ Modulator Board

Manu T S manu.ts@ee.iitb.ac.in

Department of Electrical Engineering Indian Institute of Technology Bombay

July 7, 2014

Any passband signal $s_p(t)$ can be written as

Any passband signal $s_p(t)$ can be written as

$$s_{\rm p}(t) = \sqrt{2}s_{\rm i}(t)\cos(2\pi f_c t) - \sqrt{2}s_{\rm q}(t)\sin(2\pi f_c t)$$

Any passband signal $s_p(t)$ can be written as

$$s_{\rm p}(t) = \sqrt{2}s_{\rm i}(t)\cos(2\pi f_c t) - \sqrt{2}s_{\rm q}(t)\sin(2\pi f_c t)$$

where,

$$s(t) = s_{i}(t) + js_{q}(t)$$

Any passband signal $s_p(t)$ can be written as

$$s_{\rm p}(t) = \sqrt{2}s_{\rm i}(t)\cos(2\pi f_c t) - \sqrt{2}s_{\rm q}(t)\sin(2\pi f_c t)$$

where,

$$s(t) = s_{i}(t) + js_{q}(t)$$

is called the complex envelope of $s_{\rm p}(t)$.

