IQ Modulator Board

Manu T S manu.ts@ee.iitb.ac.in

Department of Electrical Engineering Indian Institute of Technology Bombay

July 7, 2014

IQ Modulation

Any passband signal $s_p(t)$ can be written as

$$s_{p}(t) = \sqrt{2}s_{i}(t)\cos(2\pi f_{c}t) - \sqrt{2}s_{q}(t)\sin(2\pi f_{c}t)$$
 (1)

where,

$$s(t) = s_i(t) + js_q(t)$$
 (2)