




P3022-V1-CW360

ISCP Program

SWD to JTAG Debug/Program

Vref = TCK SWIO = GND
 GND1 = TDO CLK = 5V
 GND2 = TMS SWO = RST
 KEY = NC NC = RST
 GNDd = TDI !RST = GND