


SWD Debug/Program



SWD to JTAG Mapping

Vref = TCK = A3 SWIO = GND
 GND1 = TDO = A1 CLK = 5V
 GND2 = TMS = A2 SWO = RST
 KEY = NC NC = RST
 GNDd = TDI = A0 !RST = GND

SWD to ISP Mapping

GNDd = MOSI = 16
 Vref = SCK = 15
 GND1 = MISO = 14

P3022-V1-CW360