data_analysis

May 7, 2025

1 Finding Resistivity

In the instrument calculation assignment, the resistance of the semiconductor was calculated as the slope of the I-V plot generated by the source measure unit (SMU). We can then use that measure of the resistance to find the resistivity of the chip as well, which can be found as:

$$\rho = \frac{wt}{l}R$$

Where w, t, and l describe the width, thickness, and length respectively of the chip. The thickness was provided by a label on the chip as $500~\mu m$ - but the thickness and length are less certain. Estimating the chip to have a width of 2mm and a length of 8mm, we then need to consider that we are measuring across tabs B and C or Q and R, which represent roughly 1/3rd of the chips length. We can then use these values and the resistance to calculate the resistivity.

```
[1]: import hall_functions
   import numpy as np
   def calc_rho_from_R(avg_R, avg_R_sigma):
        # State R +/- R_sigma & R
        R1 = avg_R - avg_R_sigma
        R2 = avg R
        R3 = avg_R + avg_R sigma
        # Dimensions of wafer
        t = 5e-6 \# m
        w = 0.008/3 \# m
        1 = 0.002 \# m
        a = t*w
        # Finding rho ranges
        rho1 = a * R1 / 1
        rho2 = a * R2 / 1
        rho3 = a * R3 / 1
        rho = rho2
        rho_sigma = rho3-rho1
```


```
return rho, rho_sigma

[2]: avg_R = 174.256
avg_R_sigma = 0.014

rho, rho_sigma = calc_rho_from_R(avg_R, avg_R_sigma)
print(f'Resistivity = {rho:.8f} (Ohm meters) +/- {rho_sigma:.8f} (Ohm meters)')
```


Resistivity = 0.00116171 (Ohm meters) +/- 0.00000019 (Ohm meters)

2 Hall effect




Our measurements to characterize the chip's resistance and resistivity were taken parallel to the electrical field present in the chip, from $B \to C$ and $Q \to R$. But in the presence of a magnetic field which is perpendicular to the electric one, charges should be deflected in the third perpendicular direction. If we call the left to right plane of the chip the x-axis and the direction of the magnetic field to be the z-axis, we should observe an accumulation of charges across the chips y-axis. In the diagram, this means we should detect a potential difference, V_H , across the $Q \to B$ and $R \to C$ tabs when a magnetic field is present.

```
[7]: RHqb, RHqb_sigma = hall_functions.plot_resistance('Data/BqRbRUN10.csv', 'Q', \_ \cdot 'B', Magnet=True)
```



[4]: RHrc, RHrc_sigma = hall_functions.plot_resistance('Data/BrRcRUN8.csv', 'R', _ \cdot 'C', Magnet=True)



As can be seen by the non-linearity of the $Q \to B$ plot, there was likely some sort of issue which occured while taking the data across that measurement. As a result of this, only the $R \to C$ data will be used to calculate the charge density. The magnetic field the chip was placed inside of has a strength of $0.09T \pm 0.003T$.

The **Hall resistance** can then be written as:

$$R_H = \frac{V_H}{I} = \frac{B}{net}$$

This means that we should be able to use our data for the value of R_H and our measurement for B in order to find the number density of charge carriers as:

$$n = \frac{B}{etR_H}$$

We will also want to perform error propagation to find the uncertainty in n. We will assume 0 uncertainty in e and t, giving us the formula:

$$\sigma_n = \sqrt{\left(\frac{\delta n}{\delta B}\right)^2 \sigma_B^2 + \left(\frac{\delta n}{\delta R_H}\right)^2 \sigma_{R_H}^2}$$
$$\sigma_n = \sqrt{\left(\frac{1}{etR_H}\right)^2 \sigma_B^2 + \left(-\frac{B}{etR_H^2}\right)^2 \sigma_{R_H}^2}$$

From there, we can determine what type of doping our chip received, using the relationship of:

P-doped, n-type Si: $n >> n_i >> p$ B-doped, p-type Si: $p >> n_i >> n$

Where n_i is the number density of *intrinsic carriers*, p is the number density of holes in the Valence Band (VB) which act as positively charged carriers, and n is the number of electrons in the Conduction Band (CB).

Charge number density = 2.9732e+29 +/- 1.0817e+28 carriers per cubic centimeter.

According to the paper, "Improved value for the silicon intrinsic carrier concentration at 300K'' (Sproul, Green, Zhao, 1990), Silicon has an intrinsic carrier density of $1.45 \times 10^{10} cm^{-3} \pm 4.35 \times 10^{8} cm^{-3}$.

We can now use the law of mass action as well as our calculation for n to find the value of p:

$$n \cdot p = n_i^2 \to p = \frac{n_i^2}{n}$$

$$\sigma_p = \sqrt{(2\frac{n_i}{n})^2 \sigma_{n_i}^2 + (-\frac{n_i^2}{n^2})^2 \sigma_n^2}$$

Number density of holes in VB = $0.000707 \text{ cm}^{-3} +/- 0.000050 \text{ cm}^{-3}$

This tells us that our sample is likely **P-doped, n-type Si**, as $n >> n_i >> p$