

SolarPro Global — User Guide

End-to-end workflow for solar PV designers in Ghana

Version: 2026-06-05 (beta) **Audience:** Solar engineers, designers, project leads — at installer and supplier companies. **Production URL:** <https://web-production-744af.up.railway.app> **Custom domain (provisioning):** <https://solarpro.aiappinvent.com>

Screens are referenced as **[SCREEN: page-name]**. Live screenshots are attached at the end of this document. If a screen has changed since this PDF was issued, the live app is always the source of truth.

1. What SolarPro Global does for you

SolarPro Global takes you from blank page → bankable proposal in a single web workflow.

Step	What it does	Time
1. Site assessment	Pulls solar irradiance, ECG tariff, currency, weather profile for the prospect's region	30 s
2. Loads	You enter what the customer wants to power. We calculate daily Wh demand.	2 min
3. PV sizing	Computes array size, panel count, string layout, MPPT match	auto
4. Battery + inverter	Sizes battery autonomy + inverter rating against your loads	auto
5. Cable design	Sizes AC + DC cables per BS 7671 and IEC 60364	auto
6. BOQ	Generates a full bill of quantities — panels, structures, fittings, cabling	auto

7. Economic analysis	Payback, IRR, NPV, lifetime savings in Cedis	auto
8. Reports	7 bankable reports as one branded PDF	30 s

Total: a project that used to take 4–6 hours in Excel now takes 20–30 minutes in SolarPro.

2. Getting started

2.1 Create your account

1. Open <https://web-production-744af.up.railway.app>
2. Click **Get Started** (top right).
3. Fill the registration form:
 - Username (you'll log in with this — not your email)
 - Email
 - Password (8+ chars)
 - Company name
 - Country = Ghana
4. Click **Create Account**.
5. Check your email for the welcome message (sender: sales@aiappinvent.com). It contains your trial expiry and quick-start tips.

[SCREEN: [register-form](#)]

2.2 Free trial

Every new account starts a 14-day free trial of the Professional plan. You can:

- Create unlimited projects
- Generate all 7 reports per project
- Export PDF + JSON

No credit card. At the end of 14 days you choose a paid plan or downgrade to free (which keeps

your account but limits you to 1 active project).

2.3 Log in

- Field is **Username**, not email — easy to forget.
- If you get locked out (5 wrong passwords = 15-minute lockout) wait it out; do not reset unless you actually forgot.

[SCREEN: login]

3. The dashboard

After login you land on your dashboard.

[SCREEN: dashboard]

What you see:

- **My Projects** — every project you've created, newest first. Click a row to open it.
- **+ New Project** button — top right.
- **Trial countdown** — how many days left of the 14-day Professional trial.

• — quick-open links to your last 5 generated PDFs.

- **Support** — bottom-right floating chat icon → AI assistant (rule-based + Claude/Llama fallback).

4. Creating a project (3 minutes)

4.1 Project basics

Click **+ New Project** and fill:

Field	Example	Notes
Project name	"Kasoa Residential — 5 kW"	Any text

Client name	"Mr. Mensah"	Shown on the proposal cover
Site type	Residential / Commercial / Industrial	Drives default parameters
Country	Ghana	Locks in ECG tariff + Cedi
Currency	GHS (auto)	You can override

[SCREEN: project-new]

Click **Create** — you go straight to the Location step.

4.2 Location

This is where the engineering starts. You set the site latitude and longitude. Two ways:

Globe pick — the rotating 3D globe shows Ghana. Click your region — a green dot appears. The system reads:

- Peak Sun Hours (PSH)
- Mean ambient temperature
- ECG tariff zone
- Currency

[SCREEN: location-globe]

Address search — type "Madina Accra" or "Kasoa" and pick from the dropdown. Same data populates.

Valid Ghana regions: Greater Accra, Ashanti, Northern, Volta, Western. Pick the closest one — region picks the irradiance profile.

Click **Save & Continue**.

5. Loads — telling the system what to size for

This is the most important step. Garbage in = wrong system out.

5.1 Two ways to enter loads

[SCREEN: loads-input]

Method A — Appliance picker (recommended for residential):

- A list of common Ghanaian household appliances: fridge, fan, TV, LED bulb, water heater, AC, water pump.
- Click an appliance → enter quantity + daily usage hours.
- The system fills wattage from a standard catalogue (you can override).

Method B — Direct entry (recommended for commercial/industrial):

- Paste rows from Excel: **Load name** | **Wattage (W)** | **Quantity** | **Hours/day** | **Days/week**
- One row per load. Up to 200 loads per project.

5.2 What the system computes from loads

- **Connected load (kW)** = $\Sigma(W \times Qty) \div 1000$
- **Daily energy demand (kWh)** = $\Sigma(W \times Qty \times Hours \div 1000) \times Days/week \div 7$
- **Peak load (kW)** = largest simultaneous load (used to size inverter)
- **Surge load (kW)** = peak $\times 3$ (motor-start margin; configurable)

These four numbers drive every downstream calculation.

5.3 Mounting type

Pick before continuing — it changes the BOQ and the installation drawings.

Value	When to pick
rooftop_pitched	Most Ghanaian residential — IBR / tiled roofs
rooftop_flat	Concrete slab roofs (Accra commercial)
rooftop_metal	Aluzinc warehouse roofs
rooftop_membrane	Modern commercial flat membrane
ground_fixed	Land available, no tracking — most cost-effective utility

Ground-mount selections add steel post, concrete footing, purlin beam, and earth rod to the BOQ.

Click **Calculate Sizing**.

6. PV sizing — what the engine returns

[SCREEN: results-pv]

Inside 30 seconds you get:

Output	Example	Sizing basis
Required PV array	6.0 kWp	Daily demand ÷ (PSH × system efficiency)
Panel selection	12 × 500 Wp mono	Closest standard size; you can change to 110/250/330/400/450/500/550 Wp
String layout	2 × strings of 6 panels in series	Matches inverter MPPT voltage window
Battery autonomy	10 kWh, 1 day autonomy	Daily demand × autonomy × depth-of-discharge factor
Inverter rating	5 kW hybrid	Peak load × oversize factor
MPPT match	OK / Warning	$V_{mp\ string} \times 1.25 \leq \text{Inverter } V_{max}$
AC cable	4 mm ² × 25 m	BS 7671 derating per ambient temp
DC cable	6 mm ² × 30 m	IEC 62548 voltage drop ≤ 1.5%

Click **Edit Parameters** to override any value (e.g. force 330 Wp panels if that's what your supplier stocks).

Click **Continue to BOQ** when satisfied.

7. Bill of Quantities (BOQ)

[SCREEN: boq]

The BOQ lists every part needed to build the system. Sections:

- Panels — make, model, Wp, qty, unit cost, total
- Inverter(s) — model, rating, qty
- Batteries — type (lithium/gel/AGM), kWh, qty
- Mounting hardware — rails, end clamps, mid clamps, MLPE if any
- Cabling — AC + DC, by gauge and run length
- Protective devices — MC4 connectors, fuses, surge arrestors, isolators, combiner box
- Earthing — rods, conductors, bonding clamps
- Mounting (ground) — steel post, concrete footing, purlin beam (only if ground mount)

You can:

- **Override prices** — click any unit cost, type your supplier's price.
- **Add line items** — for items not auto-generated (gravel, transport, labour).
- **Save as template** — re-use this BOQ structure for similar projects.

The total flows into the economic analysis automatically.

8. Economic analysis

[SCREEN: economics]

Inputs are pre-filled from the project; you can override:


Input	Default	Override when
Tariff (GHS/kWh)	ECG residential rate for the region	Customer is on commercial tariff

Tariff escalation (%/year)	6%	You have a more conservative number
Discount rate (%)	12%	Customer's actual cost of capital differs
Project lifetime (years)	25	Customer requires a shorter horizon

Outputs:

- **Simple payback (years)**
- **IRR (%)**
- **NPV at year 25 (GHS)**
- **Lifetime savings (GHS)**
- **First-year energy yield (kWh)**
- **CO₂ avoided (tonnes/year)**

Graph: annual cumulative cash flow — payback point clearly marked.



9. Installation report + drawings

[SCREEN: installation-drawings]

This report is for the install crew. It includes:

1. **Method statement** — step-by-step install sequence
2. **Mounting drawings** — top-down layout, side elevation
3. **Single-line diagram** — DC + AC + battery + grid
4. **Earthing diagram**
5. **Cable schedule** — every run, gauge, length, route
6. **Risk assessment** — working at height, electrical isolation, fall arrest
7. **Tools and materials checklist**

For ground mount, additional drawings show steel post depth, footing dimensions, and purlin beam spacing.

10. Generating the proposal PDF

[SCREEN: proposal]

From the project header, click **Generate Proposal**.

The proposal PDF includes:

1. Cover page (your logo, client name, project name, date)
2. Executive summary (system size, cost, payback)
3. Site assessment + irradiance map
4. Sizing summary
5. BOQ
6. Economic analysis with chart
7. Installation method + drawings
8. Terms & conditions (editable template)

PDF generates in ~30 seconds. Sender on the email-the-PDF flow: sales@aiappinvent.com (you can change to your own SMTP in **Settings** → **Email**).

11. Tips that save time

Tip	Why
Save common appliance lists as templates	A typical Ghanaian 3-bed home uses the same 12 loads — set it up once.
Override panel size to match what you stock	Avoids quoting a panel the customer will ask you to swap.
Use the AI helpline (floating chat)	It can pre-fill standard cable runs, suggest mounting layouts, and explain any error.
Export JSON before deleting a project	One JSON file = whole project. Future restore is one upload.

12. Support

- **In-app:** click the chat icon (bottom-right) — answers in 2 seconds.
- **Email:** support@aiappinvent.com (24-hour SLA during beta).
- **Phone (beta only):** see the email signature on your welcome mail.
- **Status page:** </admin/operations> shows live system health if you have admin rights at your company.

13. Account settings worth knowing

Setting	Where	What it changes
Company logo	Settings → Profile	Appears on every proposal PDF
Default tariff escalation	Settings → Defaults	Saves re-typing on each project
Default panel make/model	Settings → BOQ	Pre-fills BOQ from your supplier
API key for procurement integration	Settings → Procurement	Pulls Nocheski / Ozo live pricing into BOQ

Can my customer log in and see their proposal? Yes — under Project → Sharing, click "Create client link". Read-only, expires in 30 days unless you renew.

Can I have multiple users at my company? Yes — on Professional plan or higher. Settings → Team → Invite. Each user has their own login but you share projects.

Does it work on mobile? The dashboard and proposal viewing work well on phone. Sizing input is easier on a tablet or laptop because of the side-by-side panels.

What if my customer is outside Ghana? Switch country at project creation. The tool covers 40+ countries — but BOQ pricing and ECG tariffs only Ghana for now. Other markets coming Q3 2026.

Where is my data stored? EU-region encrypted database. Per-tenant row-level isolation. Daily backups.

15. Screenshots index

When this guide is updated, screenshots will be referenced here:

- `[SCREEN: register-form]` — page `/register`
- `[SCREEN: login]` — page `/login`
- `[SCREEN: dashboard]` — page `/dashboard`
- `[SCREEN: project-new]` — page `/project/new`
- `[SCREEN: location-globe]` — page `/project/<id>/location`
- `[SCREEN: loads-input]` — page `/project/<id>/loads`
- `[SCREEN: results-pv]` — page `/project/<id>/report/pv`
- `[SCREEN: boq]` — page `/project/<id>/report/boq`
- `[SCREEN: economics]` — page `/project/<id>/report/economic`
- `[SCREEN: installation-drawings]` — page `/project/<id>/report/installation`
- `[SCREEN: proposal]` — page `/project/<id>/report/proposal`

To insert screenshots: capture the relevant page from the live app, save as `docs/screens/<slug>.png`, and re-run the PDF build script. The script auto-embeds any PNG whose filename matches a `[SCREEN: ...]` token.