

Note1: Text in italic placed on a wire doesn't correspond to net name. It just helps to identify rapidly Arduino's signal related to this wire.

Note2: Remove [N/A] on R34, R36, C31, C32, X2 from C.1 to C.2

Note3: Add "default open" on SB48, SB49, SB55 from C.1 to C.2


Note4: Replace "default open" by "default closed" on SB16 & SB50 from C.1 to


Note4: Replace "default open" by "default closed" on SB16 & SB50 from C.1 to C.2


Note5: C31&C32 value changed from 10pF to 4.3pF to fit with new 32K crystal ABS25-32.768KHZ-6-T

Title: **TOP & POWER**

Project: NUCLEO-XXXXXXX			
Size: A4	Reference: MB1136	Revision: C.3	
Date: 9/26/2014		Sheet: 1 of 4	life.augmented







Title: Extens			
Project: NUC			
Size: A4	Reference: MB1136	Revision: C.3	
Date: 6/16/2014		Sheet: 4 of 4	life.augmer