



ABSOLUTE ADAS

TECHNICIAN TRAINING HANDBOOK

Volume 1

MISSION

Empowering driver safety through precision ADAS calibrations

Same Day. Done Right.

absoluteadas.com | June 2025

CONFIDENTIAL — FOR ABSOLUTE ADAS TECHNICIANS ONLY

Table of Contents

01 Company Overview

02 Representing Absolute ADAS

03 Introduction to ADAS

04 When & How to Calibrate

05 Body Shop Terminology

06 Common ADAS Failures

07 ADAS Workflow

08 All About ADAS Components

09 Calibration Guide & Rules

10 Make & Model Gotchas

11 EV & Hybrid Precautions

12 Part Code Services & Products

13 OEM Tool & VCI Reference

14 Van Equipment Checklist

15 Invoice & Job Closeout

16 Failure & Escalation Protocol

17 Metric Test Answers

18 Notes

19 Company Contacts

0 COMPANY OVERVIEW

1 *Who we are, what we do, and why it matters*

Who We Are

Absolute ADAS is a mobile Advanced Driver Assistance Systems calibration company dedicated to serving collision repair facilities across the Pacific Northwest. Unlike competitors who compromise on technology and undervalue their technicians, Absolute ADAS is built on a different standard — industry-leading tools in every van, competitive compensation, and the resources to do the job right every time.

Our technicians and management operate with pride and ownership. That culture of excellence empowers us to deliver a powerful, reliable service model for every body shop we partner with.

What We Do

Absolute ADAS eliminates the logistical burden body shops face when transporting vehicles to specialized facilities. We bring professional, OEM-grade ADAS calibration services directly to the shop floor — saving time, reducing labor costs, and delivering a reliable, documented result to their customers.

MISSION	VISION
Empowering driver safety through precision ADAS calibrations.	To be the premium ADAS service provider in every market we serve.

Safety

ADAS systems are life-safety features. Not properly calibrating these systems can cause them to fail at the worst possible moment. Calibrate with precision and passion — every time.

0 REPRESENTING ABSOLUTE ADAS

2 Professional standards in the field

Customer Interactions

Your presence at a body shop is a direct reflection of our brand. Arrive with pride and professionalism. A friendly, approachable demeanor builds trust from the moment you walk in. Arrive fully prepared — all tools organized, all equipment ready.

Dress Code

REQUIREMENT	POLICY	CONSEQUENCE
Uniform	Company-issued T-shirts, hoodies, polos, and hats with the Absolute ADAS logo must be worn on all service calls.	
Footwear	Closed-toe, slip-resistant shoes mandatory.	
PPE	Safety glasses, gloves, hearing protection, and respiratory protection when required.	
Hygiene	Maintain clean personal hygiene and a clean uniform.	
Jewelry	Remove rings, bracelets, and necklaces while working. Secure long hair.	
Attire	Avoid loose or baggy clothing. Choose attire that allows ease of movement.	
Exceptions	Any exceptions require advance management approval.	Failure to comply may result in disciplinary action up to termination.

0 INTRODUCTION TO ADAS

3 Advanced Driver Assistance Systems — the basics

What Is ADAS?

ADAS stands for Advanced Driver Assistance Systems. This technology began gaining traction around 2010–2013. Today, ADAS encompasses any system or program that aids in the driving or operation of a vehicle. Core sensing technologies include:

- Cameras
- Radars
- LiDAR
- Infrared Sensors
- Ultrasonic Sensors
- Laser Radar

Popular ADAS Systems & Acronyms

CODE	SYSTEM	CODE	SYSTEM
ACC	Adaptive Cruise Control	LCA	Lane Change / Centering Assist
AEB	Autonomous Emergency Braking	LDW	Lane Departure Warning
APA	Advanced Parking Assist	LKA	Lane Keep Assist
AFLS	Adaptive Front Lighting System	RCTA	Rear Cross Traffic Alert
BSD	Blind Spot Detection	RVC	Rear View Camera
CTA	Cross Traffic Alert	SVC	Surround View Camera
DFW	Driver Fatigue Warning	TSR	Traffic Sign Recognition
FCW	Forward Collision Warning	TJA	Traffic Jam Assist
HUD	Heads Up Display	NV/NVC	Night Vision Camera
ICC	Intelligent Cruise Control		

VIN Decoding

Every character in the 17-digit VIN carries specific meaning:

POSITIONS	FIELD	WHAT IT TELLS YOU
1–3	World Manufacturer Identifier (WMI)	Identifies the manufacturer and country of origin.
4–8	Vehicle Descriptor Section (VDS)	Model, body type, engine type, and restraint system.
9	Check Digit	Verifies accuracy of the VIN.
10	Model Year	The vehicle's model year code.
11	Assembly Plant	Where the vehicle was manufactured.
12–17	Production Sequence Number	Unique sequence number for that specific vehicle build.

NATO Phonetic Alphabet

Use phonetics when communicating VINs or part numbers. Eliminates I vs. 1, O vs. 0, B vs. D confusion.

A — Alpha	B — Bravo	C — Charlie	D — Delta
E — Echo	F — Foxtrot	G — Golf	H — Hotel
I — India	J — Juliet	K — Kilo	L — Lima
M — Mike	N — November	O — Oscar	P — Papa
Q — Quebec	R — Romeo	S — Sierra	T — Tango
U — Uniform	V — Victor	W — Whiskey	X — X-ray
Y — Yankee	Z — Zulu		

0 WHEN & HOW TO CALIBRATE

4 Types, requirements, OEM instructions, and metric measurement

When to Calibrate

Today, 35–45% of all vehicles repaired in a body shop require one or more ADAS calibrations. A trained technician can identify most calibration requirements by examining vehicle damage and reviewing the repair estimate. Always confirm with OEM job aids.

Types of Calibration

DYNAMIC	STATIC
The scan tool puts the vehicle into a learning state. The vehicle is then driven on public roads to complete calibration. No physical target required.	The vehicle is set up in a controlled environment. Specialized targets placed around the vehicle allow it to recalibrate without moving.

Requirements for a Proper Calibration

ALL of the following must be confirmed before beginning any calibration:

- Completely level surface
- Proper lighting — no harsh shadows or direct glare on targets
- Clutter-free environment with adequate space per OEM specs
- Vehicle fully reassembled and road-ready
- All prerequisites completed: alignment, fuel level, tire pressure
- Full tank of gas (Audi/VW, Nissan/Infiniti, Honda/Acura require this)
- Wheel alignment completed if required by OEM
- Cargo area empty
- Away from elements — no extreme weather, darkness, or interference

OEM ADAS Instructions — Metric System

All OEM ADAS instructions use the metric system. You must be able to read and convert measurements accurately every time.

UNIT	ABBREV.	RELATIONSHIP
Meter	m	Base unit of length
Centimeter	cm	1 m = 100 cm

Millimeter	mm	1 m = 1,000 mm 1 cm = 10 mm
------------	----	-------------------------------

EXAMPLE: "Place the radar target at 3030 mm from center line front bumper." → 3030 mm = 303 cm = 3.03 m

Metric Practice Problems

Practice these before your first solo job. Answers are in Section 17.

1. Convert 2500 mm to meters.
2. Convert 3.75 meters to centimeters.
3. Convert 450 cm to meters.
4. Convert 6.2 meters to millimeters.
5. Convert 875 mm to centimeters.
6. Convert 5.5 meters to centimeters.
7. Convert 320 cm to millimeters.
8. Convert 4.8 millimeters to centimeters.
9. Convert 9.6 centimeters to meters.
10. Convert 7000 mm to meters.

0 BODY SHOP TERMINOLOGY

5 21 terms every Absolute ADAS tech must know

#	TERM	DEFINITION
01	Estimate	A detailed assessment of vehicle damage and the cost of repairs.
02	Labor Hours	The number of hours billed for a technician to complete a repair.
03	Parts	Replacement components needed for the repair.
04	OEM	Original Equipment Manufacturer — parts made by the vehicle manufacturer.
05	Aftermarket Parts	Replacement parts made by companies other than the OEM.
06	Refinish	Applying paint to repair or restore a damaged area.
07	Blend	Mixing paint to match surrounding panels for a seamless finish.
08	Panel Replacement	Removing and replacing damaged body panels with new ones.
09	Dent Repair	Repairing dents using PDR (paintless dent repair) or traditional methods.
10	Frame Repair	Repairing structural damage to the vehicle's frame or chassis.
11	Alignment	Adjusting suspension and steering for proper wheel alignment.
12	Tear-down	Disassembling parts of the vehicle to assess hidden damage.
13	Supplement	Additional repairs or parts discovered after the initial estimate.
14	Total Loss	When repair cost exceeds vehicle value — declared a total loss.
15	Sublet	Sending specific repairs (e.g., glass, alignment) to a specialized provider.
16	Estimating Software	Programs that generate repair estimates based on industry labor rates.
17	Deductible	Amount the customer pays out-of-pocket before insurance coverage applies.
18	Customer Pay	Repairs paid directly by the vehicle owner rather than insurance.
19	Supplemental Claim	A claim for additional repairs found after the initial estimate.
20	Pre-Scan	A vehicle scan at drop-off that records faults before repairs begin.
21	Post Scan	A scan report completed after all vehicle repairs are finished.

0 COMMON ADAS FAILURES

6 *What to look for when systems aren't communicating*

Field Diagnostic Checklist

When you arrive and find ADAS faults on the scan, physical damage is more often the root cause than an uncalibrated system. Work through this checklist systematically:

01 — CHECK CONNECTORS

02 — IDENTIFY IMPACT ZONE

03 — CHECK FUSES

04 — REQUEST ACCIDENT PHOTOS

0 ADAS WORKFLOW

7 Step-by-step procedure and documentation requirements

Step-by-Step Procedure

#	STEP	WHAT TO DO
1	ARRIVE & IDENTIFY	Identify the vehicle needing service upon arrival. Confirm the repair order number.
2	VERIFY SPACE & LEVEL	Confirm sufficient space and verify workspace levelness. Refer to Autel and OEM specs.
3	CONFIRM PREREQUISITES	Verify vehicle alignment and fuel requirements. Alert the shop in advance if prerequisites are not met.
4	SET UP VEHICLE	Set tire pressures to factory spec. Reset TPMS if required. Connect the VCI to the OBD2 port. Power up the scanner and connect via Bluetooth.
5	PRE-SCAN	Run AUTO VID on the scanner. Enter the repair order number when prompted.
6	NAVIGATE TO ADAS CALIBRATE	Main screen > Car icon > Change Vehicle > History > select vehicle > ADAS Calibrate > run fault scan on all ADAS modules.
7	EXECUTE CALIBRATION	Confirm calibration type using AI tools or OEM job aids. Read every instruction fully before proceeding.
8	FOLLOW-UP & VERIFY	Perform all follow-up routines including a test drive. Verify ALL ADAS components before leaving.

Documentation & Photo Requirements

Every calibration must be documented with photos attached to the final invoice.

REQUIRED PHOTO	REQUIREMENT
Vehicle 4 Corners	All 4 corners before touching anything. Flag pre-existing damage with close-ups.
Instrument Cluster	All illuminated dash lights with fuel gauge visible in frame.
VIN Tag	Located in the driver's door sill. Photograph clearly.
Autel Measurement Screenshots	Long-press camera button in the Autel ADAS function to screenshot any page with measurements.
Static Target Setup	Photo of the target setup with the vehicle visible in the background.
Dynamic Driving Instructions	Screenshot the Autel driving instructions before beginning a dynamic calibration.
Calibration Success Screen	Screenshot the confirmation page showing calibration completed successfully.

0 ALL ABOUT ADAS COMPONENTS

8 Quick identification guide — know what you're calibrating

AEB / ACC / FCW

Autonomous Emergency Braking | Adaptive Cruise Control | Forward Collision Warning

Radar-based systems in the front grille/bumper or behind the windshield. Detect obstacles ahead and can automatically brake the vehicle. A miscalibrated forward radar can fail to stop the vehicle or trigger unnecessary braking.

Location: Front bumper, grille area, windshield upper center

LKAS / LDW / LCA

Lane Keep Assist | Lane Departure Warning | Lane Centering Assist

Camera-based systems mounted to the windshield behind the rearview mirror. Interface with the electronic steering system to keep the vehicle centered in its lane. Any windshield replacement triggers a required calibration.

Location: Windshield — upper center, behind rearview mirror

BSM / RCTA / BSI

Blind Spot Monitor | Rear Cross Traffic Alert | Blind Spot Indicator

Radar-based systems in the rear bumper or rear body panels. Detect vehicles in blind zones alongside and behind the vehicle. Require calibration after bumper removal, rear body panel work, or module replacement.

Location: Rear bumper or rear quarter panel (both sides)

AVM / 360 CAM / APA

Around View Monitoring | 360 Camera System | Advanced Parking Aid

Camera and ultrasonic sensor-based systems that assist in parking and low-speed maneuvering. Cameras in the front bumper, mirrors, and rear.

Location: Exterior mirrors, front bumper, rear bumper

0 CALIBRATION GUIDE & RULES

9 *Non-negotiable rules before you start*

ALL VEHICLES REQUIRING ALIGNMENT MUST HAVE ALIGNMENT COMPLETED BEFORE ANY ADAS CALIBRATION

RULE	DETAIL	APPLIES TO
Full Fuel Requirement	Full tank required by OEM before calibration.	Audi/VW, Nissan/Infiniti, Honda/Acura
Bumpers Off — BSM Cal.	Leave rear bumper off for blind spot module calibration.	Honda/Acura, Kia/Hyundai
Bumpers Off — Rear Panel Work	Any rear body or quarter panel work — leave bumpers off to verify module angles.	All makes
Bumpers Off — Front ACC	Leave front bumper off for ACC radar calibration.	Kia/Hyundai; Nissan/Infiniti with off-center module
Radar Removed from Bumper	Any radar removed from a bumper needs both Static AND Dynamic calibration.	All makes

"A CLEARED CODE DOES NOT MEAN CALIBRATED"

1 MAKE & MODEL GOTCHAS

0 *Brand-specific quirks that trip up new techs*

Every OEM has its own quirks. Learn these before you hit the shop floor — they're the things that don't appear in the scan tool instructions but will absolutely cause a failed calibration if you miss them.

Subaru (EyeSight)

- EyeSight is extremely sensitive to ambient lighting. The calibration area must be evenly lit with no harsh shadows or direct sunlight on the targets. Recommended: 500–1,000 lux, no fluorescent flicker.
- The engine **MUST** be running during calibration — battery-only mode is not sufficient.
- Do not touch the steering wheel or brake pedal during the calibration sequence.

Toyota / Lexus

- Most windshield and radar calibrations require the engine running — not just ignition on.
- Toyota Safety Sense (TSS) cameras require a specific white calibration target — do not substitute.
- Pre-collision system (PCS) often throws a calibration error if the steering wheel is not perfectly centered. Verify with alignment first.
- Some Lexus models require a short drive after static to finalize learning.

Honda / Acura

- Full fuel tank is required — Honda will refuse to start calibration below 3/4 tank on many models.
- Always perform All Sensor Relearn after windshield calibration. Failure to do so leaves the system in a degraded state even after a successful cal.
- LKAS camera on Acura RDX and MDX has a very tight tolerance — level surface is critical.

Nissan / Infiniti

- Full fuel tank required. Some Infiniti models require the vehicle to sit level for 20 minutes before calibration.
- R2R (Road to Relearn) dynamic calibration requires a specific driving pattern — read the Consult instructions before starting.
- Off-center radar placement on some Frontier and Titan models means the bumper must be off for a proper angle check.

Audi / VW

- Full fuel tank required — verified via the scan tool before the procedure will begin.
- Very intolerant of unlevel surfaces. Even a 0.5-degree tilt can cause a calibration fault.
- Audi expects a specific room temperature range. Extremely hot or cold bays will abort the calibration.

Kia / Hyundai / Genesis

- Leave the front bumper off for SCC (Smart Cruise Control) radar calibrations on most models — the radar must be physically accessible for angle adjustment.
- GSCAN tablet must be fully updated before connecting. An outdated GSCAN version will return false calibration failures.
- Genesis models often require a static AND a dynamic pass — confirm in GSCAN before leaving.

Ford / Lincoln

- Some BLIS (Blind Spot Information System) calibrations on F-Series trucks require rear bumper removal for antenna angle verification.
- Co-Pilot 360 cameras on Mustang and Explorer require a level, clutter-free bay with specific target distances — follow FDRS prompts exactly.
- FDRS requires a live internet connection to validate calibration. Hotspot or shop WiFi required.

GM (Chevy / GMC / Cadillac / Buick)

- Front camera calibrations on most GM trucks require the engine running AND HVAC off — HVAC vibration can cause target detection issues.
- Cadillac Super Cruise requires a full front camera, radar, AND LiDAR calibration sequence — do not shortcut.
- Many GM calibrations end with a mandatory test drive pattern. Techline Connect will not mark the job complete without it.

BMW / MINI

- ISTA requires a live internet connection and a valid account. Never attempt BMW work without verifying ISTA is online first.
- Cameras on the 3-Series and 5-Series require a specific ambient light level — too bright OR too dark will abort.
- After any suspension work, steering angle calibration must be completed before running ADAS calibration.

Mercedes-Benz

- Xentry is the only accepted tool — no aftermarket scan tool will fully calibrate Mercedes ADAS systems.
- The DISTRONIC radar (front) often requires both static placement AND a specific road test distance and speed. Follow Xentry exactly.
- Mercedes is very strict on tire pressure matching — all four tires must be at the exact factory spec before starting.

1 EV & HYBRID PRECAUTIONS

1 High-voltage safety rules — non-negotiable

HIGH-VOLTAGE SYSTEMS CAN KILL. IDENTIFY BEFORE YOU TOUCH.

Identifying High-Voltage Systems

Any vehicle with a high-voltage (HV) battery operates differently from a standard 12V vehicle. These include full EVs (Tesla, Rivian, Leaf, Bolt) and hybrids (Prius, RAV4 Hybrid, Accord Hybrid, F-150 Lightning, etc.).

HOW TO IDENTIFY	WHAT IT MEANS
Orange cables / conduit under the hood or chassis	High-voltage system present — do NOT cut, disconnect, or touch these.
HV battery warning labels	Located on the battery housing, hood, and dashboard. Read all warnings before starting.
"EV" or "Hybrid" badging	Indicates a high-voltage system is present regardless of whether the engine is running.
Blue/green Ready indicator (Toyota/Lexus hybrid)	Vehicle is powered — HV system is LIVE even with no engine noise.

General EV & Hybrid Rules

- Never disconnect the 12V battery on a hybrid or EV without first following the OEM HV disable procedure. Disconnecting the 12V on some vehicles can trigger safety systems.
- Never attempt to service, move, or cut orange cables under any circumstances. These carry up to 800V DC.
- If you discover a damaged HV battery (swelling, burning smell, fluid leaking from the battery area) — do NOT attempt to work on the vehicle. Step back and call Mark immediately.
- Always put Tesla vehicles into Service Mode via the touchscreen before connecting tools or lifting the vehicle.
- On Toyota/Lexus hybrids, the vehicle may be powered (HV system live) even when the engine is off. Confirm the Ready light is OFF before working under the hood.
- Wear appropriate PPE — insulated gloves rated for HV work when working near orange cables.
- Keep conductive tools away from orange cable conduit and HV battery terminals.

ADAS Calibration Specifics for EVs

VEHICLE TYPE	WHAT'S DIFFERENT
Tesla Model 3/S/X/Y	Put in Service Mode first. Use Tesla-specific calibration procedures (see Section 12). Standard Autel functions do not apply.

Toyota / Lexus Hybrid	Many calibrations require the vehicle in READY mode (HV system on). Follow OEM instructions exactly.
Chevy Bolt / Volt	Similar to standard GM procedure but verify the HV system is not in fault mode before starting.
Ford Hybrid / Lightning	FDRS procedures are the same as ICE vehicles but be aware the truck may start/stop the engine mid-calibration — this is normal.
Hyundai / Kia EV	Ioniq 5, EV6, etc. use the same GSCAN procedures as ICE models. Ensure the vehicle is in a READY state before calibrating.

1 PART CODE SERVICES & PRODUCTS

2 Updated 2/1/2025 — use exact codes on all invoices and repair orders

SERVICE CODE	DESCRIPTION
ACC Radar Calibration	Perform ADAS calibration of adaptive cruise control radar.
ACC Radar R&R	Removal and replacement of ACC radar, calibration included.
All Sensor Relearn	Honda/Acura: Perform all sensor relearn.
Backup Camera Action Test	Perform Backup Camera Action Test per OEM documentation.
Backup Camera Calibration	Perform ADAS calibration of backup camera.
Blind Spot Calibration	Perform ADAS calibration of blind spot system.
Blind Spot Module Angle Measurement	Check installation angle — height and angle inspection.
BSM Action Test	Perform Blind Spot Monitoring Action Test (Diagnostic).
Dual Camera Windshield Calibration	ADAS calibration of a dual camera system (multi windshield camera).
Dual Process Windshield Camera Calibration	Two calibrations required: 1) Static 2) Dynamic. Road test to verify.
Dual Radar ACC Calibration	ADAS calibration of dual adaptive cruise control radars.
Dynamic Pro Trailer Backup Calibration	Dynamic calibration of the Pro Trailer Backup system.
Electronic Controls Relearn	Power Liftgate, Power Doors, Power Window relearn/initializations.
Front Corner Radar	Mid-Range Radar BSM Calibration.
Full Fuel Requirement	Full fuel tank required per OEM for ADAS calibration.
Lane Watch (Acura/Honda)	Perform ADAS calibration of Lane Watch system.
Module Initialization	Initialization of control units or modules per OEM specs.
Night Vision Camera Calibration	Perform ADAS calibration of night vision camera.
Parking Assist System Action Test	Verify operation of parking aid system per OEM service info.
Parking Sensor Calibration	Perform ADAS calibration of parking sensors.
Post Collision Safety Inspection — Large	Seatbelts and post-collision safety inspections (SRS, Steering Columns, etc.).
Post Collision Safety Inspection — Small w/out SRS	Seat Belt Locking System Inspection: Extraction Lock Test and Vehicle Velocity Lock Test.
Post Collision Safety Inspection — Small w/SRS	Seatbelt inspection and post-collision safety checks including SRS module reset.
Radar R&R	ACC radar removal and replacement, including calibration.
Seat Weight Sensor Zero Point Calibration	Front passenger weight sensor operational check/calibration.
SRS Disable/Enable — Battery Disconnect	Disable or Enable battery/SRS system.
Steering Angle Sensor Reset	Reset steering angle sensor after alignment or suspension work.
Surround View Camera Calibration	ADAS calibration of surround view camera system.
TPMS	Vehicle tire pressure set and relearn control module pressures.
Vehicle Alignment	Required per OEM before and/or after ADAS calibration.
Windshield Calibration	ADAS calibration of windshield camera.
Windshield Camera Calibration (Subaru Mono Camera)	Calibrate Subaru Mono Camera windshield system.

Tesla Certified Services

SERVICE	DESCRIPTION
Headlight software update/calibration (Certified)	Update headlight firmware and calibrate level sensors for adaptive lighting.
Tesla Certified Post Scan / Pre-Scan	Tesla Certified scan procedures.
Tesla Mechanical (Certified)	Mechanical operations for Tesla vehicles.
Tesla TPMS Calibration (Certified)	Fill tire to spec and reset tire monitor system.
Update Vehicle Firmware (Certified)	Update vehicle firmware (modules, cameras).
Model 3/S/X/Y — ACC Radar Calibration	Update firmware and calibrate ACC radar.
Model 3/S/X/Y — ACC Radar Manual Adjustment	ACC radar adjustment, bumper R&I if necessary, then ACC Calibration.
Model 3/S/X/Y — Surround View Camera Calibration	Surround View Camera Calibration.
Model 3/S/X/Y — Windshield Camera Cal. (reset)	Clear learned values for windshield camera.
Model 3/S/X/Y — Windshield Camera Cal. (target)	Static target calibration, windshield camera.

Products

- Calibration Identification Report
- Calibration Snapshot
- Connector/Pigtail
- Key Code
- Post-Scan
- Pre-Scan

1 OEM TOOL & VCI REFERENCE

3 Know your tools for every make on the market

Each OEM requires specific diagnostic software and a matched Vehicle Communication Interface (VCI). Using the wrong tool or VCI means no communication and a failed calibration.

MAKE	DIAGNOSTIC TOOL	VCI OPTIONS
BMW	ISTA (online-based)	ICOM / Cardaq 3/4
Chrysler / Dodge / Jeep / Fiat	WiTech (online-based)	Micropod / Cardaq 3/4
Ford	FJDS, FDRS	Ford VCM 2/3 / Cardaq 3/4
GM	Techline Connect (online with download)	Cardaq 3/4 / GM MDI 2/3
Honda / Acura	HDS — Honda Diagnostic Software (laptop-based)	Cardaq 3/4
Hyundai / KIA / Genesis	GSCAN (Hyundai, KIA, Genesis — tablet)	OWN dongle
Land Rover	JLR (laptop-based)	OWN / Cardaq
Mazda	IDS / MDRS	Mazda VCM / Cardaq 3/4
Mercedes-Benz	Xentry	OWN / Cardaq
Nissan / Infiniti	Consult 3, 4, R2R	OWN dongle / Cardaq 3/4 w/ R2R
Subaru	SSM4	OWN / Cardaq
Toyota / Lexus	Techstream / GTS	Cardaq 3/4

1 VAN EQUIPMENT CHECKLIST

4 *Verify every morning before leaving for your first job*

DO NOT LEAVE FOR YOUR FIRST JOB UNTIL ALL ITEMS ARE CONFIRMED PRESENT AND CHARGED

Diagnostic Equipment

- o Autel MaxiSYS ADAS MA600 tablet — CHARGED (above 80%)
- o Autel VCI (MaxiVCI V150) — paired and connected
- o Cardaq 3/4 — charged and in case
- o OEM-specific VCI dongles for jobs scheduled today (check the night before)
- o Laptop — charged, ISTA / WiTech / HDS / FDRS / Xentry logged in as applicable
- o OBD2 extension cables (1m and 3m)
- o USB-C / USB-A charger cables for tablet and laptop
- o Mobile hotspot or confirm phone data is available

ADAS Target Equipment

- o Full Autel ADAS target set — all panels accounted for, surfaces clean and unmarked
- o Target stands — all legs present, locking pins intact
- o Laser alignment tool / line laser
- o Metric tape measure (5m minimum)
- o Plumb bob or magnetic level
- o Chalk / floor marking tape for target placement

Vehicle & Shop Tools

- o Quality tire pressure gauge (digital preferred)
- o Air compressor adapter / portable inflator
- o Microfiber towels (camera lens cleaning)
- o Flashlight / work light
- o Extension cord (25 ft minimum)
- o Basic hand tools (screwdrivers, trim pry tools)

Documentation & Safety

- o Phone fully charged — photos and invoicing
- o First aid kit present and stocked
- o PPE kit: safety glasses, nitrile gloves, HV-rated insulated gloves
- o Van is clean — professional appearance when you open the doors at a shop

1 INVOICE & JOB CLOSEOUT

5 *You barely have to do anything — tap one button, the system handles the rest*

You don't create invoices. You finish the work, tap one button, and the system handles the rest. Kat takes it from there.

The 5-Step Flow

Find the job

1

Open the Absolute ADAS app (orange icon on your home screen). Your dispatched cars show up on the Live Day screen. "Current" is the one you're on, "Up Next" is the one after.

Do the work

2

Drive there, pull the report, run the calibrations.

Tap "Ready to Invoice"

3

Purple button at the bottom of the job card. The Calibration Review sheet slides up.

Review the calibrations

4

Confirm every calibration you actually performed is on the list. Add any you did that aren't there (quick-add chips). Remove any you skipped. PCSI and POST are always included automatically.

Tap "Done"

5

That's it. The job leaves your board. Kat sees it in #Dispatch and creates the Zoho Books invoice on her end.

What Happens Next

WHAT HAPPENS	WHAT IT MEANS FOR YOU
Job disappears from your Live Day	Clean board = clear head. You're not carrying it anymore.
Your scoreboard updates	The new sale shows up on your card once Kat invoices.
4 jobs in a day	"GET SOME!!!" on screen + a shoutout in #Dispatch.

Hit \$40k MTD	Bonus is yours.
8 AM Cliq DM every morning	Yesterday's number, your MTD progress, and the day's goal. No login needed — just read and roll.
Friday afternoon Cliq DM	Weekly wrap-up. Know where you stand going into the weekend.

Rules of Thumb

- Don't tap "Ready to Invoice" before the car is actually done. Kat starts paperwork immediately.
- If you forgot a calibration after hitting Done, ping #Dispatch right away. Kat can fix it on the Zoho side before the invoice goes out.
- The button only shows on jobs that are dispatched to you. Requested cards and unassigned cards don't have it — they're not your work yet.

1 FAILURE & ESCALATION PROTOCOL

6 What to do when calibration won't complete

Every tech hits a calibration that refuses to complete. The difference between a professional and an amateur is having a systematic approach instead of guessing. Work through these steps in order before escalating.

Systematic Failure Checklist

ST EP	CHECK	WHY IT MATTERS
1	Re-read ALL OEM instructions from the beginning	The most common cause of failure is skipping or misreading a step. Start over with fresh eyes.
2	Verify EVERY prerequisite — don't assume	Fuel level, tire pressure, alignment status, engine running or off, HVAC on or off. Confirm them all.
3	Run a full fault scan across all modules	A fault in a related module (e.g., steering angle, ABS) can block an ADAS calibration. Find and address all faults first.
4	Check all physical connections	Unplug and re-seat the VCI. Check the OBD2 port for damage. Verify the target is clean and placed correctly with a fresh measurement.
5	Restart the tool and the vehicle	Power cycle the scan tool. Turn the vehicle off for 2 minutes, then restart. Attempt the calibration again.
6	Check for software/firmware updates	An outdated scan tool version may not support the vehicle's current module firmware. Update if available.
7	Call Mark or Kat	After two clean attempts following all steps above, don't keep guessing. Call for backup.

When to Stop and Escalate Immediately

- Damaged ADAS module or mounting bracket — calibrating a physically damaged module creates liability
- Active airbag or SRS faults — vehicle may not be safe to drive for a test run
- Suspected high-voltage system fault on an EV or hybrid
- Scan tool reports a module as "not found" after confirming the vehicle has that system
- Shop is pressuring you to skip prerequisites or sign off on an incomplete calibration
- You are genuinely unsure whether a calibration completed successfully

WHEN IN DOUBT, CALL MARK. NEVER RELEASE A VEHICLE WITH AN UNCOMPLETED REQUIRED CALIBRATION WITHOUT WRITTEN SHOP ACKNOWLEDGMENT.

Protecting Yourself When a Job Can't Be Completed

- Document in the invoice exactly what was attempted and why it could not be completed
- Note what the shop must do before rebooking (alignment, part replacement, etc.)

- Verbally inform the estimator and note their name in the invoice
- Do NOT clear ADAS fault codes without completing the calibration
- Take a photo of the dash showing any remaining fault lights

1 METRIC TEST ANSWERS**7** *Check your work from Section 04*

PROBLEM	ANSWER
1. Convert 2500 mm to meters.	2500 mm = 2.5 m
2. Convert 3.75 meters to centimeters.	3.75 m = 375 cm
3. Convert 450 cm to meters.	450 cm = 4.5 m
4. Convert 6.2 meters to millimeters.	6.2 m = 6,200 mm
5. Convert 875 mm to centimeters.	875 mm = 87.5 cm
6. Convert 5.5 meters to centimeters.	5.5 m = 550 cm
7. Convert 320 cm to millimeters.	320 cm = 3,200 mm
8. Convert 4.8 millimeters to centimeters.	4.8 mm = 0.48 cm
9. Convert 9.6 centimeters to meters.	9.6 cm = 0.096 m
10. Convert 7000 mm to meters.	7000 mm = 7 m

1 NOTES

8 *Use this space during training*

1 COMPANY CONTACTS**9** *Your team — know how to reach everyone*

NAME	ROLE	CONTACT
Mark Fowler	Owner	mfowler@absoluteadas.com
Jaden		
Kat		
Joyce		