Table of Contents

iMotions Lab > Sensor Setup > Shimmer (GSR, ECG, EMG, EXG)

Shimmer 3 - Initial Setup and Firmware Updates 2

Confidential © 2023 Redistribution is not permitted without written permission from iMotions

Shimmer 3 - Initial Setup and Firmware Updates

Instructions for initial setup of Shimmer 3 with iMotions and firmware updates using Shimmer Consensys software.

Requirements

- iMotions Lab with GSR, ECG, and/or EMG modules
- Bluetooth 2.1 Receiver (or newer) with standard drivers/configuration
- Shimmer 3 (GSR+ or EXG)
- Shimmer Consensys (for firmware update) - download link for version 1.60 (64-bit)

If the computer does not have a Bluetooth 2.1 receiver, an external USB Bluetooth 2.1 receiver (adapter/dongle) can be used. These Bluetooth Receivers have been used with iMotions and Shimmer 3:
Asus USB-BT500
Trust Myna Bluetooth 5 Adapter (not available in US)
Long-range Bluetooth adapter

Initial Setup for Shimmer in iMotions

For first-time use of any Shimmer 3 in iMotions, the device must be added in iMotions Settings-Sensors tab.

Click here to download a video

1. Confirm that Shimmer is on (the status LED will quickly flash green/blue when attempting to connect)
2. Click on "Preferences" then "Sensor Settings"
3. Click "New Devices"
4. Select "Shimmer" and enter a device name. Click Save when done.
5. Check "Enable data collection".
6. Select Shimmer options as needed. Click OK when done.

Confidential © 2023 Redistribution is not permitted without written permission from iMotions

7. The Shimmer will automatically connect and begin streaming data to iMotions (the status LED will remain blue).

Updating Shimmer Firmware

Shimmer firmware updates are designed to optimize device performance. These updates should be performed before initial use or when prompted in iMotions by warning in the Shimmer Sensor Widget.

Click here to download a video

1. Shimmer Consensys must be installed.
2. Connect the Shimmer Dock to the computer via USB and attach the Shimmer to the dock.
   Make sure to turn the Shimmer on.

3. Run Consensys and open Consensys Basic.
4. Select Manage Devices.
5. Download the most current firmware by clicking on the bell notification at the top right of Consensys.
6. Click on the Shimmer icon to detect the docked Shimmer, which must be powered on.
7. Click “Firmware” to enter the update interface.
8. Select "LogAndStream_Shimmer3_v0.16.0” and click “Program” to perform update.
9. Upon successful firmware installation (Status: 100% Complete), click “Done” and close Consensys. The Shimmer sensor will now stream all data via Bluetooth.

Powered by Document360

Confidential © 2023 Redistribution is not permitted without written permission from iMotions

Confidential © 2023 Redistribution is not permitted without written permission from iMotions