Table of Contents

iMotions Lab > Troubleshooting and Support

Shimmer Troubleshooting Guide 2

Confidential © 2023 Redistribution is not permitted without written permission from iMotions

Shimmer Troubleshooting Guide


This guide provides troubleshooting information for the Shimmer GSR and EXG.

General Recommendation: Windows firewall or other security exceptions may be needed for iMotions and Shimmer Consensys (Windows Settings Recommendations).

Troubleshooting Shimmer Connection

If a Shimmer device is unable to connect or disconnects frequently:


1. Confirm Shimmer firmware version is up-to-date ('LogAndStream_Shimmer3_v0.16.0', as of 2025).
    a. To find the firmware version in iMotions, click the "i" button in the Shimmer widget (while the Shimmer is connecting/connected)
    b. Firmware version is also shown in Shimmer Consensys software.



Shimmer firmware and connection information in iMotions


2. Confirm if device connects reliably to Shimmer Consensys software.

Confidential © 2023 Redistribution is not permitted without written permission from iMotions



Shimmer Consensys software with connected device

3. Confirm if device can be detected in Windows Bluetooth settings.
    a. 'Allow Bluetooth devices to find this PC' (in 'More Bluetooth settings') or other advanced settings may need to be enabled.
    b. Test Bluetooth connection with the computer and other devices (e.g. headphones).
    c. Check for Windows or Bluetooth driver updates.



Windows - 'More Bluetooth settings'

4. Test Shimmer connection with another computer.

Confidential © 2023 Redistribution is not permitted without written permission from iMotions

If a Shimmer is still unable to connect after these troubleshooting steps, it may be necessary to contact Shimmer Support (in coordination with iMotions Support).

Shimmer Support

In case of hardware issues (e.g. the Shimmer can not connect to Windows or Shimmer Consensys), assistance will be needed from Shimmer Support (support@shimmersensing.com) for a repair or RMA (Return Merchandise Authorization).

- Required information for Shimmer Support
- Contact Name, Shipping Address, and Phone Number
- Shimmer Radio ID (and purchase/invoice number, if available)
- Shimmer Firmware version
- Warranty Status (standard - 1 year from purchase)

To expedite processing with Shimmer Support, please confirm that the troubleshooting steps (described above) have been attempted, especially for the Shimmer firmware and Windows Bluetooth settings. Recordings showing connection attempts in Shimmer Consensys would expedite further.

Powered by Document360

Confidential © 2023 Redistribution is not permitted without written permission from iMotions

Confidential © 2023 Redistribution is not permitted without written permission from iMotions