
SK2
Memory
Below Backplane
SK4
TMS9918
SK6
CTC
SK8
FT245
SK10
SN76489A
SK11
Keyboard/Joypad
35
36
37
38
39
40
NC NC
NC /ENABLE
NC /PAGE_RESET
NC /PAGE_EN
NC NC
NC NC
NC /INT
NC GROMCLK
NC CPUCLK
NC NC
NC NC
NC NC
TG3 NC
TG2 NC
CLKSRC TG1
NC NC
IEI IEO
NC NC
NC NC
NC NC
NC NC
/INT NC
NC NC
NC NC
NC NC
NC
ENHANCED STANDARD
ENHANCED STANDARD
ENHANCED STANDARD
ENHANCED STANDARD
ENHANCED STANDARD
ENHANCED STANDARD