

HIGH PERFORMANCE WIDEBAND RF PLL/VCO WITH INTEGRATED RF MIXER

Package: QFN, 32-Pin, 5mmx5mm




Features

- 30MHz to 2.5GHz Frequency Range
- Fractional-N Synthesizer
- Very Fine Frequency Resolution 1.5 Hz for 26 MHz Reference
- Low Phase Noise VCO
- On-Chip Crystal-Sustaining Circuit With Programmable Loading Capacitors
- High-Linearity RF Mixer
- Integrated LO Buffer
- Mixer Input IP3 +18dBm
- Mixer Bias Adjustable for Low Power Operation
- 2.7 V to 3.6 V Power Supply
- Low Current Consumption 55 mA to 75 mA at 3 V
- 3-Wire Serial Interface

Applications

- CATV Head-Ends
- Digital TV Up/Down Converters
- Digital TV Repeaters
- Multi-Dwelling Units
- Cellular Repeaters
- Frequency Band Shifters
- UHF/VHF Radios
- Software Defined Radios
- Satellite Communications
- Super-Heterodyne Radios
- BPSK Modulator



Functional Block Diagram

Product Description

The RF2052 is a low power, high performance, wideband RF frequency conversion chip with integrated local oscillator (LO) generation and RF mixer. The RF synthesizer includes an integrated fractional-N phase locked loop with voltage controlled oscillators (VCOs) and dividers to produce a low-phase noise LO signal with a very fine frequency resolution. The buffered LO output drives the built-in RF mixer which converts the signal into the required frequency band. The mixer bias current can be programmed dependent on the required performance and available supply current. The LO generation blocks have been designed to continuously cover the frequency range from 300MHz to 2400MHz. The RF mixer is very broad band and operates from 30MHz to 2500MHz at the input and output, enabling both up and down conversion. An external crystal of between 10MHz and 52MHz or an external reference source of between 10MHz and 104MHz can be used with the RF2052 to accommodate a variety of reference frequency options.


All on-chip registers are controlled through a simple three-wire serial interface. The RF2052 is designed for 2.7V to 3.6V operation for compatibility with portable, battery powered devices. It is available in a plastic 32-pin, 5mmx5mm QFN package.

Optimum Technology Watching® Applied									
GaAs HBT	☐ SiGe BiCMOS	☐ GaAs pHEMT	☐ GaN HEMT						
GaAs MESFET	☐ Si BiCMOS	▼ Si CMOS	☐ RF MEMS						
InGaP HBT	☐ SiGe HBT	☐ Si BJT	☐ LDMOS						


RF MICRO DEVICES®, RFMD®, Optimum Technology Matching®, Enabling Wireless ConnectivityI^{IM}, PowerStar®, POLARIS™ TOTAL RADIO™ and UltimateBlue™ are trademarks of RFMD, LLC. BLUETOOTH is a trademark owned by Bluetooth SIG. Inc. LLS A and licensed for use by RFMD. All other trade names, trademarks and registered trademarks are the property of their respective owners. © 2006, RF Micro Devices, Inc.



Detailed Functional Block Diagram



Pin Out





1	f	m	d.	.c	o	n

Pin	Function	Description
1	ENBL	Ensure that the ENBL high voltage level is not greater than V _{DD} . An RC low-pass filter could be used to reduce digital noise.
2	INDP	VCO 3 differential inductor. Normally a micro-strip inductor is used to set the VCO 3 frequency range 1200 MHz to 1600 MHz.
3	INDN	VCO 3 differential inductor. Normally a micro-strip inductor is used to set the VCO 3 frequency range 1200 MHz to 1600 MHz.
4	REXT	External bandgap bias resistor. Connect a $51 \text{k}\Omega$ resistor from this pin to ground to set the bandgap reference bias current. This could be a sensitive low frequency noise injection point.
5	ANA_DEC	Analog supply decoupling capacitor. Connect to analog supply and decouple as close to the pin as possible.
6	LFILT1	Phase detector output. Low-frequency noise-sensitive node.
7	LFILT2	Loop filter op-amp output. Low-frequency noise-sensitive node.
8	LFILT3	VCO control input. Low-frequency noise-sensitive node.
9	MODE	Mode select pin. An RC low-pass filter can be used to reduce digital noise.
10	XTALIPP	Reference crystal / reference oscillator input. Should be AC-coupled if an external reference is used. See note 3.
11	XTALIPN	Reference crystal / reference oscillator input. Should be AC-coupled to ground if an external reference is used. See note 3.
12	GND	Connect to ground.
13	NC	
14	NC	
15	NC	
16	NC	
17	NC	
18	NC	
19	DIG_VDD	Digital supply. Should be decoupled as close to the pin as possible.
20	NC	
21	NC	
22	ANA_VDD	Analog supply. Should be decoupled as close to the pin as possible.
23	RFIPN	Differential input. See note 1.
24	RFIPP	Differential input. See note 1.
25	NC	
26	NC	
27	RFOPN	Differential output. See note 2.
28	RFOPP	Differential output. See note 2.
29	RESETB	Chip reset (active low). Connect to DIG_VDD if external reset is not required.
30	ENX	Serial interface select (active low). An RC low-pass filter could be used to reduce digital noise.
31	SCLK	Serial interface clock. An RC low-pass filter could be used to reduce digital noise.
32	SDATA	Serial interface data. An RC low-pass filter could be used to reduce digital noise.
EP	Exposed pad	Connect to ground. This is the ground reference for the circuit. All decoupling should be connected here through low impedance paths.

Note 1: The signal should be connected to this pin such that DC current cannot flow into or out of the chip, either by using AC coupling capacitors or by use of a transformer (see evaluation board schematic).

Note 2: DC current needs to flow from ANA_VDD into this pin, either through an RF inductor, or transformer (see evaluation board schematic).

Note 3: Alternatively an external reference can be AC-coupled to pin 11 XTALIPN, and pin 10 XTALIPP decoupled to ground. This may make PCB routing simpler.



Absolute Maximum Ratings

Parameter	Rating	Unit
Supply Voltage (V _{DD})	-0.5 to +3.6	V
Input Voltage (V _{IN}), any Pin	-0.3 to V _{DD} +0.3	V
RF/IF Mixer Input Power	+15	dBm
Operating Temperature Range	-40 to +85	°C
Storage Temperature Range	-40 to +150	°C



Caution! ESD sensitive device.

Exceeding any one or a combination of the Absolute Maximum Rating conditions may cause permanent damage to the device. Extended application of Absolute Maximum Rating conditions to the device may reduce device reliability. Specified typical performance or functional operation of the device under Absolute Maximum Rating conditions is not implied.

RoHS status based on EUDirective 2002/95/EC (at time of this document revision).

The information in this publication is believed to be accurate and reliable. However, no responsibility is assumed by RF Micro Devices, Inc. ("RFMD") for its use, nor for any infringement of patents, or other rights of third parties, resulting from its use. No license is granted by implication or otherwise under any patent or patent rights of RFMD. RFMD reserves the right to change component circuitry, recommended application circuitry and specifications at any time without prior notice.

Davamatav	S	pecificatio	n	Hoit	Condition		
Parameter	Min.	Тур.	Max.	Unit	Condition		
ESD Requirements		_		_			
Human Body Model							
General	2000			V			
RF Pins	1000			V			
Machine Model							
General	200			V			
RF Pins	100			V			
Operating Conditions							
Supply Voltage (V _{DD})	2.7	3.0	3.6	V			
Temperature (T _{OP})	-40		+85	°C			
Logic Inputs/Outputs					V _{DD} =Supply to DIG_VDD pin		
Input Low Voltage	-0.3		+0.5	V			
Input High Voltage	1.5		V_{DD}	V			
Input Low Current	-10		+10	uA	Input=0V		
Input High Current	-10		+10	uA	Input=V _{DD}		
Output Low Voltage	0		0.2*V _{DD}	V			
Output High Voltage	0.8*V _{DD}		V_{DD}	V			
Load Resistance	10			kΩ			
Load Capacitance			20	pF			
Static							
Programmable Supply Current (I _{DD})							
Low Current Setting		55		mA			
High Linearity Setting		75		mA			
Standby		3		mA	Reference oscillator and bandgap only.		
Power Down Current		140		μΑ	ENBL=0 and REF_STBY=0		
Mixer					Mixer output driving 4:1 balun.		
Gain		-2		dB	Not including balun losses.		
Noise Figure							
Low Current Setting		9.5		dB			
High Linearity Setting		12		dB			






Davamatav		Specification	n	Unit	Condition		
Parameter	Min.	Тур.	Max.	Unit			
Mixer, cont.							
IIP ₃							
Low Current Setting		+10		dBm			
High Linearity Setting		+18		dBm			
Pin1dB							
Low Current Setting		+2		dBm			
High Linearity Setting		+12		dBm			
RF and IF Port Frequency Range	30		2500	MHz			
Mixer Input Return Loss		10		dB	100Ω differential		
Voltage Controlled Oscillator							
Open Loop Phase Noise at 1MHz Offset							
2GHz LO Frequency		-130		dBc/Hz			
1GHz LO Frequency		-135		dBc/Hz			
500MHz LO Frequency		-140		dBc/Hz			
Reference Oscillator							
Xtal Frequency	10		52	MHz			
External Reference Frequency	10		104	MHz			
Reference Divider Ratio	1		7				
External Reference Input Level	500	800	1500	mV _{P-P}	AC-coupled		
Local Oscillator							
Synthesizer Output Frequency	300		2400	MHz	Dependant on VCO 3 external inductor. After LO dividers.		
Phase Detector Frequency			52	MHz			
Closed Loop Phase-Noise at 10 kHz Offset					26MHz phase detector frequency		
2GHz LO Frequency		-90		dBc/Hz			
1GHz LO Frequency		-95		dBc/Hz			
500MHz LO Frequency		-102		dBc/Hz			




Typical Performance Characteristics: Synthesizer and VCO - V_{DD} =3V, T_A =25°C, as measured on RF2052 evaluation board, for application schematic see page 34. Phase Detector Frequency=26MHz, Loop Bandwidth=60kHz.






Typical Performance Characteristics: Synthesizer and VCO - V_{DD} =3V, T_A =25°C unless stated, as measured on RF2052 evaluation board, for application schematic see page 34.






Typical Performance Characteristics: RF Mixer - V_{DD} = 3V, T_A = 25 °C unless stated, as measured on RF2052 evaluation board, for application schematic see page 34.





Typical Performance Characteristics: RF Mixer - V_{DD} =3V, T_A =25 °C unless stated, as measured on RF2052 evaluation board, for application schematic see page 34.





Detailed Description

The RF2052 is a wideband RF frequency converter chip which includes a fractional-N phase-locked loop, a crystal oscillator circuit, a low noise VCO core, an LO buffer, and an RF mixer. Synthesizer programming, device configuration and control are achieved through a mixture of hardware and software controls. All on-chip registers are programmed through a simple three-wire serial interface.

VCO

The VCO core in the RF2052 consists of three VCOs which, in conjunction with the integrated 2/4 LO divider, cover the LO range from 300 MHz to 2400 MHz.

VCO	Tank Inductor	VCO Frequency Range		DIV 4
1	Internal	1800MHz to 2400MHz	900 MHz to 1200 MHz	450 MHz to 600 MHz
2	Internal	1500 MHz to 2100 MHz	750MHz to 1050MHz	375MHz to 525MHz
3	External	1200 MHz to 1600 MHz*	600 MHz to 800 MHz	300MHz to 400MHz

^{*}The frequency of VCO3 is set by external inductors and can be varied by the user.

VCO 1, 2, and 3 are selected using the PLL2x0:P2_VCOSEL control word. Each VCO has 128 overlapping bands to achieve an acceptable VCO gain (20MHz/V nom) and hence a good phase noise performance across the whole tuning range. The chip automatically selects the correct VCO band ("VCO coarse tuning") to generate the desired LO frequency based on the values programmed into the PLL2 registers bank. For information on how to program the desired LO frequency refer to page 11.

The automatic VCO band selection is triggered every time the ENBL pin is taken high. Once the band has been selected the PLL will lock onto the correct frequency. During the band selection process fixed capacitance elements are progressively connected to the VCO resonant circuit until the VCO is oscillating at approximately the correct frequency. The output of this band selection is made available in the RB1:CT_CAL read-back register. A value of 127 or 0 in this register indicates that the selection was unsuccessful, this is usually due to the wrong VCO being selected so the user is trying to program a frequency that is outside of the VCO operating range. A value between 1 and 126 indicates a successful calibration, the actual value being dependent on the desired frequency as well as process variation for a particular device. The band selection takes approximately 1500 cycles of the phase detector clock (about 50 us with a 26MHz clock). The band select process will center the VCO tuning voltage at about 1.2V, compensating for manufacturing tolerances and process variation as well as environmental factors including temperature. For applications where the synthesizer is always on and the LO frequency is fixed, the synthesizer will maintain lock over a +/-60°C temperature range. However it is recommended to re-initiate an automatic band selection for every 30 degrees change in temperature in order to maintain optimal synthesizer performance. This assumes an active loop filter. If start-up time is a critical parameter, and the user is always programming the same frequency for the PLL, the calibration result may be read back from the RB1:CT_CAL register, and written to the PLL2x2:P2_CT_DEF register. The calibration function must then be disabled by setting the PLL2x0:P2_CT_EN control word to 0. For further information please refer to the RF205x Calibration User Guide.

When operating using VCO1 for frequencies above 2.2 GHz, it is recommended to change the coarse tuning voltage setting, PLL2x5:P2_CT_V, from the default value of 16 down to 12.

The LO divide ratio is set by the PLL2x0:P2_LODIV control words.

The current in the VCO core can be programmed using the PLL2x3:P2_VCOI control word. This allows optimization of VCO performance for a particular frequency. For applications where the required LO frequency is above 2GHz it is recommended that the LO buffer current be increased by setting CFG5:LO2_I to 1100 (hex value C).



Fractional-N PLL

The IC contains a charge-pump based fractional-N phase locked loop (PLL) for controlling the three VCOs. The PLL includes automatic calibration systems to counteract the effects of process and environmental variations, ensuring repeatable lock-time and noise performance. The PLL is intended to use a reference frequency signal of 10MHz to 104MHz. A reference divider (divide by 1 to divide by 7) is supplied and should be programmed to limit the frequency at the phase detector to a maximum of 52MHz. The reference divider bypass is controlled by bit CLK DIV_BYP, set low to enable the reference divider and set high for divider bypass (divide by 1). The remaining three bits CLK DIV<15:13> set the reference divider value, divide by 2 (010) to 7 (111) when the reference divider is enabled.

Two PLL programming banks are provided, the first bank is preceded by the label PLL1 and the second bank is preceded by the label PLL2. For the RF2052 the default programming bank is PLL2, selected by setting the MODE pin high.

The PLL will lock the VCO to the frequency F_{VCO} according to:

where N_{EFF} is the programmed fractional N divider value, F_{OSC} is the reference input frequency, and R is the programmed R divider value (1 to 7).

The N divider is a fractional divider, containing a dual-modulus prescaler and a digitally spur-compensated fractional sequence generator to allow fine frequency steps. The N divider is programmed using the N and NUM bits as follows:

First determine the desired, effective N divider value, N_{FFE}:

N(9:0) should be set to the integer part of N_{EFF} . NUM should be set to the fractional part of N_{EFF} multiplied by 2^{24} = 16777216.

Example: VCO1 operating at 2220MHz, 23.92MHz reference frequency, the desired effective divider value is:

$$N_{EFF} = F_{VCO} *R / F_{OSC} = 2220 *1 / 23.92 = 92.80936454849.$$

The N value is set to 92, equal to the integer part of N_{EFF}, and the NUM value is set to the fractional portion of N_{EFF} multiplied by 2^{24} :

Converting N and NUM into binary results in the following:

N=0 0101 1100 NUM=1100 1111 0011 0010 1000 0100

So the registers would be programmed:

P2_N=0 0101 1100 P2_NUM_MSB=1100 1111 0011 0010 P2_NUM_LSB=1000 0100

The maximum N_{EFF} is 511, and the minimum N_{EFF} is 15, when in fractional mode. The minimum step size is $F_{OSC}/R*2^{24}$. Thus for a 23.92MHz reference, the frequency step size would be 1.4Hz. The minimum reference frequency that could be used to program a frequency of 2400MHz (using VCO1) is 2400/511, 4.697MHz (approx).



Phase Detector and Charge Pump

The chip provides a current output to drive an external loop filter. An on-chip operational amplifier can be used to design an active loop filter or a passive design can be implemented. The maximum charge pump output current is set by the value contained in the P2_CP_DEF field and CP_LO_I.

In the default state (P2_CP_DEF=31 and CP_LO_I=0) the charge pump current (ICPset) is 120 uA. If CP_LO_I is set to 1 this current is reduced to 30 uA.

The charge pump current can be altered by changing the value of P2_CP_DEF. The charge pump current is defined as:


If automatic loop bandwidth correction is enabled the charge pump current is set by the calibration algorithm based upon the VCO gain. For more information on the VCO gain calibration, which is disabled by default, please refer to the RF205x Calibration User Guide.

The phase detector will operate with a maximum input frequency of 52 MHz.

Note that for high phase detector frequencies, the divider ratio decreases. For N<28 the FLL_FACT register needs to be changed to 00 from the default value of 01. This is to ensure correct VCO band selection.

Loop Filter

The PLL may be designed to use an active or a passive loop filter as required. The internal configuration of the chip is shown below. If the CFG1:LF_ACT bit is asserted high, the op-amp will be enabled. If the CFG1:LF_ACT bit is asserted low, the internal op-amp is disabled and a high impedance is presented to the LFILT1 pin. The RF205x Programming Tool software can assist with loop filter designs. Because the op-amp is used in an inverting configuration in active mode, when the passive loop filter mode is selected the phase-detector polarity should be inverted. For active mode, CFG1:PDP=1, for passive mode, CFG1:PDP=0.



The charge pump output voltage compliance range is typically +0.7V to +1.5V. For applications using a passive loop filter VCO coarse tuning must be performed regularly enough to ensure that the VCO tuning voltage falls within this compliance range at all temperatures. The active loop filter maintains the charge pump output voltage in the center of the compliance range, and the op-amp provides a wider VCO tuning voltage range, typical OV to +2.4V.



Crystal Oscillator

The PLL may be used with an external reference source, or its own crystal oscillator. If an external source (such as a TCXO) is being used it should be AC-coupled into one of the XO inputs, and the other input should be AC-coupled to ground.

A crystal oscillator typically takes many milliseconds to settle, and so for applications requiring rapid pulsed operation of the PLL (such as a TDMA system, or Rx/Tx half-duplex system) it is necessary to keep the XO running between bursts. However, when the PLL is used less frequently, it is desirable to turn off the XO to minimize current draw. The REFSTBY register is provided to allow for either mode of operation. If REFSTBY is programmed high, the XO will continue to run even when ENBL is asserted low. Thus the XO will be stable and a clock is immediately available when ENBL is asserted high, allowing the chip to assume normal operation. On cold start, or if REFSTBY is programmed low, the XO will need a warm-up period before it can provide a stable clock. The length of this warm-up period will be dependent on the crystal characteristics.

The crystal oscillator circuit contains internal loading capacitors. No external loading capacitors are required, dependant on the crystal loading specification. The internal loading capacitors are a combination of fixed capacitance, and an array of switched capacitors. The switched capacitors can be used to tune the crystal oscillator onto the required center frequency and minimize frequency error. The PCB stray capacitance and oscillator input and output capacitance will also contribute to the crystal's total load capacitance. The register settings in the CFG4 register for the switched capacitors are as follows:

- Coarse Tune XO_CT (4 bits) 15 * 0.55 pF, default 0100
- Fine Step XO_CR_S (1 bit) 1 * 0.25 pF, default 0

The on chip fixed capacitance is approximately 4.2 pF.

Wideband Mixer

The RF2052 includes a wideband, double-balanced Gilbert cell mixer. It supports RF/IF frequencies of 30MHz to 2500MHz using the internal VCO to provide the LO frequency of 300MHz to 2400MHz. The mixer has an input port and an output port that can be used for either IF or RF, i.e. for up conversion or down conversion. The mixer current can be programmed to between 15mA and 35mA depending on linearity requirements, using the MIX2_IDD<3:0> word in the CFG2 register. The majority of the mixer current is sourced through the output pins via either a centre-tapped balun or an RF choke in the external matching circuitry to the supply.

The RF mixer input and output ports are differential and require simple matching circuits optimized to the specific application frequencies. A conversion gain of approximately -3dB to 0dB is achieved with 100Ω differential input impedance, and the outputs driving 200Ω differential load impedance. Increasing the mixer output load increases the conversion gain.

The mixer has a broadband common gate input. The input impedance is dominated by the resistance set by the mixer 1/gm term, which is inversely proportional to the mixer current setting. The resistance will be approximately 85Ω at the default mixer current setting (100). There is also some shunt capacitance at the mixer input, and the inductance of the bond wires to consider at higher frequencies.

The mixer output is high impedance, consisting of a resistance of approximately $2k\Omega$ in parallel with some capacitance. The mixer output does not need to be matched as such, just to see a resistive load. A higher resistance load will give higher output voltage and gain. A shunt inductor can be used to resonate with the mixer output capacitance at the frequency of interest. This inductor may not be required at lower frequencies where the impedance of the output capacitance is less significant. At higher output frequencies the inductance of the bond wires becomes more significant.


For more information about the mixer port impedances and matching, please refer to the RF205x Family Application Note on Matching Circuits and Baluns.




General Programming Information

Serial Interface

All on-chip registers in the RF2052 are programmed using a 3-wire serial bus which supports both write and read operations. Synthesizer programming, device configuration and control are achieved through a mixture of hardware and software controls. Certain functions and operations require the use of hardware controls via the ENBL, MODE, and RESETB pins in addition to programming via the serial bus. For most applications the MODE pin can be held high.




Serial Data Timing Characteristics



Parameter	Description	Time
t1	Reset delay	>5ns
t2	Programming setup time	>5ns
t3	Programming hold time	>5ns
t4	ENX setup time	>5 ns
t5	ENX hold time	>5ns
t6	Data setup time	>5ns
t7	Data hold time	>5ns
t8	ENBL setup time	>0 ns
t9	ENBL hold time	>0 ns



Write



Initially ENX is high and SDATA is high impedance. The write operation begins with the controller starting SCLK. On the first falling edge of SCLK the baseband asserts ENX low. The second rising edge of SCLK is reserved to allow the SDI to initialize, and the third rising edge is used to define whether the operation will be a write or a read operation. In write mode the baseband will drive SDATA for the entire telegram. RF2052 will read the data bit on the rising edge of SCLK.


The next 7 data bits are the register address, MSB first. This is followed by the payload of 16 data bits for a total write mode transfer of 24 bits. Data is latched into RF2052 on the last rising edge of SCLK (after ENX is asserted high).

For more information, please refer to the timing diagram on page 14.

The maximum clock speed for a register write is 19.2 MHz. A register write therefore takes approximately 1.3 us. The data is latched on the rising edge of the clock. The datagram consists of a single start bit followed by a '0' (to indicate a write operation). This is then followed by a seven bit address and a sixteen bit data word.

Note that since the serial bus does not require the presence of the crystal clock, it is necessary to insert an additional rising clock edge before the ENX line is set low to ensure the address/data are read correctly.

Read



Initially ENX is high and SDATA is high impedance. The read operation begins with the controller starting SCLK. The controller is in control of the SDATA line during the address write operation. On the first falling edge of SCLK the baseband asserts ENX low. The second rising edge of SCLK is reserved to allow the SDI to initialize, and the third rising edge is used to define whether the operation will be a write or a read operation. In read mode the baseband will drive SDATA for the address portion of the telegram, and then control will be handed over to RF2052 for the data portion. RF2052 will read the data bits of the address on the rising edge of SCLK. After the address has been written, control of the SDATA line is handed over to RF2052. One and a half clocks are reserved for turn-around, and then the data bits are presented by RF2052. The data is set up on the rising edge of SCLK, and the controller latches the data on the falling edge of SCLK. At the end of the data transmission, RF2052 will release control of the SDATA line, and the controller asserts ENX high. The SDATA port on RF2052 transitions from high impedance to low impedance on the first rising edge of the data portion of the transaction (for example, 3 rising edges after the last address bit has been read), so the controller chip should be presenting a high impedance by that time.

For more information, please refer to the timing diagram on page 14.

The maximum clock speed for a register read is 19.2 MHz. A register read therefore takes approximately 1.4 us. The address is latched on the rising edge of the clock and the data output on the falling edge. The datagram consists of a single start bit fol-



lowed by a '1' (to indicate a read operation), followed by a seven bit address. A 1.5 bit delay is introduced before the sixteen bit data word representing the register content is presented to the receiver.

Note that since the serial bus does not require the presence of the crystal clock, it is necessary to insert an additional rising clock edge before the ENX line is set low to ensure the address is read correctly.

Hardware Control

Three hardware control pins are provided: ENBL, MODE, and RESETB.

ENBL Pin

The ENBL pin has two functions: to enable the analog circuits in the chip and to trigger the VCO band selection as described in the VCO section on page 10.

ENBL Pin	REFSTBY Bit	XO and Bias Block	Analogue Block	Digital Block
Low	0	Off	Off	On
Low	1	On	Off	On
High	0	On	On	On
High	1	On	On	On

As outlined in the VCO section the chip has a built-in automatic VCO band selection to tune the selected VCO to the desired frequency. The band selection is initiated when the ENBL pin is taken high. Every time the frequency of the synthesizer is re-programmed, the ENBL has to be inserted high to initiate the automatic VCO band selection (VCO coarse tune).


RESETB Pin

The RESETB pin is a hardware reset control that will reset all digital circuits to their start-up state when asserted low. The device includes a power-on-reset function, so this pin should not normally be required, in which case it should be connected to the positive supply.

MODE Pin

The MODE pin controls which PLL programming register bank is active.

For normal operation of the RF2052 the MODE pin should be set high to select the default PLL2 programming registers. It is possible to set the FULLD bit in the CFG1 register high. This allows the MODE pin to select either PLL1 register bank (MODE=low) or PLL2 register bank (MODE=high). This may be useful for some applications where two LO frequencies can be programmed into the registers then the MODE pin used to toggle between them. The ENBL pin will also need to be cycled to relock the synthesizer for each frequency.




Parameter	Description	Time
t1	MODE setup time	>5 ns
t2	MODE hold time	>5 ns



Programming the RF2052

The figure below shows an overview of the device programming.



Note: The set-up processes 1 to 2, 2 to 3, and 3 to 4 are explained further below.

Additional information on device use and programming can be found on the RF205x family page of the RFMD web site (http://www.rfmd.com/rf205x). The following documents may be particularly helpful:

- RF205x Frequency Synthesizer User Guide
- RF205x Calibration User Guide




Start-up

When starting up and following device reset then REFSTBY=0, REFSTBY should be asserted high approximately $500\,\mu s$ before ENBL is taken high. This is to allow the XO to settle and will depend on XO characteristics. The various calibration routines will also take some time depending on whether they are enabled or not. Coarse tuning calibration takes about $50\,\mu s$ and VCO tuning gain compensation takes about $100\,\mu s$. Additionally, time for the PLL to settle will be required. All of these timings will be dependant upon application specific factors such as loop filter bandwidth, reference clock frequency, XO characteristics and so on. The fastest turn-on and lock time will be obtained by leaving REFSTBY asserted high, disabling all calibration routines, and setting the PLL loop bandwidth as wide as possible.

The device can be reset into its initial state (default settings) at any time by performing a hard reset. This is achieved by setting the RESETB pin low for at least 100 ns.

Setting Up Device Operation

The device offers a number of operating modes which need to be set up in the device before it will work as intended. This is achieved as follows.




Three registers need to be written, taking 3.9us at the maximum clock speed. If the device is used with an active filter in simplex operation it will not be necessary to program CFG1 reducing the programming time to 2.6us.



Setting Up VCO Coarse Tuning and Loop Filter Calibration

If the user wishes to disable the VCO coarse tune calibration or enable the loop filter calibration then the following programming operation will need to take place.




Two registers need to be written taking 2.6 us at maximum clock speed if the course tuning is deactivated or the loop filter calibration activated. Since it is necessary to program these registers when setting the operating frequency (see next section) this operation usually carries no overhead.

The coarse tune calibration takes approximately 50 us when using a 26MHz reference clock (it will take proportionally longer if a slower clock is used, and vice versa).



Setting The Operating Frequency

Setting the operating frequency of the device requires a number of registers to be programmed.



A total of four registers must be programmed to set the device operating frequency. This will take 5.2 us for each path at maximum clock speed.

To change the frequency of the VCO it will be necessary to repeat these operations. However, if the frequency shift is small it may not be necessary to reprogram the VCOSEL and LODIV bits reducing the register writes to three.

For an example on how to determine the integer and fractional parts of the synthesizer PLL division ratio please refer to the detailed description of the PLL on page 11.



Programming Registers

Register Map Diagram

	1 1																	1
Reg.	R/W	Add				Data												
Name	,		15	14	13	12	11	10	თ	8	7	6	5	4	3	2	1	0
CFG1	R/W	00	LD_EN	LD_LEV			TVCO)		PDP	LF_ACT		CPL	CT_POL	Res	EXT_VCO	FULLD	CP_LO_I
CFG2	R/W	01	M	IIX1_IDD		MIX:	1_VB	MI	X2_II	DD	MIX2	_VB	Res	KV_RNG	NBR	CT_AVG	NBR_k	KV_AVG
CFG3	R/W	02		TKV1				TK	V2				Res		FL	L_FACT	CT_CPOL	REFSTBY
CFG4	R/W	03	CLI	K_DIV_B	/PASS	6		XO_	_CT		X0_I2	XO_I1	XO_CR_S			TCT		
CFG5	R/W	04		L01_l				LO:	2_I					T_PH_/	ALGN	l		
CFG6	R/W	05					SU_W									Res		
PLL1x0	R/W	08	P1_V	COSEL		CT_E N	P1_k			LODI /	Re	es			P1_	CP_DEF		
PLL1x1	R/W	09									P1_N	NUM_M	ISB					
PLL1x2	R/W	OA			P1_N	UM_I	_SB						Р	1_CT_DEF	=			Res
PLL1x3	R/W	OB				P1	_N						Res	6	_		P1_VCOI	
PLL1x4	R/W	OC				P1 _.	_DN						P1_CT_GAIN P1_KV_GAIN			GAIN	Res	
PLL1x5	R/W	OD				L_N_F							Res P1_CT_V					
PLL2x0	R/W	10	P2_V	COSEL		CT_E N	P2_K N		_	LODI /	Re	es	P2_CP_DEF					
PLL2x1	R/W	11					•				P2_N	P2_NUM_MSB						
PLL2x2	R/W	12			P2_N	UM_I	SB						P2_CT_DEF R			Res		
PLL2x3	R/W	13				P2	2_N						Res	5			P2_VCOI	
PLL2x4	R/W	14				P2	_DN						P2_CT_GA	AIN		P2_KV_0	SAIN	Res
PLL2x5	R/W	15				2_N_F		ADJ					Res			P2_CT_	_V	
GPO	R/W	18	Res	P1_GPC 1	Res	P1_ GPO 3	P1_ GPO 4			Res		P2_GP 01	P Res	P2_GP0 3	P2_ GP0 4		Res	
CHIPREV	R	19	PARTNO							•		REV	NO	•				
RB1	R	1C	LOCK CT_CAL							CP_CAL Res								
RB2	R	1D	VO_CAL						V1_CAL									
RB3	R	1E	RSM_STATE								Res							
TEST	R	1F	TEN TMUX				CPU	CPD	FNZ	LDO _BY P	TSEL Res DACTEST				Res			



CFG1 (00h) - Operational Configuration Parameters

#	Bit Name	Default		Function
15	LD_EN	1	9	Enable lock detector circuitry
14	LD_LEV	0		Modify lock range for lock detector
13	TVCO(4:0)	0		VCO warm-up time=TVCO/(F _{REF} * 256)
12		0		
11		0	1	
10		0		
9		0		
8	PDP	1		Phase detector polarity: 0=positive, 1=negative
7	LF_ACT	1	С	Active loop filter enable, 1=Active 0=Passive
6	CPL(1:0)	1		Charge pump leakage current: 00=no leakage, 01=low leakage, 10=mid leakage, 11=high
5		0		leakage
4	CT_POL	0		Polarity of VCO coarse-tune word: 0=positive, 1=negative
3		0	0	
2	EXT_VCO	0		0=Normal operation 1=external VCO (VCO3 disabled, KV_CAL and CT_CAL must be disabled)
1	FULLD	0		0=Half duplex, mixer is enabled according to MODE pin, 1=Full duplex, both mixers enabled
0	CP_LO_I	0		0=High charge pump current, 1=low charge pump current

CFG2 (01h) - Mixer Bias and PLL Calibration

#	Bit Name	Def	ault	Function
15	MIX1_IDD	1	8	This register is not used for the RF2052.
14		0		
13]	0		
12	MIX1_VB	0		This register is not used for the RF2052.
11]	1	С	
10	MIX2_IDD	1		Mixer 2 current setting: 000=0 mA to 111=35 mA in 5 mA steps
9]	0		
8]	0		
7	MIX2_VB	0	5	Mixer 2 voltage bias
6]	1		
5		0		
4	KV_RNG	1		Sets accuracy of voltage measurement during KV calibration: 0=8bits, 1=9bits
3	NBR_CT_AVG	1	8	Number of averages during CT cal
2	1	0		
1	NBR_KV_AVG	0		Number of averages during KV cal
0		0		



CFG3 (02h) - PLL Calibration

#	Bit Name	Def	ault	Function
15	TKV1	0	0	Settling time for first measurement in LO KV compensation
14		0		
13		0		
12		0		
11	TKV2	0	4	Settling time for second measurement in LO KV compensation
10		1		
9		0		
8		0		
7		0	0	
6		0		
5		0		
4		0		
3	FLL_FACT	0	4	Default setting 01. Needs to be set to 00 for N<28. This case can arise when higher phase
2		1		detector frequencies are used.
1	CT_CPOL	0		
0	REFSTBY	0		Reference oscillator standby mode 0=X0 is off in standby mode, 1=X0 is on in standby mode

CFG4 (O3h) - Crystal Oscillator and Reference Divider

#	Bit Name	Def	ault	Function
15	CLK_DIV	0	1	Reference divider, divide by 2 (010) to 7 (111) when reference divider is enabled
14		0		
13		0		
12	CLK_DIV_BYPASS	1		Reference divider enabled=0, divider bypass (divide by 1)=1
11	XO_CT	1	8	Crystal oscillator coarse tune (approximately 0.5 pF steps from 8 pF to 16 pF)
10		0		
9		0		
8		0		
7	XO_I2	0	0	Crystal oscillator current setting
6	XO_I1	0		
5	XO_CR_S	0		Crystal oscillator additional fixed capacitance (approximately 0.25 pF)
4	TCT	0		Duration of coarse tune acquisition
3		1	F	
2		1		
1		1		
0		1		



CFG5 (04h) - LO Bias

#	Bit Name	Def	ault	Function
15	L01_I	0	0	Local oscillator Path1 current setting
14		0		
13		0		
12		0		
11	L02_I	0	0	Local oscillator Path2 current setting
10		0		
9		0		
8		0		
7	T_PH_ALGN	0	0	Phase alignment timer
6		0		
5		0		
4		0		
3		0	4	
2		1		
1		0		
0		0		

CFG6 (05h) - Start-up Timer

#	Bit Name	Def	ault	Function
15	SU_WAIT	0	0	Crystal oscillator settling timer.
14]	0		
13]	0		
12		0		
11		0	1	
10]	0		
9		0		
8		1		
7		0	0	
6		0		
5		0		
4		0		
3		0	0	
2		0		
1		0		
0		0		



PLL1x0 (08h) - VCO, LO Divider and Calibration Select

#	Bit Name	Def	ault	Function
15	P1_VCOSEL	0	7	Path 1 VCO band select: 00=VCO1, 01=VCO2, 10=VCO3, 11=Reserved
14		1		
13	P1_CT_EN	1		Path 1 VCO coarse tune: 00=disabled, 11=enabled
12		1		
11	P1_KV_EN	0	1	Path 1 VCO tuning gain calibration: 00=disabled, 11=enabled
10		0		
9	P1_LODIV	0		Path 1 local oscillator divider: 00=divide by 1, 01=divide by 2, 10=divide by 4, 11=reserved
8		1		
7		0	1	
6		0		
5	P1_CP_DEF	0		Charge pump current setting
4		1		If P1_KV_EN=11 this value sets charge pump current during KV compensation only
3		1	F	
2	1	1	1	
1		1	1	
0		1		

PLL1x1 (09h) - MSB of Fractional Divider Ratio

#	Bit Name	Def	ault	Function
15	P1_NUM_MSB	0	6	Path 1 VCO divider numerator value, most significant 16 bits
14		1		
13		1		
12		0		
11		0	2	
10		0		
9		1		
8		0		
7		0	7	
6		1		
5		1		
4		1		
3		0	6	
2		1		
1		1		
0		0		



PLL1x2 (0Ah) - LSB of Fractional Divider Ratio and CT Default

#	Bit Name	Def	ault	Function
15	P1_NUM_LSB	0	2	Path 1 VCO divider numerator value, least significant 8 bits
14		0		
13		1		
12		0		
11		0	7	
10		1		
9		1		
8		1		
7	P1_CT_DEF	0	7	Path 1 VCO coarse tuning value, used when P1_CT_EN=00
6		1		
5		1		
4		1		
3		1	E	
2		1		
1		1		
0		0		

PLL1x3 (0Bh) - Integer Divider Ratio and VCO Current

#	Bit Name	Def	ault	Function
15	P1_N	0	2	Path 1 VCO divider integer value
14		0		
13		1		
12		0		
11		0	3	
10		0		
9		1		
8		1		
7		0	0	
6		0		
5		0		
4		0		
3		0	2	
2		0		Path 1 VCO bias setting: 000=minimum value, 111=maximum value
1		1		
0		0		



PLL1x4 (0Ch) - Calibration Settings

#	Bit Name	Def	ault	Function
15	P1_DN	0	1	Path 1 frequency step size used in VCO tuning gain calibration
14		0		
13		0		
12		1		
11		0	7	
10		1		
9		1		
8		1		
7		1	E	
6	P1_CT_GAIN	1		Path 1 coarse tuning calibration gain
5		1		
4		0		
3	P1_KV_GAIN	0	4	Path 1 VCO tuning gain calibration gain
2		1		
1		0]	
0		0	1	

PLL1x5 (0Dh) - More Calibration Settings

#	Bit Name	Def	ault	Function
15	P1_N_PHS_ADJ	0	0	Path 1 frequency step size used in VCO tuning gain calibration
14		0		
13		0		
12		0		
11		0	0	
10		0		
9		0		
8		0		
7		0	1	
6		0		
5		0		
4	P1_CT_V	1		Path 1 course tuning voltage setting when performing course tuning calibration. Default
3		0	0	value is 16. Change to 12 when using VCO1 for frequencies above 2.2 GHz.
2		0	1	
1		0	1	
0		0		



PLL2x0 (10h) - VCO, LO Divider and Calibration Select

#	Bit Name	Def	ault	Function
15	P2_VCOSEL	0	7	Path 2 VCO band select: 00=VCO1, 01=VCO2, 10=VCO3, 11=Reserved
14		1		
13	P2_CT_EN	1		Path 2 VCO coarse tune: 00=disabled, 11=enabled
12		1		
11	P2_KV_EN	0	1	Path 2 VCO tuning gain calibration: 00=disabled, 11=enabled
10		0		
9	P2_LODIV	0		Path 2 local oscillator divider: 00=divide by 1, 01=divide by 2, 10=divide by 4, 11=reserved
8		1		
7			1	
6				
5	P2_CP_DEF	0		Charge pump current setting.
4		1		If P2_KV_EN=11 this value sets charge pump current during KV compensation only
3		1	F	
2		1		
1		1	1	
0		1	1	

PLL2x1 (11h) - MSB of Fractional Divider Ratio

#	Bit Name	Def	ault	Function
15	P2_NUM_MSB	0	6	Path 2 VCO divider numerator value, most significant 16 bits
14		1		
13		1		
12		0		
11		0	2	
10		0		
9		1		
8		0		
7		0	7	
6		1		
5		1		
4		1		
3		0	6	
2		1		
1		1		
0		0		



PLL2x2 (12h) - LSB of Fractional Divider Ratio and CT Default

#	Bit Name	Def	ault	Function
15	P2_NUM_LSB	0	2	Path 2 VCO divider numerator value, least significant 8 bits.
14		0		
13		1		
12		0		
11		0	7	
10		1		
9		1		
8		1		
7	P2_CT_DEF	0	7	Path 2 VCO coarse tuning value, used when P2_CT_EN=00
6		1		
5		1		
4		1		
3		1	E	
2		1		
1		1		
0		0		

PLL2x3 (13h) - Integer Divider Ratio and VCO Current

#	Bit Name	Def	ault	Function
15	P2_N	0	2	Path 2 VCO divider integer value
14		0		
13		1		
12		0		
11		0	3	
10		0		
9		1		
8		1		
7		0	0	
6		0		
5		0		
4		0		
3		0	2	
2	P2_VCOI	0		Path 1 VCO bias setting: 000=minimum value, 111=maximum value
1	1	1		
0		0		



PLL2x4 (14h) - Calibration Settings

#	Bit Name	Def	ault	Function
15	P2_DN	0	1	Path 2 frequency step size used in VCO tuning gain calibration
14		0		
13		0		
12		1		
11		0	7	
10		1		
9		1		
8		1		
7		1	Е	
6	P2_CT_GAIN	1		Path 2 coarse tuning calibration gain
5		1		
4		0		
3	P2_KV_GAIN	0	4	Path 2 VCO tuning gain calibration gain
2		1	1	
1		0]	
0		0	1	

PLL2x5 (15h) - More Calibration Settings

#	Bit Name	Def	ault	Function
15	P2_N_PHS_ADJ	0	0	Path 2 synthesizer phase adjustment
14		0		
13		0		
12		0	1	
11		0	0	
10		0		
9		0		
8		0		
7		0	1	
6		0		
5		0		
4	P2_CT_V	1		Path 2 course tuning voltage setting when performing course tuning calibration. Default
3		0	0	value is 16. Change to 12 when using VCO1 for frequencies above 2.2 GHz.
2		0		
1	1	0		
0		0		



GPO (18h) - Internal Control Output Settings

#	Bit Name	Def	ault	Function
15		0	0	
14	P1_GP01	0		Setting of GPO1 when path 1 is active, used internally only
13		0		
12	P1_GP03	0		Setting of GPO3 when path 1 is active, used internally only
11	P1_GP04	0	0	Setting of GPO4 when path 1 is active, used internally only
10		0		
9		0		
8		0		
7		0	0	
6	P2_GP01	0		Setting of GPO1 when path 2 is active, used internally only
5		0		
4	P2_GP03	0		Setting of GPO3 when path 2 is active, used internally only
3	P2_GP04	0	0	Setting of GPO4 when path 2 is active, used internally only
2		0		
1		0		
0		0		

CHIPREV (19h) - Chip Revision Information

#	Bit Name	Def	ault	Function
15	PARTNO	0	0	RFMD Part number for device
14		0		
13		0		
12		0		
11		0	0	
10		0		
9		0		
8		0		
7	REVNO	Х	Х	Part revision number
6		X		
5		Х		
4		Х		
3		X	X	
2		X		
1		X		
0		X		



RB1 (1Ch) - PLL Lock and Calibration Results Read-back

#	Bit Name	Def	ault	Function
15	LOCK	Х	Х	PLL lock detector, 0=PLL locked, 1=PLL unlocked
14	CT_CAL	Х		CT setting (either result of course tune calibration, or CT_DEF, depending on state of CT_EN).
13		Х		Also depends on the MODE of the device
12		Х		
11		Х	Х	
10		Χ		
9		Х		
8		Х		
7	CP_CAL	X	X	CP setting (either result of KV cal, or CP_DEF, depending on state of KV_EN).
6		Χ		Also depends on the MODE of the device
5		X		
4		Х		
3		Χ	X	
2		X		
1		0		
0		0		

RB2 (1Dh) - Calibration Results Read-Back

#	Bit Name	Def	ault	Function
15	VO_CAL	Х	Х	The VCO voltage measured at the start of a VCO gain calibration
14		Х		
13		X		
12		Х		
11		Х	Х	
10		Х		
9		Х		
8		Х		
7	V1_CAL	Х	Х	The VCO voltage measured at the end of a VCO gain calibration
6		X		
5		Χ		
4		X		
3		X	Х	
2		X		
1		X	1	
0		Χ		



RB3 (1Eh) - PLL state Read-Back

#	Bit Name	Def	ault	Function
15	RSM_STATE	Х	X	State of the radio state machine
14		X		
13		X		
12		X		
11		Х	Х	
10		Х		
9		0		
8		0		
7		0	0	
6		0		
5		0		
4		0		
3		0	0	
2		0		
1		0		
0		0		

TEST (1Fh) - Test Modes


#	Bit Name	De	fault	Function
15	TEN	0	0	Enables test mode
14	TMUX	0		Sets test multiplexer state
13		0		
12	=	0		
11	CPU	0	0	Set charge pump to pump up, 0=normal operation 1=pump down
10	CPD	0		Set charge pump to pump down, 0=normal operation 1=pump down
9	FNZ	0		0=normal operation, 1=fractional divider modulator disabled
8	LDO_BYP	0		On chip low drop out regulator bypassed
7	TSEL	0	0	
6		0		
5		0		
4	DACTEST	0		DAC test
3		0	0	
2		0	1	
1		0	1	
0		0		



Evaluation Board

The following diagrams show the schematic and PCB layout of the RF2052 evaluation board. The standard evaluation board has been configured for wideband operation. Application notes have been produced showing how the device is matched and on balun implementations for narrowband applications. The evaluation board is provided as part of a design kit (DK2052), along with the necessary cables and programming software tool to enable full evaluation of the RF2052.


Evaluation Board Schematic








Evaluation Board Layout Board Size 2.5" x 2.5"

Board Thickness 0.040", Board Material FR-4

















Package Drawing QFN, 32-Pin, 5mmx5mm



Support and Applications Information

Application notes and support material can be downloaded from the product web page: www.rfmd.com/rf205x.

Ordering Information

Part Number	Package	Quantity
RF2052	32-Pin QFN	25pcs sample bag
RF2052SB	32-Pin QFN	5pcs sample bag
RF2052SR	32-Pin QFN	100pcs reel
RF2052TR7	32-Pin QFN	750pcs reel
RF2052TR13	32-Pin QFN	2500pcs reel
DK2052	Complete Design Kit	1 box

