rfmd.com

## **RF2056**

## HIGH PERFORMANCE VHF/UHF PLL AND VCO WITH INTEGRATED MIXERS

Package: QFN, 32-Pin, 5mmx5mm






#### **Features**

- Fractional-N Synthesizer
- Very Fine Frequency Resolution 1.5 Hz for 26 MHz Reference
- LO Frequency Range Between 50MHz and 500MHz
- Low Phase Noise VCO
- VCO Range 200MHz to 500MHz Dependent on External Inductor
- Integrated LO Buffers and LO Dividers
- On-Chip Crystal-Sustaining Circuit With Programmable Loading Capacitors
- Two High-Linearity RF Mixers
- Mixer Frequency Range 30MHz to 500MHz
- Mixer Input IP3 +25dBm
- Mixer Bias Adjustable for Low Power Operation
- 2.7 V to 3.6 V Power Supply
- Low Current Consumption 45 mA to 65 mA at 3 V
- 3-Wire Serial Interface

#### **Applications**

- VHF/UHF Radios
- Super-Heterodyne Radios
- Diversity Receivers
- Wireless Telemetry
- PMR
- Marine Radios



**Functional Block Diagram** 

#### **Product Description**


The RF2056 is a low power, high performance, VHF/UHF frequency conversion chip with integrated local oscillator (LO) generation and a pair of mixers. The synthesizer includes an integrated fractional-N phase locked loop that can control the VCO to produce a low phase noise and low spurious LO signal with very fine frequency resolution. The VCO output can then be divided by one, two, or four in the LO divider, the output of which drives the mixer, which converts the signal into the required frequency band. The mixer bias current can be programmed dependent on the required performance and available supply current. The LO generation block has been designed to operate with the VCO covering the frequency range from 200 MHz to 500 MHz, dependant on the value of the external inductor used. With the LO dividers, the LO range achievable is within the range of 50 MHz to 500 MHz. The mixer is broadband and can operate from 30 MHz to 500 MHz at the input and output, enabling both up and down conversion. An external crystal of between 10 MHz and 26 MHz, or an external reference source of between 10 MHz and 104 MHz, can be used with the RF2056 to accommodate a variety of reference frequency options.

All on-chip registers are controlled through a simple three-wire serial interface. The RF2056 is designed for 2.7V to 3.6V operation. It is available in a plastic 32-pin, 5mmx5mm QFN package.


0	ptimum Technolog	gy Matching® App	lied
☐ GaAs HBT ☐ GaAs MESFET ☐ InGaP HBT	☐ SiGe BiCMOS ☐ Si BiCMOS ☐ SiGe HBT	☐ GaAs pHEMT ☑ Si CMOS ☐ Si BJT	☐ GaN HEMT ☐ RF MEMS



### **Detailed Functional Block Diagram**



#### **Pin Out**





Pin	Function	Description		
1	ENBL	Ensure that the ENBL high voltage level is not greater than V <sub>DD</sub> . An RC low-pass filter could be used to reduce digital noise.		
2	INDP	VCO 3 differential inductor. Connect to ground for DC bias. Requires 2K2 damping resistor between pins 2 and 3.		
3	INDN	VCO 3 differential inductor. Connect to ground for DC bias. Requires 2K2 damping resistor between pins 2 and 3.		
4	REXT	External bandgap bias resistor. Connect a $51$ k $\Omega$ resistor from this pin to ground to set the bandgap reference bias current. This could be a sensitive low frequency noise injection point.		
5	ANA_DEC	Analog supply decoupling capacitor. Connect to analog supply and decouple as close to the pin as possible.		
6	LFILT1	Phase detector output. Low-frequency noise-sensitive node.		
7	LFILT2	Loop filter op-amp output. Low-frequency noise-sensitive node.		
8	LFILT3	VCO control input. Low-frequency noise-sensitive node.		
9	MODE	Mode select pin. An RC low-pass filter can be used to reduce digital noise.		
10	XTALIPP	Reference crystal / reference oscillator input. Should be AC-coupled if an external reference is used. See note 3.		
11	XTALIPN	Reference crystal / reference oscillator input. Should be AC-coupled to ground if an external reference is used. See note 3.		
12	GND	Connect to ground.		
13	RFIP1P	Differential input 1. See note 1.		
14	RFIP1N	Differential input 1. See note 1.		
15	NC			
16	NC			
17	RFOP1N	Differential output 1. See note 2.		
18	RFOP1P	Differential output 1. See note 2.		
19	DIG_VDD	Digital supply. Should be decoupled as close to the pin as possible.		
20	NC			
21	NC			
22	ANA_VDD	Analog supply. Should be decoupled as close to the pin as possible.		
23	RFIP2N	Differential input 2. See note 1.		
24	RFIP2P	Differential input 2. See note 1.		
25	NC			
26	NC			
27	RFOP2N	Differential output 2. See note 2.		
28	RFOP2P	Differential output 2. See note 2.		
29	RESETB	Chip reset (active low). Connect to DIG_VDD if external reset is not required.		
30	ENX	Serial interface select (active low). An RC low-pass filter could be used to reduce digital noise.		
31	SCLK	Serial interface clock. An RC low-pass filter could be used to reduce digital noise.		
32	SDATA	Serial interface data. An RC low-pass filter could be used to reduce digital noise.		
EP	Exposed pad	Connect to ground. This is the ground reference for the circuit. All decoupling should be connected here through low impedance paths.		

Note 1: The signal should be connected to this pin such that DC current cannot flow into or out of the chip, either by using AC coupling capacitors or by use of a transformer (see evaluation board schematic).

Note 2: DC current needs to flow from ANA\_VDD into this pin, either through an RF inductor, or transformer (see evaluation board schematic).

Note 3: Alternatively an external reference can be AC-coupled to pin 11 XTALIPN, and pin 10 XTALIPP decoupled to ground. This may make PCB routing simpler.



#### **Absolute Maximum Ratings**

Parameter	Rating	Unit
Supply Voltage (V <sub>DD</sub> )	-0.5 to +3.6	V
Input Voltage (V <sub>IN</sub> ), any Pin	-0.3 to V <sub>DD</sub> +0.3	V
RF/IF Mixer Input Power	+15	dBm
Operating Temperature Range	-40 to +85	°C
Storage Temperature Range	-40 to +150	°C



#### Caution! ESD sensitive device.

Exceeding any one or a combination of the Absolute Maximum Rating conditions may cause permanent damage to the device. Extended application of Absolute Maximum Rating conditions to the device may reduce device reliability. Specified typical performance or functional operation of the device under Absolute Maximum Rating conditions is not implied.

RoHS status based on EUDirective 2002/95/EC (at time of this document revision).

The information in this publication is believed to be accurate and reliable. However, no responsibility is assumed by RF Micro Devices, Inc. ("RFMD") for its use, nor for any infringement of patents, or other rights of third parties, resulting from its use. No license is granted by implication or otherwise under any patent or patent rights of RFMD. RFMD reserves the right to change component circuitry, recommended application circuitry and specifications at any time without prior notice.

Davamatav	Specification		Unit	Condition	
Parameter	Min.	Тур.	Max.	Unit	Condition
ESD Requirements				_	
Human Body Model					
General	2000			V	
RF Pins	1000			V	
Machine Model					
General	200			V	
RF Pins	100			V	
Operating Conditions					
Supply Voltage (V <sub>DD</sub> )	2.7	3.0	3.6	V	
Temperature (T <sub>OP</sub> )	-40		+85	°C	
Logic Inputs/Outputs					V <sub>DD</sub> =Supply to DIG_VDD pin
Input Low Voltage	-0.3		+0.5	V	
Input High Voltage	1.5		$V_{DD}$	V	
Input Low Current	-10		+10	uA	Input=0V
Input High Current	-10		+10	uA	Input=V <sub>DD</sub>
Output Low Voltage	0		0.2 * V <sub>DD</sub>	V	
Output High Voltage	0.8*V <sub>DD</sub>		V <sub>DD</sub>	V	
Load Resistance	10			kΩ	
Load Capacitance			20	pF	
Static					
Programmable Supply Current (I <sub>DD</sub> )					
Low Current Setting		45		mA	
High Linearity Setting		65		mA	
Standby		3		mA	Reference oscillator and bandgap only.
Power Down Current		140		μΑ	ENBL=0 and REF_STBY=0
Mixer					Mixer output driving 4:1 balun.
Gain		-2		dB	Not including balun losses.
Noise Figure					
Low Current Setting		10.0		dB	
High Linearity Setting		12.5		dB	








Parameter		Specification	ution Unit		Condition
Farameter	Min.	Тур.	Max.	Unit	Condition
Mixer, cont.					
IIP <sub>3</sub>					
Low Current Setting		+10		dBm	
High Linearity Setting		+25		dBm	
Pin1dB					
Low Current Setting		+2		dBm	
High Linearity Setting		+12		dBm	
RF and IF Port Frequency Range	30		500	MHz	
Mixer Input Return Loss		10		dB	100 $\Omega$ differential
Voltage Controlled Oscillator					
VCO Frequency Range					Dependant on differential inductor.
Inductor Value 16nH (*2)	400		500	MHz	
Inductor Value 24nH (*2)	320		400	MHz	
Inductor Value 33nH (*2)	280		320	MHz	
Inductor Value 47 nH (*2)	240		280	MHz	
Inductor Value 68nH (*2)	200		240	MHz	
Open Loop Phase-Noise at 1MHz Offset					
500MHz LO Frequency		-139		dBc/Hz	LO divider=1, 16nH (*2) VCO Inductor
200 MHz LO Frequency		-144		dBc/Hz	LO divider=1, 68nH (*2) VCO Inductor
Reference Oscillator					
Xtal Frequency	10		26	MHz	
External Reference Frequency	10		104	MHz	
Reference Divider Ratio	1		7		
External Reference Input Level	500	800	1500	mV <sub>P-P</sub>	AC-coupled
Local Oscillator					
Synthesizer Output Frequency	50		500	MHz	At LO divider output, dependant on VCO differential inductor used.
Phase Detector Frequency			52	MHz	
Closed Loop Phase-Noise at 10 kHz Offset					26MHz phase detector frequency and 16nH (*2) VCO inductor.
400MHz LO Frequency		-100		dBc/Hz	LO divider=1
200MHz LO Frequency		-107		dBc/Hz	LO divider=2
100MHz LO Frequency		-113		dBc/Hz	LO divider=4
			-		





Typical Performance Characteristics: Synthesizer and VCO -  $V_{DD}$ =3V,  $T_A$ =+23°C, as measured on RF2056 evaluation board. Note: VCO external inductor and reference frequency as described on each plot.





















Typical Performance Characteristics: Synthesizer and VCO -  $V_{DD}$ =3V,  $T_A$ =+23°C, as measured on RF2056 evaluation board. Note: VCO external inductor and reference frequency as described on each plot.
















Typical Performance Characteristics: VCO -  $V_{DD}$  = 3V,  $T_A$  = +23 °C unless stated, as measured on RF2056 evaluation board.






Typical Performance Characteristics: RF Mixers -  $V_{DD}$  = 3V,  $T_A$  = +23 °C unless stated, as measured on RF2056 evaluation board.


Mixer 1 Conversion Gain Down Conversion to 30MHz IF Output +23 Deg C, +3.3V +23 Deg C, +3.3V +23 Deg C, +3.6V -1 -40 Deg C, +3.3V -40 Deg C, +3.3V -40 Deg C, +3.6V -2 +85 Deg C, +3.0\ -3 Conversion Gain <sub>-4</sub> (dB) -5 -6 -8 410 430 470 450 490 530 550 RF Input Frequency (MHz)






Typical Performance Characteristics: RF Mixers - V<sub>DD</sub>=3V, T<sub>A</sub>=+23°C unless stated, as measured on RF2056 evaluation board.











Mixer 2 Noise Figure

Up Conversion from 30MHz IF Input













Typical Performance Characteristics: RF Mixers -  $V_{DD}$  = 3V,  $T_A$  = +23 °C unless stated, as measured on RF2056 evaluation board.


Mixer 1 Input Power for 1dB Compression




Mixer 2 Input Power for 1dB Compression Up Conversion from 30MHz IF to 450MHz RF Output




LO Leakage in dBm at Mixer Output




Isolation Between Mixers in Full Duplex Mode 30MHz IF



Mixer Linearity versus RF Frequency 30MHz IF, MIX\_IDD = 101, +3.3V and +23°C



Operating Current versus Temperature and Supply Voltage, One Mixer Active





#### **Detailed Description**

The RF2056 is a VHF/UHF frequency converter chip that includes a fractional-N phase locked loop, a crystal oscillator circuit, a low noise VCO core, an LO signal multiplexer, two LO buffer circuits, and two RF mixers. Synthesizer programming, device configuration, and control are achieved through a mixture of hardware and software controls. All on-chip registers are programmed through a simple three-wire serial interface.

#### **VCO**

The VCO core in the RF2056 consists of one VCO which covers a frequency range between 200MHz and 500MHz, dependant on the value of the external inductor used. In conjunction with the integrated 2/4 divider frequencies down to 50MHz can be generated. The following table gives examples of the LO frequency ranges possible versus the inductor value fitted. Note that the VCO inductor is differential so the value given is the inductance on each device pin, and the total differential inductance will be twice this value.

Inductor Value	LO Div=1	LO Div=2	LO Div=4
16nH	400MHz to 500MHz	200MHz to 250MHz	100 MHz to 125 MHz
24 nH	320MHz to 400MHz	160MHz to 200MHz	80MHz to 100MHz
33nH	280MHz to 320MHz	140MHz to 160MHz	70MHz to 80MHz
47 nH	240MHz to 280MHz	120MHz to 140MHz	60MHz to 70MHz
68nH	200 MHz to 240 MHz	100MHz to 120MHz	50MHz to 60MHz

VCO3 must be selected using the PLL1x0:P1\_VCOSEL and PLL2x0:P2\_VCOSEL control word and setting 10 for VCO3. The VCO has 128 overlapping bands to achieve an acceptable VCO gain (MHz/V) and hence a good phase noise performance across the whole tuning range. The chip automatically selects the correct VCO band (VCO coarse tuning) to generate the desired frequency based on the values programmed into the PLL1 and PLL2 register banks. For information on how to program the desired LO frequency into the PLL1 and PLL2 banks, refer to the next section. The automatic VCO band selection is triggered every time the ENBL pin is taken high. Once the band has been selected, the PLL will lock onto the correct frequency. During the band selection process, fixed capacitance elements are progressively connected to the VCO resonant circuit until the VCO is oscillating at approximately the correct frequency. The output of this band selection is made available in the RB1:CT\_CAL read-back register. A value of 127 or 0 in this register indicates that the selection was unsuccessful; this is usually due to the wrong VCO being selected so the user is trying to program a frequency that is outside of the VCO operating range. A value between one and 126 indicates a successful calibration, the actual value being dependent on the desired frequency, as well as process variation. The band selection takes approximately 1500 cycles of the phase detector clock (about 50 us with a 26MHz clock). The band select process will center the VCO tuning voltage at about 1.2V, compensating for manufacturing tolerances and process variation, as well as environmental factors, including temperature. For applications where the synthesizer is always on and the LO frequency is fixed, the synthesizer will maintain lock over a ±60°C temperature range. However, it is recommended to re-initiate an automatic band selection for every 30 degrees of temperature change in order to maintain optimal synthesizer performance. This assumes an active loop filter. If start-up time is a critical parameter and the user is always programming the same frequency for the PLL, the calibration result may be read back from the RB1:CT\_CAL register and written to PLL1x2:P1\_CT\_DEF or PLL2x2:P2\_CT\_DEF registers (depending on the desired PLL register bank). The calibration function must then be disabled by setting the PLL1x0:P1\_CT\_EN and/or PLL2x0:P2\_CT\_EN control words to 0. For further information, please refer to the RF205x Calibration User Guide.


For the RF2056, the values of the N divider used in the PLL are typically below 28. In order for the VCO band selection to be successful, it is necessary to set CFG3:FLL\_FACT=00.

The LO divide ratio is set by the PLL1x0:P1\_LODIV and PLL2x0:P2\_LODIV control words. The LO is routed to mixer1, mixer2, or both, depending on the state of the MODE pin and the value of CFG1:FULLD.



#### **VCO External Inductor Selection**

The RF2056 VCO resonator circuit can be simplified to the schematic shown below:



C1	Variable (coarse tune) capacitance plus varactor and stray capacitance.
L1 and L2	Bondwire inductance of 0.5 nH on each pin.
L3 and L4	External inductors that form a differential inductor and provide a DC ground path to bias VCO.
R1	VCO damping resistor of 2.2 K $\Omega$ .
L5	Inductance of ground via (not part of differential inductor).

The following equation can be used to calculate the VCO frequency range:

$$Fo = \frac{1}{2\pi\sqrt{LC}}$$

where C is the total differential capacitance C1, 2.5 pF to 5.5 pF, and L is the total differential inductance:

For L3 and L4 of 16 nH, this equation gives VCO frequency range of about 373 MHz to 554 MHz.

Some margin must be left at the top and bottom of the VCO frequency range to allow for process, assembly and environmental variations. A CT\_CAL margin of 25 bits is recommended at both the top and bottom, about 0.6 pF of capacitance.

The VCO resonator will have the highest Q and lowest phase noise at the lower end of the coarse tuning curve. For applications where the LO frequency is fixed, or only for tunes over a few MHz, it is recommended to design for CT\_CAL of about 40 using  $C1=4.7 \, pF$ .



The VCO damping resistor has two purposes: it limits the voltage swing on the VCO output and it improves the temperature stability of the VCO. It does not affect the resonator Q significantly, since this is dominated by the capacitance. This resistor becomes more important as the VCO frequency is reduced.

#### **Fractional-N PLL**

The RF2056 contains a charge-pump based fractional-N phase locked loop (PLL) for controlling the VCO. The PLL includes automatic calibration systems to counteract the effects of process and environmental variations, ensuring repeatable lock time and noise performance. The PLL is intended to use a reference frequency signal of 10MHz to 104MHz. A reference divider (divide by 1 to divide by 7) is supplied and should be programmed to limit the frequency at the phase detector to less than the minimum required VCO frequency divided by 15. The phase detector can operate up to 52MHz, but in practice with the RF2056, the minimum possible N divider value of 15 is the limiting factor. The reference divider bypass is controlled by bit CLK DIV\_BYP, set low to enable the reference divider and set high for divider bypass (divide by 1). The remaining three bits CLK DIV <15:13> set the reference divider value, divide by 2 (010) to 7 (111) when the reference divider is enabled.

Two PLL programming banks are provided, the first bank is preceded by the label PLL1, and the second bank is preceded by the label PLL2. For the RF2056, these banks are used to program mixer 1 and mixer 2 respectively, and are selected automatically as the mixer is selected (using the MODE pin).

The PLL will lock the VCO to the frequency F<sub>VCO</sub> according to:

$$F_{VCO} = N_{EFF} * F_{OSC} / R$$

where  $N_{EFF}$  is the programmed fractional-N divider value,  $F_{OSC}$  is the reference input frequency, and R is the programmed R divider value (1 to 7).

The N divider is a fractional divider, containing a dual-modulus prescaler and a digitally spur-compensated fractional sequence generator to allow fine frequency steps. The N divider is programmed using the N and NUM bits as follows:

First determine the desired, effective N divider value, N<sub>EFE</sub>:

$$N_{EFF} = F_{VCO} * R / F_{OSC}$$

N(9:0) should be set to the integer part of  $N_{EFF}$  NUM should be set to the fractional part of  $N_{EFF}$  multiplied by  $2^{24}$  = 16777216.

Example: VCO3 operating at 410MHz, 26MHz reference frequency, the desired effective divider value is:

$$N_{EFF} = F_{VCO} *R / F_{OSC} = 410 *1 / 26 = 15.769230769231.$$

The N value is set to 15, equal to the integer part of N<sub>EFF</sub>, and the NUM value is set to the fractional portion of N<sub>EFF</sub> multiplied by  $2^{24}$ :

NUM=0.769230769231 \*  $2^{24}$ =12905551.

Converting N and NUM into binary results in the following:

N=0000 0111 1 NUM=1100 0100 1110 1100 0100 1111

So the registers would be programmed:

P1\_N (or P2\_N)=0000 0111 1 P1\_NUM\_MSB (or P2\_NUM\_MSB)=1100 0100 1110 1100 P1\_NUM\_LSB (or P2\_NUM\_LSB)=0100 1111



The maximum  $N_{EFF}$  is 511, and the minimum  $N_{EFF}$  is 15, when in fractional mode. To get best phase noise from the PLL, it is best to run with the highest possible phase detector frequency, and minimum N. This is limited by the minimum  $N_{EFF}$  of 15. The table below gives recommended phase detector frequencies to use for different VCO frequency ranges. It also shows the minimum step size,  $F_{OSC}/R*2^{24}$ .

Phase Detector Frequency	26 MHz	20MHz	19.2 MHz	13MHz (26MHz/2)
VCO Frequency Range	390MHz to 500MHz	300 MHz to 400 MHz	290MHz to 390MHz	200MHz to 290MHz
N Divider Range	15.00 to 19.23	15.00 to 20.00	15.10 to 20.31	15.38 to 22.31
Step Size	1.55Hz	1.19Hz	1.14 Hz	0.78Hz

#### **Phase Detector and Charge Pump**

The chip provides a current output to drive an external loop filter. An on-chip operational amplifier can be used to design an active loop filter or a passive design can be implemented. The maximum charge pump output current is set by the value contained in the P1\_CP\_DEF/P2\_CP\_DEF field and CP\_LO\_I.

In the default state (P1\_CP\_DEF/P2\_CP\_DEF=31 and CP\_LO\_I=0) the charge pump current (ICPset) is 120uA. If CP\_LO\_I is set to 1 this current is reduced to 30uA.

The charge pump current can be altered by changing the value of P1\_CP\_DEF/P2\_CP\_DEF. The charge pump current is defined as:


If automatic loop bandwidth correction is enabled the charge pump current is set by the calibration algorithm based upon the VCO gain. For more information on the VCO gain calibration, which is disabled by default, please refer to the RF205x Calibration User Guide.

The phase detector will operate with a maximum input frequency of 52MHz, but for the RF2056, this is unlikely to be above 26MHz due to the minimum N of 15. For the RF2056, N<28 the FLL\_FACT register needs to be changed to 00 from the default value of 01. This is to ensure correct VCO band selection.

#### **Loop Filter**

The PLL may be designed to use an active or a passive loop filter as required. The internal configuration of the chip is shown below. If the CFG1:LF\_ACT bit is asserted high, the op-amp will be enabled. If the CFG1:LF\_ACT bit is asserted low, the internal op-amp is disabled and a high impedance is presented to the LFILT1 pin. The RF205x Programming Tool software can assist with loop filter designs. Because the op-amp is used in an inverting configuration in active mode, when the passive loop filter mode is selected the phase-detector polarity should be inverted. For active mode, CFG1:PDP=1, for passive mode, CFG1:PDP=0.





The charge pump output voltage compliance range is typically +0.7 V to +1.5 V. For applications using a passive loop filter VCO coarse tuning must be performed regularly enough to ensure that the VCO tuning voltage falls within this compliance range at all temperatures. The active loop filter maintains the charge pump output voltage in the center of the compliance range, and the op-amp provides a wider VCO tuning voltage range, typical 0V to +2.4V.

#### **Crystal Oscillator**

The PLL may be used with an external reference source, or its own crystal oscillator. If an external source (such as a TCXO) is being used it should be AC-coupled into one of the XO inputs, and the other input should be AC-coupled to ground.

A crystal oscillator typically takes many milliseconds to settle, and so for applications requiring rapid pulsed operation of the PLL (such as a TDMA system, or Rx/Tx half-duplex system) it is necessary to keep the XO running between bursts. However, when the PLL is used less frequently, it is desirable to turn off the XO to minimize current draw. The REFSTBY register is provided to allow for either mode of operation. If REFSTBY is programmed high, the XO will continue to run even when ENBL is asserted low. Thus the XO will be stable and a clock is immediately available when ENBL is asserted high, allowing the chip to assume normal operation. On cold start, or if REFSTBY is programmed low, the XO will need a warm-up period before it can provide a stable clock. The length of this warm-up period will be dependant on the crystal characteristics.

The crystal oscillator circuit contains internal loading capacitors. No external loading capacitors are required, dependant on the crystal loading specification. The internal loading capacitors are a combination of fixed capacitance, and an array of switched capacitors. The switched capacitors can be used to tune the crystal oscillator onto the required center frequency and minimize frequency error. The PCB stray capacitance and oscillator input and output capacitance will also contribute to the crystal's total load capacitance. The register settings in the CFG4 register for the switched capacitors are as follows:

- Coarse Tune XO\_CT (4 bits) 15 \* 0.55 pF, default 0100
- Fine Step XO\_CR\_S (1 bit) 1\*0.25 pF, default 0

The on chip fixed capacitance is approximately 4.2 pF.

#### **Wideband Mixer**

The RF2056 includes two wideband, double-balanced Gilbert cell mixers. They support RF/IF frequencies of 30MHz to 500MHz using the internal VCO to provide the LO frequency of 50MHz to 500MHz. Each mixer has an input port and an output port that can be used for either IF or RF, i.e. for up conversion or down conversion. The mixer current can be programmed to between 5mA and 25mA in 5mA steps depending on linearity requirements, using the MIX1\_IDD<3:0> word for mixer 1 and the MIX2\_IDD<3:0> word for mixer 2, both of which are in the CFG2 register. The majority of the mixer current is sourced through the output pins via either a centre-tapped balun or an RF choke in the external matching circuitry to the supply.

The RF mixer input and output ports are differential and require simple matching circuits optimized to the specific application frequencies. A conversion gain of approximately -3dB to 0dB is achieved with  $100\Omega$  differential input impedance, and the outputs driving  $200\Omega$  differential load impedance. Increasing the mixer output load increases the conversion gain.



The mixer has a broadband common gate input. The input impedance is dominated by the resistance set by the mixer 1/gm term, which is inversely proportional to the mixer current setting. The resistance will be approximately  $85\Omega$  at the default mixer current setting (100). There is also some shunt capacitance at the mixer input.

The mixer output is high impedance, consisting of a resistance of approximately  $2k\Omega$  in parallel with some capacitance. The mixer output does not need to be matched as such, just to see a resistive load. A higher resistance load will give higher output voltage and gain. A shunt inductor can be used to resonate with the mixer output capacitance at the frequency of interest. This inductor may not be required at lower frequencies where the impedance of the output capacitance is less significant.

For more information about the mixer port impedances and matching, please refer to the RF205x Family Application Note on Matching Circuits and Baluns.

The mixer layout and pin placement has been optimized for high mixer-to-mixer isolation of over 60dB. The mixers can be set up to operate in half-duplex mode (1 mixer active) or full duplex mode (both mixers active). The mode selection is done via hardware control of the MODE pin and by setting the FULLD bit in the CFG1 register as shown in the table below. When in full-duplex mode, one can either use PLL register bank 1 or 2, the LO signal is routed to both mixers.


Mode Pin	FULLD Bit	Active PLL Register Bank	Active Mixer
Low	0	1	1
High	0	2	2
Low	1	1	Both
High	1	2	Both




### **General Programming Information**

#### **Serial Interface**

All on-chip registers in the RF2056 are programmed using a 3-wire serial bus which supports both write and read operations. Synthesizer programming, device configuration and control are achieved through a mixture of hardware and software controls. Certain functions and operations require the use of hardware controls via the ENBL, MODE, and RESETB pins in addition to programming via the serial bus.




#### **Serial Data Timing Characteristics**



Parameter	Description	Time
t1	Reset delay	>5ns
t2	Programming setup time	>5ns
t3	Programming hold time	>5ns
t4	ENX setup time	>5 ns
t5	ENX hold time	>5ns
t6	Data setup time	>5ns
t7	Data hold time	>5ns
t8	ENBL setup time	>0 ns
t9	ENBL hold time	>0ns



#### Write



Initially ENX is high and SDATA is high impedance. The write operation begins with the controller starting SCLK. On the first falling edge of SCLK the baseband asserts ENX low. The second rising edge of SCLK is reserved to allow the SDI to initialize, and the third rising edge is used to define whether the operation will be a write or a read operation. In write mode the baseband will drive SDATA for the entire telegram. RF2056 will read the data bit on the rising edge of SCLK.


The next 7 data bits are the register address, MSB first. This is followed by the payload of 16 data bits for a total write mode transfer of 24 bits. Data is latched into RF2056 on the last rising edge of SCLK (after ENX is asserted high).

For more information, please refer to the timing diagram on page 17.

The maximum clock speed for a register write is 19.2 MHz. A register write therefore takes approximately 1.3 us. The data is latched on the rising edge of the clock. The datagram consists of a single start bit followed by a '0' (to indicate a write operation). This is then followed by a seven bit address and a sixteen bit data word.

Note that since the serial bus does not require the presence of the crystal clock, it is necessary to insert an additional rising clock edge before the ENX line is set low to ensure the address/data are read correctly.

#### Read



Initially ENX is high and SDATA is high impedance. The read operation begins with the controller starting SCLK. The controller is in control of the SDATA line during the address write operation. On the first falling edge of SCLK the baseband asserts ENX low. The second rising edge of SCLK is reserved to allow the SDI to initialize, and the third rising edge is used to define whether the operation will be a write or a read operation. In read mode the baseband will drive SDATA for the address portion of the telegram, and then control will be handed over to RF2056 for the data portion. RF2056 will read the data bits of the address on the rising edge of SCLK. After the address has been written, control of the SDATA line is handed over to RF2056. One and a half clocks are reserved for turn-around, and then the data bits are presented by RF2056. The data is set up on the rising edge of SCLK, and the controller latches the data on the falling edge of SCLK. At the end of the data transmission, RF2056 will release control of the SDATA line, and the controller asserts ENX high. The SDATA port on RF2056 transitions from high impedance to low impedance on the first rising edge of the data portion of the transaction (for example, 3 rising edges after the last address bit has been read), so the controller chip should be presenting a high impedance by that time.

For more information, please refer to the timing diagram on page 17.

The maximum clock speed for a register read is 19.2 MHz. A register read therefore takes approximately 1.4 us. The address is latched on the rising edge of the clock and the data output on the falling edge. The datagram consists of a single start bit fol-



lowed by a '1' (to indicate a read operation), followed by a seven bit address. A 1.5 bit delay is introduced before the sixteen bit data word representing the register content is presented to the receiver.

Note that since the serial bus does not require the presence of the crystal clock, it is necessary to insert an additional rising clock edge before the ENX line is set low to ensure the address is read correctly.

#### **Hardware Control**


Three hardware control pins are provided: ENBL, MODE, and RESETB.

#### **ENBL Pin**

The ENBL pin has two functions: to enable the analog circuits in the chip and to trigger the VCO band selection as described in the VCO section on page 11.

ENBL Pin	REFSTBY Bit	XO and Bias Block	Analogue Block	Digital Block
Low	0	Off	Off	On
Low	1	On	Off	On
High	0	On	On	On
High	1	On	On	On

As outlined in the VCO section the chip has a built-in automatic VCO band selection to tune the selected VCO to the desired frequency. The band selection is initiated when the ENBL pin is taken high. Every time the frequency of the synthesizer is re-programmed, the ENBL has to be inserted high to initiate the automatic VCO band selection (VCO coarse tune).



Parameter	Description	Time
t1	MODE setup time	>5 ns
t2	MODE hold time	>5 ns

#### **RESETB Pin**

The RESETB pin is a hardware reset control that will reset all digital circuits to their start-up state when asserted low. The device includes a power-on-reset function, so this pin should not normally be required, in which case it should be connected to the positive supply.


#### **MODE Pin**

The MODE pin controls which mixer(s) and PLL programming register bank is active. See the PLL and Mixer description sections for details.



#### **Programming the RF2056**

The figure below shows an overview of the device programming.



Note: The set-up processes 1 to 2, 2 to 3, and 3 to 4 are explained further below.

Additional information on device use and programming can be found on the RF205X family page of the RFMD web site (http://www.rfmd.com/rf205x). The following documents may be particularly helpful:

- RF2056 Frequency Synthesizer User Guide
- RF205x Calibration User Guide




#### Start-up

When starting up and following device reset then REFSTBY=0, REFSTBY should be asserted high approximately  $500\,\mu s$  before ENBL is taken high. This is to allow the XO to settle and will depend on XO characteristics. The various calibration routines will also take some time depending on whether they are enabled or not. Coarse tuning calibration takes about  $50\,\mu s$  and VCO tuning gain compensation takes about  $100\,\mu s$ . Additionally, time for the PLL to settle will be required. All of these timings will be dependant upon application specific factors such as loop filter bandwidth, reference clock frequency, XO characteristics and so on. The fastest turn-on and lock time will be obtained by leaving REFSTBY asserted high, disabling all calibration routines, minimizing all calibration times, and setting the PLL loop bandwidth as wide as possible.

The device can be reset into its initial state (default settings) at any time by performing a hard reset. This is achieved by setting the RESETB pin low for at least 100 ns.

#### **Setting Up Device Operation**

The device offers a number of operating modes which need to be set up in the device before it will work as intended. This is achieved as follows.




Three registers need to be written, taking 3.9us at the maximum clock speed. If the device is used with an active filter in simplex operation it will not be necessary to program CFG1 reducing the programming time to 2.6us.



#### Setting Up VCO Coarse Tuning and Loop Filter Calibration

If the user wishes to disable the VCO coarse tune calibration or enable the loop filter calibration then the following programming operation will need to take place.




Two registers need to be written taking 2.6 us at maximum clock speed if the course tuning is deactivated or the loop filter calibration activated. Since it is necessary to program these registers when setting the operating frequency (see next section) this operation usually carries no overhead.

The coarse tune calibration takes approximately 50 us when using a 26MHz reference clock (it will take proportionally longer if a slower clock is used, and vice versa).



#### **Setting The Operating Frequency**

Setting the operating frequency of the device requires a number of registers to be programmed.



A total of five registers must be programmed to set the device operating frequency for each path within the device. This will take 6.5 us for each path at maximum clock speed.

To change the frequency of the VCO it will be necessary to repeat these operations. However, it may not be necessary to reprogram the LODIV bits reducing the register writes to three per path.

For an example on how to determine the integer and fractional parts of the synthesizer PLL division ratio please refer to the detailed description of the PLL on page 13.



## **Programming Registers**

### **Register Map Diagram**

			1	Date														
Reg.	R/W	Add										Data					•	
Name	, ,		15	14	13			10	9	8	7	6	5	4	3	2	1	0
CFG1	R/W	00	_	LD_LEV			TVCO				LF_ACT		CPL			EXT_VCO		CP_LO_I
CFG2	R/W	01	М	IX1_IDD	-	MIX:	1_VB	MI	X2_II	DD	MIX2	_VB	Res	KV_RNG	NBR	_CT_AVG		(V_AVG
CFG3	R/W	02		TKV1				TK	V2				Res		FL	L_FACT	CT_CPOL	REFSTBY
CFG4	R/W	03	CLI	K_DIV_BY	'PASS	3		XO_	_CT		XO_I2	XO_I1	XO_CR_S			TCT		
CFG5	R/W	04		L01_I				LO	2_I			3	•	T_PH_	ALGN			
CFG6	R/W	05					SU_W									Res		
PLL1x0	R/W	08	P1_V	COSEL		CT_E N	P1_k			LODI /	Re	es			P1_	CP_DEF		
PLL1x1	R/W	09									P1_N	NUM_M	ISB					
PLL1x2	R/W	OA		ı	P1_N	IUM_I	LSB						Р	1_CT_DEF	:			Res
PLL1x3	R/W	OB					L_N				•		Re	S	_		P1_VCOI	
PLL1x4	R/W	OC				P1.	P1_DN						P1_CT_GAIN			P1_KV_GAIN		
PLL1x5	R/W	0D			P1	L_N_F	_PHS_ADJ					Res P1_CT_V			_V			
PLL2x0	R/W	10	P2_V	COSEL		CT_E N	P2_KV P2_LODI EN V			Re	es	P2_CP_DEF						
PLL2x1	R/W	11					•	•			P2_N	NUM_M	ISB					
PLL2x2	R/W	12		ı	P2_N	IUM_I	LSB						P2_CT_DEF				Res	
PLL2x3	R/W	13				P2_N						Res			P2_VCOI			
PLL2x4	R/W	14				P2_DN					P2_CT_GAIN				P2_KV_GAIN Res		Res	
PLL2x5	R/W	15			P2	2_N_F	PHS_/	\DJ				Res				P2_CT_V		
GPO	R/W	18	Res	P1_GP0 1	Res		P1_ GPO 4		I	Res		P2_GP 01	Res	P2_GP0 3	P2_ GP0 4		Res	
CHIPREV	R	19			)					REVNO								
RB1	R	1C	LOCK		CT_	_CAL					CP_CAL Res							
RB2	R	1D			CAL					V1_CAL								
RB3	R	1E		RSM	TE				Res									
TEST	R	1F	TEN	TN		CPU	CPD	FNZ	LDO _BY P	TSEL	Res	DAC	TEST			Res		



## **CFG1 (00h) - Operational Configuration Parameters**

#	Bit Name	De	fault	Function
15	LD_EN	1	9	Enable lock detector circuitry
14	LD_LEV	0		Modify lock range for lock detector
13	TVCO(4:0)	0		VCO warm-up time=(TVCO*32)/F <sub>REF</sub>
12		0		
11		0	1	
10		0		
9		0		
8	PDP	1		Phase detector polarity: 0=positive, 1=negative
7	LF_ACT	1	С	Active loop filter enable, 1=Active O=Passive
6	CPL(1:0)	1		Charge pump leakage current: 00=no leakage, 01=low leakage, 10=mid leakage, 11=high
5		0		leakage
4	CT_POL	0		Polarity of VCO coarse-tune word: 0=positive, 1=negative
3		0	0	
2	EXT_VCO	0		0=Normal operation 1=external VCO
1	FULLD	0		0=Half duplex, mixer is enabled according to MODE pin, 1=Full duplex, both mixers enabled
0	CP_LO_I	0		0=High charge pump current, 1=low charge pump current

### CFG2 (01h) - Mixer Bias and PLL Calibration

#	Bit Name	De	fault	Function
15	MIX1_IDD	1	8	Mixer 1 current setting: 000=0 mA to 101=25 mA in 5 mA steps. 110 and 111 unused.
14	]	0		
13	]	0		
12	MIX1_VB	0		Mixer 1 voltage bias.
11	]	1	С	
10	MIX2_IDD	1		Mixer 2 current setting: 000=0 mA to 101=25 mA in 5 mA steps. 110 and 111 unused.
9	]	0		
8	]	0		
7	MIX2_VB	0	5	Mixer 2 voltage bias
6	]	1		
5		0		
4	KV_RNG	1		Sets accuracy of voltage measurement during KV calibration: 0=8bits, 1=9bits
3	NBR_CT_AVG	1	8	Number of averages during CT cal
2	1	0	1	
1	NBR_KV_AVG	0	1	Number of averages during KV cal
0		0		



### CFG3 (02h) - PLL Calibration

#	Bit Name	Def	ault	Function
15	TKV1	0	0	Settling time for first measurement in LO KV compensation
14	=	0		
13		0		
12	=	0		
11	TKV2	0	4	Settling time for second measurement in LO KV compensation
10		1		
9		0		
8		0		
7		0	0	
6		0		
5		0		
4		0		
3	FLL_FACT	0	4	Default setting 01. Needs to be set to 00 for N<28. This is normally required to be set to 00
2	1	1	1	for RF2056.
1	CT_CPOL	0	]	
0	REFSTBY	0	1	Reference oscillator standby mode 0=X0 is off in standby mode, 1=X0 is on in standby mode

## CFG4 (O3h) - Crystal Oscillator and Reference Divider

#	Bit Name	Def	ault	Function
15	CLK_DIV	0	1	Reference divider, divide by 2 (010) to 7 (111) when reference divider is enabled
14		0		
13		0		
12	CLK_DIV_BYPASS	1		Reference divider enabled=0, divider bypass (divide by 1)=1
11	XO_CT	1	8	Crystal oscillator coarse tune (approximately 0.5 pF steps from 8 pF to 16 pF)
10		0		
9		0		
8		0		
7	XO_I2	0	0	Crystal oscillator current setting
6	XO_I1	0		
5	XO_CR_S	0		Crystal oscillator additional fixed capacitance (approximately 0.25 pF)
4	TCT	0		Duration of coarse tune acquisition
3		1	F	
2		1		
1		1		
0		1		



### CFG5 (04h) - LO Bias

#	Bit Name	Def	ault	Function
15	L01_I	0	0	Local oscillator Path1 current setting
14		0		
13		0		
12		0		
11	L02_I	0	0	Local oscillator Path2 current setting
10		0		
9		0		
8		0		
7	T_PH_ALGN	0	0	Phase alignment timer
6		0		
5		0		
4		0		
3		0	4	
2		1		
1		0		
0		0		

## CFG6 (05h) - Start-up Timer

#	Bit Name	Def	ault	Function
15	SU_WAIT	0	0	Crystal oscillator settling timer.
14		0		
13		0		
12		0		
11		0	1	
10		0		
9		0		
8		1		
7		0	0	
6		0		
5		0		
4		0		
3		0	0	
2		0		
1		0		
0		0		



## PLL1x0 (08h) - VCO, LO Divider and Calibration Select

#	Bit Name	Def	ault	Function
15	P1_VCOSEL	0	7	Always set to 10=VC03.
14		1		
13	P1_CT_EN	1		Path 1 VCO coarse tune: 00=disabled, 11=enabled
12		1		
11	P1_KV_EN	0	1	Path 1 VCO tuning gain calibration: 00=disabled, 11=enabled
10		0		
9	P1_LODIV	0		Path 1 local oscillator divider: 00=divide by 1, 01=divide by 2, 10=divide by 4, 11=reserved
8		1		
7		0	1	
6		0		
5	P1_CP_DEF	0		Charge pump current setting
4		1		If P1_KV_EN=11 this value sets charge pump current during KV compensation only
3		1	F	
2		1	1	
1		1	1	
0		1	1	

### PLL1x1 (09h) - MSB of Fractional Divider Ratio

#	Bit Name	Def	ault	Function
15	P1_NUM_MSB	0	6	Path 1 VCO divider numerator value, most significant 16 bits
14		1		
13		1		
12		0		
11		0	2	
10		0		
9		1		
8		0		
7		0	7	
6		1		
5		1		
4		1		
3		0	6	
2		1		
1		1		
0		0		



### PLL1x2 (0Ah) - LSB of Fractional Divider Ratio and CT Default

#	Bit Name	Def	ault	Function
15	P1_NUM_LSB	0	2	Path 1 VCO divider numerator value, least significant 8 bits
14		0		
13		1		
12		0		
11		0	7	
10		1		
9		1		
8		1		
7	P1_CT_DEF	0	7	Path 1 VCO coarse tuning value, used when P1_CT_EN=00
6		1		
5		1		
4		1		
3		1	E	
2		1		
1		1		
0		0		

### PLL1x3 (0Bh) - Integer Divider Ratio and VCO Current

#	Bit Name	Def	ault	Function
15	P1_N	0	2	Path 1 VCO divider integer value
14		0		
13		1		
12		0		
11		0	3	
10		0		
9		1		
8		1		
7		0	0	
6		0		
5		0		
4		0		
3		0	2	
2	P1_VCOI	0		Path 1 VCO bias setting: 000=minimum value, 111=maximum value
1		1		
0		0		



## PLL1x4 (0Ch) - Calibration Settings

#	Bit Name	Def	ault	Function
15	P1_DN	0	1	Path 1 frequency step size used in VCO tuning gain calibration
14		0		
13		0		
12		1		
11		0	7	
10		1		
9		1		
8		1		
7		1	Е	
6	P1_CT_GAIN	1		Path 1 coarse tuning calibration gain
5		1		
4		0		
3	P1_KV_GAIN	0	4	Path 1 VCO tuning gain calibration gain
2		1	]	
1		0	]	
0		0	1	

## PLL1x5 (0Dh) - More Calibration Settings

#	Bit Name	Def	ault	Function
15	P1_N_PHS_ADJ	0	0	Path 1 frequency step size used in VCO tuning gain calibration
14		0		
13		0		
12		0		
11		0	0	
10		0		
9		0		
8		0		
7		0	1	
6		0		
5		0		
4	P1_CT_V	1		Path 1 course tuning voltage setting when performing course tuning calibration. Default
3		0	0	value is 16.
2		0		
1		0		
0		0		



### PLL2x0 (10h) - VCO, LO Divider and Calibration Select

#	Bit Name	Def	ault	Function
15	P2_VCOSEL	0	7	Always set to 10=VC03.
14		1		
13	P2_CT_EN	1		Path 2 VCO coarse tune: 00=disabled, 11=enabled
12		1		
11	P2_KV_EN	0	1	Path 2 VCO tuning gain calibration: 00=disabled, 11=enabled
10		0		
9	P2_LODIV	0		Path 2 local oscillator divider: 00=divide by 1, 01=divide by 2, 10=divide by 4, 11=reserved
8		1		
7			1	
6				
5	P2_CP_DEF	0		Charge pump current setting.
4		1		If P2_KV_EN=11 this value sets charge pump current during KV compensation only
3		1	F	
2	1	1	1	
1		1	1	
0		1	1	

### PLL2x1 (11h) - MSB of Fractional Divider Ratio

#	Bit Name	Def	ault	Function
15	P2_NUM_MSB	0	6	Path 2 VCO divider numerator value, most significant 16 bits
14		1		
13		1		
12		0		
11		0	2	
10		0		
9		1		
8		0		
7		0	7	
6		1		
5		1		
4		1		
3		0	6	
2		1		
1		1		
0		0		



## PLL2x2 (12h) - LSB of Fractional Divider Ratio and CT Default

#	Bit Name	Def	ault	Function
15	P2_NUM_LSB	0	2	Path 2 VCO divider numerator value, least significant 8 bits.
14		0		
13		1		
12		0		
11		0	7	
10		1		
9		1		
8		1		
7	P2_CT_DEF	0	7	Path 2 VCO coarse tuning value, used when P2_CT_EN=00
6		1		
5		1		
4		1		
3		1	E	
2		1		
1		1		
0		0		

### PLL2x3 (13h) - Integer Divider Ratio and VCO Current

#	Bit Name	Def	ault	Function
15	P2_N	0	2	Path 2 VCO divider integer value
14		0		
13		1		
12		0		
11		0	3	
10		0		
9		1		
8		1		
7		0	0	
6		0		
5		0		
4		0		
3		0	2	
2	P2_VCOI	0		Path 2 VCO bias setting: 000=minimum value, 111=maximum value
1		1		
0		0		



### PLL2x4 (14h) - Calibration Settings

#	Bit Name	Def	ault	Function
15	P2_DN	0	1	Path 2 frequency step size used in VCO tuning gain calibration
14		0		
13		0		
12		1		
11		0	7	
10		1		
9		1		
8		1		
7		1	E	
6	P2_CT_GAIN	1		Path 2 coarse tuning calibration gain
5		1		
4		0		
3	P2_KV_GAIN	0	4	Path 2 VCO tuning gain calibration gain
2		1	1	
1		0	]	
0		0	1	

## PLL2x5 (15h) - More Calibration Settings

#	Bit Name	Def	ault	Function
15	P2_N_PHS_ADJ	0	0	Path 2 synthesizer phase adjustment
14		0		
13		0		
12		0		
11		0	0	
10		0		
9		0		
8		0		
7		0	1	
6		0		
5		0		
4	P2_CT_V	1		Path 2 course tuning voltage setting when performing course tuning calibration. Default
3		0	0	value is 16.
2		0		
1		0	1	
0		0		



### **GPO (18h) - Internal Control Output Settings**

#	Bit Name	De	fault	Function
15		0	0	
14	P1_GP01	0		Setting of GPO1 when path 1 is active, used internally only
13		0		
12	P1_GP03	0		Setting of GPO3 when path 1 is active, used internally only
11	P1_GP04	0	0	Setting of GPO4 when path 1 is active, used internally only
10		0		
9		0		
8		0		
7		0	0	
6	P2_GP01	0		Setting of GPO1 when path 2 is active, used internally only
5		0		
4	P2_GP03	0		Setting of GPO3 when path 2 is active, used internally only
3	P2_GP04	0	0	Setting of GPO4 when path 2 is active, used internally only
2		0		
1		0		
0		0		

## **CHIPREV (19h) - Chip Revision Information**

#	Bit Name	Def	ault	Function
15	PARTNO	0	0	RFMD Part number for device
14		0		
13		0		
12		0		
11		0	0	
10		0		
9		0		
8		0		
7	REVNO	Х	Х	Part revision number
6		X		
5		Х		
4		Х		
3		X	X	
2		Χ		
1		X		
0		Χ		



### **RB1 (1Ch) - PLL Lock and Calibration Results Read-back**

#	Bit Name	Def	ault	Function
15	LOCK	Х	Х	PLL lock detector, 0=PLL locked, 1=PLL unlocked
14	CT_CAL	Х		CT setting (either result of course tune calibration, or CT_DEF, depending on state of CT_EN).
13		Х		Also depends on the MODE of the device
12		Х		
11		Х	Х	
10		Χ		
9		Х		
8		Х		
7	CP_CAL	X	Х	CP setting (either result of KV cal, or CP_DEF, depending on state of KV_EN).
6		X		Also depends on the MODE of the device
5		X		
4		X		
3		X	Х	
2		Х		
1		0		
0		0		

## **RB2 (1Dh) - Calibration Results Read-Back**

#	Bit Name	Def	ault	Function
15	VO_CAL	Х	X	The VCO voltage measured at the start of a VCO gain calibration
14		Х		
13		Х		
12		Х		
11		Х	Х	
10		Х		
9		Х		
8		Х		
7	V1_CAL	Х	Х	The VCO voltage measured at the end of a VCO gain calibration
6		Х		
5		Х		
4		Х		
3		Х	X	
2		Х		
1		Х		
0		Χ		



### RB3 (1Eh) - PLL state Read-Back

#	Bit Name	Def	ault	Function
15	RSM_STATE	Х	Х	State of the radio state machine
14		Х		
13		Х		
12		Х		
11		Х	Х	
10		Х		
9		0		
8		0		
7		0	0	
6		0		
5		0		
4		0		
3		0	0	
2		0	1	
1		0		
0		0	1	

### **TEST (1Fh) - Test Modes**


#	Bit Name	De	fault	Function
15	TEN	0	0	Enables test mode
14	TMUX	0		Sets test multiplexer state
13		0		
12		0		
11	CPU	0	0	Set charge pump to pump up, 0=normal operation 1=pump down
10	CPD	0		Set charge pump to pump down, 0=normal operation 1=pump down
9	FNZ	0		0=normal operation, 1=fractional divider modulator disabled
8	LDO_BYP	0		On chip low drop out regulator bypassed
7	TSEL	0	0	
6		0		
5		0		
4	DACTEST	0		DAC test
3		0	0	
2		0		
1		0		
0		0		



#### **Evaluation Board**

The following diagrams show the schematic and PCB layout of the RF2056 evaluation board. The standard evaluation board has been configured for a VCO frequency range of 400 MHz to 500 MHz, and for wideband mixer operation. Application notes have been produced showing how the device is matched and on balun implementations for narrowband applications. The evaluation board is provided as part of a design kit (DK2056), along with the necessary cables and programming software tool to enable full evaluation of the RF2056.


#### **Evaluation Board Schematic**








# Evaluation Board Layout Board Size 2.5"x2.5"

Board Thickness 0.040", Board Material FR-4



















# Package Drawing QFN, 32-Pin, 5mmx5mm



### **Support and Applications Information**

Application notes and support material can be downloaded from the product web page: www.rfmd.com/rf205x.

### **Ordering Information**

Part Number	Package	Quantity	
RF2056	32-Pin QFN	25pcs sample bag	
RF2056SB	32-Pin QFN	5pcs sample bag	
RF2056SR	32-Pin QFN	100pcs reel	
RF2056TR7	32-Pin QFN	750pcs reel	
RF2056TR13	32-Pin QFN	2500pcs reel	
DK2056	Complete Design Kit Note: Set-up for 400 MHz to 500 MHz VCO range.	1 box	