

Running test on MR through Slocum science computer

1. Connect to the glider using a hardwired or FreeWave connection.
2. Ctl-C to gliderdos
3. Wait for the science side to come up.
4. consci
5. uart j6 115200 0 (may need to change j6 based on progllets.dat configuration)
6. Press return to get a command prompt on the MR
7. Wait about 60 seconds
8. Type "odas info"
9. Type "odas start"
10. Type "odas info"
11. Wait about 10 minutes
12. Type "odas info"
13. Type "odas stop"
14. Type "odas info"
15. Type "ls -la data"
16. Type "tail -50 data/logfile.txt"
17. Type a control-C to return to scidos
18. Wait 120+ seconds
19. Type "uart j6 115200 0"
20. Press return to get an MR prompt
21. Type "tail -50 data/logfile.txt"
22. Type a control-C to return to scidos
23. Type "quit" to return to gliderdos
24. Type "exit"
25. When prompted, remove the glider's green plug