

GND

GND

SW2

SW3


10_4


O TP1 ADC1_CH4

JP1 as default bridged Leave open IF Touch is used


TOUCH INT

10 FPC LCD connector





USB_D- 13 1018




USB_C_Programming

J3 ¥


ADC1_CH4 = 104 Just offered like Touch Point TP1

IMPORTANT: This PCB does not have UART Chip.
USB just connects to the IOs specified in C3-mini datasheet
for USB_D- (18) and USB_D+ (19)
TOUCH_INT IO8 needs to be pulled-high during boot to enter
download mode and be able to program the MCU

LCD pinuout:




Battery jack




DS3231 Real time clock via I2C


I2C_SCL_



Charge and power management



TO-DOs for Release 1.1



TX 3 16 RX DTR 5 0 RTS 6 O H4

UART CONNECTION

Cann_01x06_Sacket