



\_\_\_\_RTC\_INT




IMPORTANT: This QFN20 version does not have a CTR pin. I've read comments that CTS might work instead: https://www.reddit.com/r/AskElectronics/comments/ta5fbt/comment/hzz5ial/


## PCF8563T Real time clock via I2C







## Charge and power management



- H2 Not included in PCB (no space)
- 0
- 0