An Elegant Method for Incorporating the Wellbore Storage Effect in the Laplace Domain

Masaru Sawata

May 10, 2025

There is an interesting technique for incorporating the wellbore storage effect into the constant-rate analytical solution. This is one of my favorite topics in pressure transient analysis.

If we have a constant (sandface) rate solution $p_{wDc}(t_D)$ (dimensionless pressure), which may or may not include skin effect, we can derive an analytical solution for a variable-rate problem by applying the principle of superposition.

First, we discretize the sand face rate:

$$p_{wD} \approx \frac{1}{q} \sum_{i=1}^{n} (q_{sf,i} - q_{sf,i-1}) p_{wDc} (t_D - t_{D,i-1})$$

where p_{wD} is the dimensionless pressure that accounts for wellbore storage, q is the (constant) surface rate, and q_{sf} is the sand face rate. Here, the subscript i denotes denotes discretized time steps.

We define the dimensionless rate as $q_D = \frac{q_{sf}}{q}$, so the expression becomes:

$$p_{wD} \approx \sum_{i=1}^{n} (q_{D,i} - q_{D,i-1}) p_{wDc} (t_D - t_{D,i-1})$$

$$p_{wD} \approx \sum_{i=1}^{n} \frac{q_{D,i} - q_{D,i-1}}{t_{D,i} - t_{D,i-1}} \left[p_{wDc} \left(t_D - t_{D,i-1} \right) \right] \left(t_{D,i} - t_{D,i-1} \right)$$

If we take the limit $n \to \infty$ (divide the interval so that the $q_{D,i} - q_{D,i-1}$ becomes infinitesimally small),

$$p_{wD} = \int_0^{t_D} \frac{d}{d\tau} q_D(\tau) p_{wDc}(t_D - \tau) d\tau$$

This is a convolution integral. Therefore, in the Laplace domain:

$$\mathcal{L}\left[p_{wD}\right] = s\mathcal{L}\left[q_D\right]\mathcal{L}\left[p_{wDc}\right] \tag{1}$$

where s is Laplace variable.

From the definition of the wellbore storage effect:

$$q_D + C_D \frac{dp_{wD}}{dt_D} = 1$$

Take the Laplace transform:

$$\mathcal{L}\left[q_{D}\right] + sC_{D}\mathcal{L}\left[p_{wD}\right] = \frac{1}{s}$$

Rearranging:

$$\mathcal{L}\left[q_D\right] = \frac{1}{s} - sC_D \mathcal{L}\left[p_{wD}\right] \tag{2}$$

Substituting Equation 2 into Equation 1, we eliminate $\mathcal{L}[q_D]$:

$$\mathcal{L}[p_{wD}] = s \left(\frac{1}{s} - sC_D \mathcal{L}[p_{wD}]\right) \mathcal{L}[p_{wDc}]$$
$$\left(1 + s^2 C_D \mathcal{L}[p_{wDc}]\right) \mathcal{L}[p_{wD}] = \mathcal{L}[p_{wDc}]$$
$$\mathcal{L}[p_{wD}] = \frac{\mathcal{L}[p_{wDc}]}{1 + s^2 C_D \mathcal{L}[p_{wDc}]}$$

This is a very interesting and elegant result. It shows that if we have the constant-rate solution, we can modify it to account for wellbore storage under a variable-rate condition.