
AEB Control Structure
7 UCAs, 1 control action covered, 6 with no controlAction reference
AEB ECU (Controller)
CA-01: Apply Emergency Brake
[command]
1 UCA
CA-02: Release Brake Command
[command]
CA-03: Issue Driver Warning
[warning]
FB-01: Brake Pressure Feedback
[sensor]
Hydraulic Brake Actuator (Controlled Process)