




Hot Water Generation



- 1. Steam main valve
- 2. Steam PRV
- 3. Steam Pressure gauge (After regulator)
- 5. Tank 1 pressure gauge
- 4. Steam Pressure gauge (Before Regulator)
- 6. Safety relief valve
- 7. Steam Pressure Sensor
- 8. Steam Condensed Drain valve
- 9. Tank 1 Compressed Air main valve
- 10. Tank 1 Compressed Air regulator
- 11. Tank 1 Air filter (5 & 0.2 micron)
- 12. Tank 1 Vent Filter

- 13. Tank 1 Air SRV below vent filter
- 14. Tank 1 Pressure sensor
- 15. Tank 1 Temperature sensor
- 16. Tank 1 level 1 sensor
- 17. Tank 1 Level 2 Sensor
- 18. Soft water intel valve
- 19. Hot water Transfer valve
- 20. Tank 1 drain manual valve
- 21. Tank 2 Compressed Air main valve
- 22. Tank 2 Compressed Air Regulator
- 23. Tank 2 Air filter (5 & 0.2 micron)
- 24. Tank 2 Vent Filter

- 25. Tank 2 Air SRV below vent filter
- 26. Tank 2 Pressure sensor
- 27. Tank 2 Temperature sensor
- 28. Tank 2 level 1 sensor
- 29. Tank 2 Level 2 Sensor
- 30. Heater
- 31. Tank 2 pressure gauge
- 32. Tank 2 drain manual valve
- 33. Tank 2 Distribution valve
- 34. Control panel
- 35. HMI
- 36. Heat exchanger

- 37. Pump
- 38. Tank 3 outlet valve
- 39. Tank 3 inlet valve
- 39. Common outlet valve for tank 1 and 2
- 40. Common inlet valve for tank 1 and 2
- 41. Inlet valve for Tank 2 jacket
- 42. Inlet valve for Tank 2
- 43. Inlet valve for Tank 1 jacket
- 44. Inlet valve for Tank 1
- 45. Outlet valve for Tank 2
- 46. Outlet valve for Tank 2 jacket
- 47. Outlet valve for Tank 1
- 48. Outlet valve for Tank 1 jacket

Prepared by

Checked by

Approved by