
## Chapter 23

# **Boolean Operations and Primitives**



#### **Learning Objectives**

In this chapter, we introduce a set of tools, called *Boolean operators*, that allow important additive and subtractive interactions between objects. We also introduce the concept of AutoCAD primitive shapes, known as just *primitives*. We specifically look at

- Union
- Subtract
- Intersect
- Box
- Wedge
- Cone
- Sphere
- Cylinder
- Torus
- Pyramid

By the end of this chapter, you will be able to create designs that feature openings and holes as well as complex unions and intersections. Also, you will understand basic primitive shapes and be able to apply them in design work as necessary. Estimated time for completion of this chapter: 2–3 hours.

#### 23.1 INTRODUCTION TO BOOLEAN OPERATIONS

We have thus far been able to put together a few fairly simple objects using extrude and the 3D manipulation commands (mirror3D, rotate3D, etc.). What we still miss is the ability for objects to interact with each other, such as being fused together (e.g., two adjoining walls) or subtracted from each other (e.g., a hole in a wall representing a window).

This functionality, referred to as Boolean operations, is very important for advanced 3D modeling in both architectural and mechanical design. We cover the three Boolean operations of union, subtract, and intersect. The functionality of each can be represented by two overlapping circles (representing two solids), as shown in Fig. 23.1.




FIGURE 23.1 Boolean operations.

These circles also form the AutoCAD icons for these operations. As you can see from the shaded areas, the solids can be

- Joined together completely.
- Subtracted, leaving only one part of the solid (either one can be chosen).
- Intersected where only the intersecting geometry remains.

All three Boolean operators can be accessed via typing, cascading menus, a toolbar (Modeling toolbar, which you should already have up), and of course the Ribbon.

#### Union

The union operation fuses solids or regions together into one object. This is an irreversible operation, so be careful before you implement it. Objects do not actually have to be touching to be joined together. Union is not as commonly used as subtract but does find some use when joining together walls or mechanical assemblies.

Let us give union a try by first creating two solid cubes of any size and positioning them to intersect each other, as seen in Fig. 23.2. Notice that their grips have been activated, and you can see that the two cubes are distinct and separate entities, even though they are touching.





FIGURE 23.2 Two solid cubes before union.



**Step 1.** Start the union command via any of the preceding methods.

AutoCAD says: Select objects:

Step 2. Select both cubes (they turn dashed) and press Enter. Both cubes now are fused, as seen in Fig. 23.3. Notice how the grips reflect one entity, not two. Go ahead and move the objects; they move as one. This becomes even clearer if we switch to wireframe (Fig. 23.4), with a color change for additional clarity.




FIGURE 23.3 One solid cube after union (shaded view).





FIGURE 23.4 One solid cube after union (wireframe).

#### **Subtract**


This is a frequently used command, and it is quite indispensable in 3D work. As you may have guessed from the name, it involves the process of subtracting one object from another. In AutoCAD, this is the only way to take away material to create an empty space. Examples of this include the creation of doors and windows in 3D architectural floor plans and bolt holes in mechanical design, just to name a few. Let us set up just such a situation with a flat plate and a circle, which are then extruded and subtracted to form a hole.

Staying in wireframe mode (for clarity), draw a  $10'' \times 10''$  square, extruding it to 2'', as shown in Fig. 23.5.

Now, draw a guideline from corner to corner (use endpoints) of the top surface of the extruded rectangle and a circle of 2" radius based on the midpoint of the guideline, as shown in Fig. 23.6. Note that switching to the wireframe view and adding temporary guidelines is a common technique in 3D.




**FIGURE 23.5**  $10'' \times 10'' \times 2''$  block.



**FIGURE 23.6**  $10'' \times 10'' \times 2''$  block with a circle.

You can erase the guideline and extrude the circle a total of -2'' (yes, that is a negative sign), as seen in Fig. 23.7. Although it seems like we are done, we are not; the "hole" is not yet a hole.

The final step is to subtract the extruded circle from the extruded rectangle, leaving a hole in its place.



- **Step 1.** Start up the subtract command via any of the preceding methods.
  - AutoCAD says: Select solids, surfaces, and regions to subtract from... Select objects
- Step 2. Here, you have to be careful. You must first select the material that you want to keep. In this case, it is the extruded square. Go ahead and select it, then press Enter.
  - AutoCAD says: Select solids and regions to subtract... Select objects:
- Step 3. Select the material you want to get rid of to make the hole. That of course is the extruded circle.

The subtraction operation is performed. Although you may not be able to immediately see what you did, a simple switch to the shaded mode reveals the hole, as seen in Fig. 23.8.




FIGURE 23.7 Circle extruded.




FIGURE 23.8 Completed subtraction operation.

Be sure you thoroughly understand the essence of the subtract command; as mentioned earlier, we use it often. The key is to visualize what material you want removed and where and to create a shape to exactly reflect that. Remember again that the first selection is always for the material you want to keep; the second is for the material you want to remove.

#### **Intersect**

The final Boolean command creates a new shape out of the overlapping parts of other shapes and can be used to create some interesting objects. Let us create a simple intersection. Use the previous rectangle with the hole and copy it to the side (with Ortho on) to create two shapes that intersect each other. Fig. 23.9 shows you what you get.

Notice the overlap between the shapes. This is what is kept after the intersection command is executed.




FIGURE 23.9 Intersected shapes.

- **Step 1.** Start intersect via any of the preceding methods.
  - AutoCAD says: Select objects:
- Step 2. Select both pieces and press Enter. The result is shown in Fig. 23.10; only the intersecting part remains.





FIGURE 23.10 Completed intersect operation.


#### 3D Modeling Exercise: Building Wall With Door and Window

This next practice drawing is a very important one. We are creating a basic 3D model of two building walls, complete with a door and a window opening. Although this model is quite simple, it contains many of the important elements needed to create an entire building in 3D, the differences being only the amount of pieces present and some minor refinements. All the essentials are here, however, so follow all the steps closely.


- Step 1. Draw two walls that are 8' high and 10' long, with a thickness of 5". One way to do this is to first draw a rectangle that is  $5'' \times 10'$  and extrude it to 8'. Then, copy the structure and reattach the copy at  $90^{\circ}$  to the original wall. Fig. 23.11 shows what you should see in wireframe mode.
- Step 2. Use the union command to fuse the walls together. Fig. 23.12 shows another, slightly rotated, view of the walls in wireframe after the application of union. Notice where they intersect; they are clearly in one piece, not two separate
- Step 3. Now create a  $36'' \times 36''$  window (off to the side) as well as a 36'' widex 72'' high door (also off to the side). Both should be 5" thick, as that is the overall thickness of the walls. Rotate3D the objects into position if needed. The result is shown in Fig. 23.13.
- Step 4. Let us think carefully about what to do next. The window is actually a hole in the wall, so we need not reuse it. All we need to do is position it in the right place and subtract. The door is a slightly different story. We need one copy of it to make the opening in the first place, and one copy to then install into the new opening (and rotate into an open position). So it is a good idea to make a copy of the door right now, because the process of subtracting deletes the original. Do not forget this, or you will end up redoing the door after using the original to create the opening.
- Step 5. After copying the door, insert it carefully into the wall, making sure it is lined up correctly (midpoint of bottom front of door to midpoint of bottom front of wall). Then, insert the window in a similar manner and raise it up (using



**FIGURE 23.11** 3D modeling exercise, Step 1.




**FIGURE 23.12** 3D modeling exercise, Step 2.



**FIGURE 23.13** 3D modeling exercise, Step 3.

Ortho) to roughly the halfway point in the wall. You may have your own method of doing this as well, but either way, Fig. 23.14 shows what you should have as a result.

- Step 6. Go ahead and subtract out the window and the door. Fig. 23.15 shows what you see in wireframe mode. Fig. 23.16 shows the same thing in shaded mode with color added.
- Step 7. Finally, let us put the copy of the door back where it belongs and give it  $a 30^{\circ}$  rotation (negative again). The final result is in Fig. 23.17.



**FIGURE 23.14** 3D modeling exercise, Steps 4 and 5.




FIGURE 23.15 3D modeling exercise, Step 6 (wireframe).




FIGURE 23.16 3D modeling exercise, Step 6 (solid).




FIGURE 23.17 3D modeling exercise, Step 7.

#### **INTRODUCTION TO PRIMITIVES** 23.2

We now go over a very basic set of tools that you may find useful in certain situations. Called *primitives*, they are nothing more than ready-to-go shapes built into AutoCAD. Think of them as Lego pieces for computer-aided design; all you need to do is specify a few dimensional values and place them in your drawing as needed. The available primitives are


- box
- wedge
- cone
- sphere
- cylinder
- torus
- pyramid

As with most commands you learn in AutoCAD, there are four ways to access these tools:

- 1. Typing in the desired primitive and pressing Enter.
- 2. Cascading menus under Draw→Modeling.
- **3.** Using the Modeling toolbar; icons 2–8 from the left.
- **4.** Using the Ribbon; Solid tab.


Once you select the primitive via one of these methods, simply enter the shape's dimensional values as prompted (such as height, width, angle) or just click or move the mouse for random values. It is best to have the Conceptual Visual Style shading turned on, as the shapes become clearer, as well as staying in the 3D SW Isometric View, to get the full effect. Hold off with trying the other shapes on the Modeling toolbar, as we go over them in advanced chapters. Finally, all primitives can be erased, moved, copied, and rotated in space, just like any other solid shape.

#### **Box**



- **Step 1.** To try this first primitive, use any of the preceding methods.
  - AutoCAD says: Specify first corner or [Center]:
- **Step 2.** Click anywhere on the screen.
  - AutoCAD says: Specify other corner or [Cube/Length]:
- Step 3. A 2D solid rectangle is drawn based on the movements of your mouse, or you can enter a value by pressing \( \triangle \) for length. Click randomly or enter a value.
  - AutoCAD says: Specify height or [2Point] <7.2545>:
- Step 4. Drag your mouse up (or enter a value) and the shape is automatically extruded into a cube, as seen in Fig. 23.18.

### Wedge



- **Step 1.** To try this primitive, use any of the preceding methods.
  - AutoCAD says: Specify first corner or [Center]:
- **Step 2.** Click anywhere on the screen.
  - AutoCAD says: Specify other corner or [Cube/Length]:
- Step 3. A 2D solid rectangle (the base of the wedge) is drawn based on the movements of your mouse, or you can enter a value by pressing L for length. Click randomly or enter a value.
  - AutoCAD says: Specify height or [2Point] <2.0000>:
- Step 4. Drag your mouse up (or enter a value) and the wedge shape is automatically extruded, as seen in Fig. 23.19.




FIGURE 23.18 Box primitive.





FIGURE 23.19 Wedge primitive.

#### Cone



- **Step 1.** To try this primitive, use any of the preceding methods.
  - AutoCAD says: Specify center point of base or [3P/2P/Ttr/Elliptical]:
- **Step 2.** Click anywhere on the screen or use the 3P, 2P Ttr features, as in the 2D world.
  - AutoCAD says: Specify base radius or [Diameter] <7.1596>:
- Step 3. A 2D solid circle (the base of the cone) is drawn based on the movements of your mouse, or you can enter a value by typing in a radius or pressing d for diameter. Click randomly or enter a value.
  - AutoCAD says: Specify height or [2Point/Axis endpoint/Top radius] <6.9580>:
- Step 4. Drag your mouse up (or enter a value) and the cone shape is automatically extruded, as seen in Fig. 23.20. The command has some interesting suboptions, such as Top radius, which can chop off the pointy top of the cone. Experiment with these options.






FIGURE 23.20 Cone primitive.


### **Sphere**



- **Step 1.** To try this primitive, use any of the preceding methods.
  - AutoCAD says: Specify center point or [3P/2P/Ttr]:
- Step 2. Click anywhere on the screen or use the 3P, 2P Ttr features, as in the 2D world.
  - AutoCAD says: Specify radius or [Diameter] <5.7587>:
- Step 3. A solid sphere is drawn based on the movements of your mouse, or you can enter a value by typing in a radius or pressing d for diameter. The final shape is shown in Fig. 23.21.



### Cylinder



- **Step 1.** To try this primitive, use any of the preceding methods.
  - AutoCAD says: Specify center point of base or [3P/2P/Ttr/Elliptical]:
- **Step 2.** Click anywhere on the screen or use the 3P, 2P Ttr features, as in the 2D world.
  - AutoCAD says: Specify base radius or [Diameter] <7.9122>:
- Step 3. A solid circle (the base of the cylinder) is drawn based on the movements of your mouse, or you can enter a value by typing in a radius or pressing d for diameter.
  - AutoCAD says: Specify height or [2Point/Axis endpoint] <22.8198 >:
- Step 4. Drag your mouse up (or enter a value) and the cylinder shape is automatically extruded, as seen in Fig. 23.22.





FIGURE 23.22 Cylinder primitive.

#### **Torus**



- Step 1. A torus is basically a donut. To try this primitive, use any of the preceding methods.
  - AutoCAD says: Specify center point or [3P/2P/Ttr]:
- **Step 2.** Click anywhere on the screen or use the 3P, 2P Ttr features, as in the 2D world.
  - AutoCAD says: Specify radius or [Diameter] <6.3128>:
- Step 3. A hoop is drawn based on the movements of your mouse or you can enter a value by typing in a radius or pressing d for diameter.
  - AutoCAD says: Specify tube radius or [2Point/Diameter] <6.2433>:
- Step 4. Drag your mouse (or enter a value) and the torus shape is automatically extruded, as seen in Fig. 23.23.





FIGURE 23.23 Torus primitive.

### **Pyramid**



- **Step 1.** To try this primitive, use any of the preceding methods.
  - AutoCAD says: 4 sides Circumscribed Specify center point of base or [Edge/Sides]:
- Step 2. You can then click anywhere, or use the Sides option to give the pyramid more than four sides, a useful feature.
  - AutoCAD says: Specify base radius or [Inscribed] <22.2294>:
- Step 3. A pyramid base is drawn based on the movements of your mouse, or you can enter a value. The inscribed feature works in the same manner as it was used with the polygon command.
  - AutoCAD says: Specify height or [2Point/Axis endpoint/Top radius] <38.8857>:
- Step 4. Drag your mouse (or enter a value) and the pyramid shape is automatically extruded, as seen in Fig. 23.24. Just like with the cone, you can vary the top radius of the shape.




FIGURE 23.24 Pyramid primitive.

#### 23.3 APPLYING PRIMITIVES

So, how useful are these primitives in real-life applications? The best way to describe this is "extremely useful in isolated cases and not used much in most others." For example, if you need a shape not quickly done any other way, such as a sphere or torus (you can easily extrude the other shapes), then primitives are indispensable. But, since most of the 3D objects you will design are not simple shapes, primitives are rarely used. It is still a good skill to have and an easy one to learn. Go over each shape several times, add some color, and be sure to practice 3D orbit to get various views of the objects, as well as switching between wireframe and shaded.

This chapter concludes 3D "flat design." These basic 3D skills go a long way in creating a realistic model of a building or even a simple mechanical device. In the coming chapters, we add additional tools and refinement, starting with curved design. For now, be sure to completely understand everything and practice everything learned thus far.

#### 23.4 **SUMMARY**

You should understand and know how to use the following concepts and commands before moving on to Chapter 24, Solid Modeling:

- Union
- Subtract
- Intersect
- Box
- Wedge
- Cone
- Sphere
- Cylinder
- Torus
- Pyramid


#### **Review Questions**

Answer the following based on what you learned in this chapter:


- 1. What are the three Boolean operations?
- 2. In what toolbar are they found?
- **3.** Is union a permanent setting?
- **4.** Why is it a good idea to make a copy of something that is being subtracted?
- 5. Name the seven primitives covered in this chapter.
- **6.** What four methods are used to create primitives?
- 7. What two primitives cannot be created any other way?

#### **Exercises**


1. Using your new Boolean skills, create this washer and bolt assembly. Make the washer 3" square and the hole (as well as the bolt) 0.75" in diameter, and size the hex bolt top off of that. You need the circle, extrude, and polygon commands among others. (Difficulty level: Easy; Time to completion: 10 minutes.)




2. Create the following design of a bed. It consists of a thick panel, a mattress, two identical headboards (with cutouts), and two pillows angled at 30°. Sizing is entirely up to you; draw a reasonable-looking base panel and size the rest from that. You need the rectangle, line, arc, pedit, extrude, fillet, mirror3D, and subtract commands among others, as well as some UCS rotations. (Difficulty level: Moderate; Time to completion: 30 minutes.)



3. Create the following design of a drilled, vented brake rotor. Create a circle of the given size, extrude to 1", add the center axle cutout, and arrange the drilled holes as shown on the left, arraying them eight times. Extrude and subtract as needed. Shade and color to finish the model as seen on the right. (Difficulty level: Moderate; Time to completion: 15 minutes.)



4. Create the following simplified model of construction excavator. Begin all extrusions with basic 2D shapes using some starter dimensions given in the exploded view. Size all others from them. You need to use the subtract command for the wheels/track assembly as well as the cab. In addition, the union command was used to make the cab one piece. Pretty much everything else was done via basic extrusion, 3D rotation, and careful positioning of objects. (Difficulty level: Moderate/Advanced; Time to completion: 45-60 minutes.)



5. Create each primitive shape once via only mouse clicking and once using keyed-in values. (Difficulty level: Easy; Time to completion: 5-10 minutes.)
















6. Create the following layout using primitives and the rectangle command. All sizes and positioning are approximate. (Difficulty level: Easy; Time to completion: 10 minutes.)



7. Create the following shapes using primitives and Boolean interactions. All sizes and positioning are approximate. (Difficulty level: Easy; Time to completion: 10 minutes.)

