WASHPRO WAREWASHING

Commercial Warewashing Systems - Installation Guide

Field	Value	Field	Value
Document ID	PT-011	Revision	4
Effective Date	1 January 2026	Status	Current
Document Type	Installation Guide	Product Family	WashPro Warewashing

1. Purpose and Scope

Defines site, water, electrical, drainage, clearance, positioning, workflow, and commissioning requirements for UW-50, UW-70, HT-100, HT-140, GW-40, and GW-60.

2. Electrical Requirements

Model	Supply	Rated Power
UW-50	380-415 V, 3 phase, 50 Hz	5.5 kW
UW-70	380-415 V, 3 phase, 50 Hz	6.5 kW
HT-100	380-415 V, 3 phase, 50 Hz	9.5 kW
HT-140	380-415 V, 3 phase, 50 Hz	12.0 kW
GW-40	220-240 V, 1 phase, 50 Hz	4.5 kW
GW-60	380-415 V, 3 phase, 50 Hz	5.8 kW

3. Water and Drainage

• Inlet-water temperature: 5-60 degrees C

• Dynamic inlet pressure: 0.20-0.40 MPa

• Potable water

• Dedicated shut-off valve

• Approved sanitary drainage

Water condition can affect wash performance, spotting, scale, heating reliability, and maintenance.

4. General Clearances

Location	Minimum
Rear	100 mm
Left	75 mm
Right	75 mm
Top - undercounter/glasswasher	100 mm
Top - hood-type, hood closed	300 mm

5. Hood-Type Workflow

HT installations must consider dirty-rack staging, pre-rinse, loading table, machine, unloading table, clean-rack staging, operator movement, and full hood-opening height. The machine body alone is not the complete operational footprint.

6. Pre-Rinse and Throughput

Machine rated throughput assumes racks can be presented at an appropriate rate. A pre-rinse, loading, or unloading bottleneck can reduce actual wash-area throughput without indicating a machine-performance problem.

7. Site-Fit Assessment

• Equipment fit: machine plus required clearances

• Utility fit: water, drainage, electrical supply

• Workflow fit: safe loading and unloading at required rate

• Service fit: maintenance access

A positive answer to only one of these does not establish complete installation feasibility.

8. Pre-Commissioning

• Verify model and clearances

• Verify electrical supply and grounding

• Verify dynamic water pressure

• Verify drainage and treatment

• Verify chemical connections

• Verify hood movement where applicable

• Review applicable technical bulletins

• Complete test cycles and workflow checks

9. Limitations

Do not confirm installation from machine dimensions alone, ignore hood-opening height, reduce clearance without authorization, assume treatment compatibility from connection size, or treat rated machine throughput as guaranteed wash-area throughput.

Specifications and requirements are subject to controlled technical revision. Always verify the current applicable documentation before a final customer-facing or installation commitment.