Variables and Functions in Arduino

Programming in Arduino's C language is very different than the majority of programming that you have done so far in the engineering curriculum, which heavily utilizes Matlab. This may create a steep learning curve, but once you gain a hold of the syntax, programming the Arduino will not be that difficult. One of the biggest differences between C and Matlab is how functions and variables are declared and used. This document will highlight the differences in program structure, functions, and variables to help get you started.

Basic Arduino Set-Up

A *sketch* is the name Arduino uses for programs. It is the unit of code that is uploaded to and run on an Arduino board. All sketches **must** have 2 void type functions, setup() and loop(). "Void" simply means that the function doesn't return any value.

The setup() method is run once just after the Arduino is powered on, and the loop() is run continuously afterwards. The setup() is where you want to do any initialization steps, and in loop(), you want to run the code you want to run over and over again. Your basic sketch should look something like this:



Figure 1: Bare minimum code required for an Arduino sketch

Variables

A variable is a place to store a piece of date. It has a name, a type, and a value.

Name: You can name a variable any word that is not already a keywords in Arduino. You should also avoid beginning variable names with numeral characters

Type: Unlike Matlab, you must declare all variable types before using them when coding in Arduino. In choosing a variable type, it is important to consider the size of the numbers you want to store. Variables will roll on when the value stored exceeds the space assigned to store it. Here are some common variable types:

Name	Description	Range of Values	Size
int	Integer, primary data-type for number storage	-32,768 – 32,767	2 bytes
long	Extended size variable for number storage	-2,147,483,648 – 2,147,483,647	4 bytes
float	Floating point numbers, used for numbers that	-3.402835E38 — 3.402835E38	4 bytes
	have a decimal point. Floating numbers allow		
	for 6-7 points of data precision. However, math		
	with float variable is significantly slower.		
double	Double precision floating number. These take up	-3.402835E38 — 3.402835E38	4 bytes
	4-bytes on the Arduino UNO - the same as float		
	variables - so even with double implementation,		
	there is no gain in precision.		
byte	Stores an 8-bit unsigned number	0 – 255	1 byte
boolean	Holds one of two values, true or false	true/false	1 byte

Variables can also be unsigned. This is helpful when dealing solely with positive numbers, as it can essentially double the range of useful values. For example unsigned int can hold values from 0 to 65,535.

When declaring variables, the location of variable declaration matters, and variables can be global or local.

A global variable is declared outside of a function (e.g. setup(), loop(), etc.), and can be seen by every function in the program.

A local variable is declared within a function and can only be seen by that function. Local variables are useful when programs start to become larger and complex. They insure that only one function has access to its own variables and prevents programming errors when one function may accidentally modify samename variables used by another function.

Value: When declaring a variable, setting an initial value is *optional*. For example:

```
unsigned int Variable1;
unsigned int Variable2=0;
```

Both are correct ways to declare variables. It is often to useful to initialize variables, but it will be dependent on the information that the variable is actually storing.

Functions

Creating Modular Code

When coding in Arduino, it is best to use functions and make your code as modular as possible, for a number of reasons:

- Helps the keep the program organize and often helps to conceptualize the program
- Makes the code more readable and easier to debug by codifying the one action in one place
- Makes the whole sketch smaller when sections of code are reused many times
- Makes it easier to reuse code in other programs

As you know, Arduino sketches require 2 functions: setup() and loop(). All other functions must be created outside the brackets of those two functions. In making your own function, it is helpful to designate a **New Tab** in your Arduino sketch to the function. The Arduino website provides a helpful diagram of the basic structure of functions:

Anatomy of a C function Datatype of data returned, any C datatype. "void" if nothing is returned. Function name int myMultiplyFunction(int x, int y) { int result; Return statement, datatype matches declaration. return result; Curly braces required.

Figure 2: Anatomy of a C Function.

To "call" on this simple multiplication function, we pass it the parameters of interest.

```
ans = myMultiplyFunction(4,6); // ans now contains the value 24
```