- 1) Make sure all pieces one in elastomer table
- 2) Make sive solvable support fits easily in the mold Lo IF not, sand the delgas with a file
- 3) Apply a thin coat of mold release (Ecose release 200 by Mann) if nessecary. If you have not sprayed in last day. 4 Never were accome with any of treports
- 4) Mixel: use the non-disposable cup (3piecs). The lid, cup Esdely. 4) weigh dobut apprount (silicane ripher resps) and Set bulane in mixer to that weight.
- Sero scale after placing the cup on top of it. We pour raighly BOg from each part of Drapon Skin 20. During the pouring process precision mothers. We want a constant flow rate of rubber from a short distance from the cup if we pour too fast, bubbles will be trapped. 20 minutes start here.

  6) Use the thinky mixer with 2000 rpm /1:00 min settings for mix/deforam. Don't forget to adjust the scale.

- 7. Very very correquily empty the mixed silicone rubber into the bottom meld, small distance between cup and mold while pouring + slow pouring.
- 8. Vacuum Degass the mold using the ovent vacuum pump. Oven must be at room tempercutiere. Turn vent knob to off/close, Vacuum knob must be on. Turn on the racuum pump. Leave mold in vacuum for. ~ 10 mins.
- 9. Four Carefully place the support on top of the bottom mold.

  Allow it to naturally submerge if necessary, apply a small constant force to aid it. When the support is fully submerged in the silicone rubber, place (cover mold with the lid.
- 10. Place a small weight on top of mold to beep it ubsed. Cure for ~4hrs.
- 11. Post cure in oven for ~8 hrs @50-65°C
- \* Clean silicone rubber only after it cures.