

CapSense_CSD_P4 Slider Design example project

1.30

Features

- Sensing elements: 5-segment Linear Slider:
 - CY8CKIT-042 and CY8CKIT-042-BLE uses linear slider on board;
 - CY8CKIT-040 uses 5-rows of Trackpad on Trackpad Shield;
- Visual indication of Slider touch position with Tri-color LED

General Description

This example project demonstrates the CapSense CSD component configured with Linear Slider. The HUE of the Tri-color LED displays the scanning results of Linear Slider.

Development kit configuration

The project requires configuration settings changes in order to run on the KIT, different from CY8CKIT-042.

A full description of the supported development KITs, along with more example programs and ordering information, can be found at the following links:

- CY8CKIT-042 http://www.cypress.com/go/cy8ckit-042
- CY8CKIT-040 http://www.cypress.com/go/cy8ckit-040
- CY8CKIT-042-BLE http://www.cypress.com/go/cy8ckit-042-ble

In order to switch from the CY8CKIT-042 to the CY8CKIT-040/CY8CKIT-042-BLE KITs the following steps should be performed:

- 1. Select the appropriate device with a Device Selector called from the project's context menu:
 - CY8C4245AXI-483 for CY8CKIT-042 KIT
 - CY8C4014LQI-422 for CY8CKIT-040 KIT
 - CY8C4247LQI-BL483 for CY8CKIT-042-BLE
- 2. In the case of migration to the CY8CKIT-040 KIT, the LED_2 pin should be removed from the project schematic. Double click on the LED_2, select Built-in tab, set CY_REMOVE parameter to True.
- 3. Change assignment of the pin components to physical pins. In the Workspace Explorer window, double-click the project's design-wide resource file and assign the pins for CapSense_CSD and RGB LED according to Table 1.

Table 1. Pin assignment for the CapSense_CSD_P4_Design project

Pin Name		Development Kit	
	CY8CKIT-042	CY8CKIT-042-BLE	CY8CKIT-040
\Capsense_CSD:Cmod\	P4[2]	P4[0]	P0[4]
\Capsense_CSD:Sns[0]\	P1[1]	P2[1]	P1[4]
\Capsense_CSD:Sns[1]\	P1[2]	P2[2]	P1[5]
\Capsense_CSD:Sns[2]\	P1[3]	P2[3]	P1[6]
\Capsense_CSD:Sns[3]\	P1[4]	P2[4]	P1[0]
\Capsense_CSD:Sns[4]\	P1[5]	P2[5]	P1[7]
LED_1	P0[2]	P3[6]	P1[1]
LED_2	P0[3]	P3[7]	-

Project configuration

The top design schematic is shown in Figure 1.




Figure 1. Top design schematic



The PWMs is configured to drive two LEDs from the Tri-color LED.





Figure 2. PWMs configuration

The CapSense_CSD component is configured with the Tuning method Auto for 1 Linear Slider.







Figure 3. CapSense_CSD Widget Config Tab



The clock system configuration is shown in Figure 5.

PSoC 4100/4200

PSoC4000



PSoC 4100/P4200-BL




Figure 5. "Configure System Clocks" windows

Project Description

The project demonstrates setting the LED color on CY8CKIT-042/CY8CKIT-042-BLE KITs (or LED brightness on CY8CKIT-040) using a CapSense slider touch position. No additional connection is required.



Expected results

On the CY8CKIT-042/CY8CKIT-042-BLE KITs a touch position changes the LED color if moving up and vice versa in the downward direction.

On the CY8CKIT-040 Slider a touch position changes the LED brightness from low to high if moving up and vice versa in the downward direction.



© Cypress Semiconductor Corporation, 2016. This document is the property of Cypress Semiconductor Corporation and its subsidiaries, including Spansion LLC ("Cypress"). This document, including any software or firmware included or referenced in this document ("Software"), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you a personal, non-exclusive, nontransferable license (without the right to sublicense) (1) under its copyright rights in the Software (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units, and (2) under those claims of Cypress's patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE OR ACCOMPANYING HARDWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. To the extent permitted by applicable law, Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of its document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Cypress products are not designed, intended, or authorized for use as critical components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system could cause personal injury, death, or property damage ("Unintended Uses"). A critical component is any component of a device or system whose failure to perform can be reasonably expected to cause the failure of the device or system, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from or related to all Unintended Uses of Cypress products. You shall indemnify and hold Cypress harmless from and against all claims, costs, damages, and other liabili

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.

